

# E.F.I. WATER TEMPERATURE (3SZ-VE)

## INSPECTION

### 1. CHECK EFI COOLANT TEMPERATURE

- (a) Check the resistance.
  - (1) Using a tester, measure the resistance between the terminals.

**Standard**

Measurement Condition	Standard
When approx. 20°C	2.32 to 2.59 kΩ
When approx. 80°C	0.310 to 0.326 kΩ

**NOTICE:**  
Make sure that the terminal area does not get wet when applying the sensor to water during inspection. Wipe the sensor dry after the check.

ES

