

FRONT SHOCK ABSORBER INSPECTION

B3E021334700W01

1. Remove the front shock absorber.
2. Inspect for damage and oil leakage.
3. Compress and extend the shock absorber piston rod **at least three times** at a steady rate. **From the fourth** compression stroke, verify that the operational force does not change and that there is no unusual noise.
 - If there is any malfunction, replace the shock absorber.