

DTC P0762 [FN4A-EL]

B3E050219090W28

DTC P0762	Shift solenoid C stuck on
DETECTION CONDITION	<ul style="list-style-type: none"> • When DTC P0731 and P0732 are not output, and both the following conditions are satisfied. <ul style="list-style-type: none"> - When all conditions below are satisfied while driving in 3GR. <ul style="list-style-type: none"> • ATF temperature 20 °C {68 °F} or more. • Driving in D range • Engine running • Turbine speed within 225-4,987 rpm • Differential gear case (output) revolution speed 35 rpm or more • Revolution ratio of forward clutch drum revolution to differential gear case revolution below 0.863 or 1.249 or more • None of the following present: DTC P0500, P0706, P0707, P0708, P0712, P0713, P0715, P0751, P0752, P0753, P0756, P0757, P0758, P0761, P0762, P0763, P0766, P0767, P0768, P0771, P0772, P0773 - When all conditions below are satisfied while driving in 4GR <ul style="list-style-type: none"> • ATF temperature 20 °C {68 °F} or more • Driving in D range • Engine running • Turbine speed within 225-4,987 rpm • Vehicle speed 50 km/h {31mph} or more • Differential gear case (output) revolution speed 35 rpm or more • Throttle opening angle at closed throttle position • Revolution ratio of forward clutch drum revolution to differential gear case revolution below 0.6 or 1.249 or more • None of the following present: DTC P0500, P0706, P0707, P0708, P0712, P0713, P0715, P0751, P0752, P0753, P0756, P0757, P0758, P0761, P0762, P0763, P0766, P0767, P0768, P0771, P0772, P0773 <p>Diagnostic support note:</p> <ul style="list-style-type: none"> • This is a continuous monitor (CCM). • The MIL illuminates if the PCM detects the above malfunction condition in two consecutive drive cycles or in one drive cycle while the DTC for the same malfunction has been stored in the PCM. • The PENDING CODE is available if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA is available. • The AT warning light illuminates. • The DTC is stored in the PCM memory.
POSSIBLE CAUSE	<ul style="list-style-type: none"> • ATF level low • Deteriorated ATF • Shift solenoid C and pressure control solenoid stuck • Control valve stuck • PCM malfunction

Diagnostic procedure

STEP	INSPECTION	ACTION
1	VERIFY FREEZE FRAME DATA HAS BEEN RECORDED	Yes Go to the next step.
	• Has the FREEZE FRAME DATA been recorded?	No Record the FREEZE FRAME DATA on the repair order, then go to the next step.
	VERIFY RELATED REPAIR INFORMATION	Perform repair or diagnosis according to the

2	AVAILABILITY • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available?	Yes	available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT ATF CONDITION • Turn the ignition switch to the LOCK position. • Inspect the ATF condition. - Clear red: Normal - Milky: Water mixed in fluid - Reddish brown: Deteriorated ATF • Is it normal? (See Automatic Transaxle Fluid (ATF) Condition Inspection.)	Yes	Go to the next step.
		No	If the ATF color is milky or reddish brown, replace ATF, then go to Step 5. (See AUTOMATIC TRANSAXLE FLUID (ATF) REPLACEMENT.)
4	INSPECT ATF LEVEL • Start the engine. • Warm up the ATX. • Is the ATF level within the specification? (See Automatic Transaxle Fluid (ATF) Level Inspection.)	Yes	Go to the next step.
		No	Add ATF to the specified level, then go to Step 7. (See Automatic Transaxle Fluid (ATF) Level Inspection.)
5	INSPECT LINE PRESSURE • Start the engine. • Measure the line pressure. Specification Idle: 330-470 kPa {3.4-4.7 kgf/cm², 48-68 psi} Stall: 1,090-1,250 kPa {11.2-12.7 kgf/cm², 159-181 psi} (Z6) 1,160-1,320 kPa {11.8-13.5 kgf/cm², 168-191 psi} (LF) • Are the line pressures within the specifications? (See Line Pressure Test.)	Yes	Go to the next step.
		No	• All ranges: Replace the oil pump or control valve body, then go to Step 7. • Any ranges: Replace the ATX, then go to Step 7. (See AUTOMATIC TRANSAXLE REMOVAL/INSTALLATION [Z6].) (See AUTOMATIC TRANSAXLE REMOVAL/INSTALLATION [LF].) (See ATX Workshop Manual FN4A-EL.)
6	INSPECT OPERATION OF EACH VALVE AND EACH SPRING • Turn the ignition switch to the LOCK position. • Remove the control valve body. • Disassemble the control valve body. • Is each valve operation normal and is the return spring normal? (See CONTROL VALVE BODY REMOVAL.) (See CONTROL VALVE BODY INSTALLATION.) (See ATX Workshop Manual FN4A-EL.)	Yes	Replace the ATX, then go to the next step. (See AUTOMATIC TRANSAXLE REMOVAL/INSTALLATION [Z6].) (See AUTOMATIC TRANSAXLE REMOVAL/INSTALLATION [LF].) (See ATX Workshop Manual FN4A-EL.)
		No	Repair or replace the shift valve and return spring, then go to the next step. (See CONTROL VALVE BODY REMOVAL.) (See CONTROL VALVE BODY INSTALLATION.) (See ATX Workshop Manual FN4A-EL.)
	VERIFY TROUBLESHOOTING OF DTC P0762 COMPLETED		

7	<ul style="list-style-type: none"> • Make sure to reconnect all the disconnected connectors. • Clear the DTC from the memory using the WDS or equivalent. • Start the engine. • Warm up the ATX. • Drive the vehicle under the following conditions and make sure that gears shift smoothly from 1GR to 4GR: <ul style="list-style-type: none"> - ATF temperature: 20 °C {68 °F} or more - Drive in the D range - Throttle opening angle (TP PID): 0% (4GR only) - Vehicle speed (VSS PID): 50 km/h {31 mph} or more (4GR only) 	Yes	Replace the PCM, then go to the next step. (See PCM REMOVAL/INSTALLATION [ZJ, Z6].) (See PCM REMOVAL/INSTALLATION [LF].)
		No	Go to the next step.
8	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "After Repair Procedure". (See AFTER REPAIR PROCEDURE [FN4A-EL].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection.
		No	DTC troubleshooting completed.