

- [!\[\]\(1207edb9a08751d3d55970560645ed23_img.jpg\) CLUTCH LOCATION INDEX](#)
- [!\[\]\(d7a34a706cfa4ef37c62a369101e1b36_img.jpg\) GENERAL PROCEDURES \(CLUTCH\)](#)
- [!\[\]\(7325769475e8f4bf67f57a0cbebc8ab9_img.jpg\) CLUTCH FLUID INSPECTION](#)
- [!\[\]\(1a468f12cdfc63dc07896d0781cf55ec_img.jpg\) CLUTCH FLUID REPLACEMENT](#)
- [!\[\]\(a9a0baec8ceb7d7c04180806eca8d32a_img.jpg\) CLUTCH PEDAL INSPECTION](#)
- [!\[\]\(c1ab807d6aebb565b3082513037b5622_img.jpg\) CLUTCH PEDAL REMOVAL/INSTALLATION](#)
- [!\[\]\(083bb479299cb5e55cd99db0433ca6ba_img.jpg\) CLUTCH MASTER CYLINDER REMOVAL/INSTALLATION](#)
- [!\[\]\(ede41f318336daae6cce8449321d11ea_img.jpg\) CLUTCH RELEASE CYLINDER REMOVAL/INSTALLATION](#)
- [!\[\]\(b0cd9d88e5935e4c3891570bfdded05c_img.jpg\) CLUTCH UNIT REMOVAL/INSTALLATION](#)
- [!\[\]\(81bb4e52f43acc06353225c332f66031_img.jpg\) CLUTCH COVER INSPECTION](#)
- [!\[\]\(4862a3d83a50b6aa02d9ef677ec36116_img.jpg\) CLUTCH DISC INSPECTION](#)
- [!\[\]\(b564abb3972f4216a833af91832e1619_img.jpg\) CLUTCH RELEASE COLLAR INSPECTION](#)
- [!\[\]\(3e91863309aa91e589b5ab92c8ebd53f_img.jpg\) PILOT BEARING INSPECTION](#)
- [!\[\]\(bf6def3f21dfdb4b0473718404626f2c_img.jpg\) FLYWHEEL INSPECTION](#)