

- [!\[\]\(1207edb9a08751d3d55970560645ed23\_img.jpg\) ELECTRO HYDRAULIC POWER ASSIST STEERING \(EHPAS\) SYSTEM WIRING DIAGRAM](#)
- [!\[\]\(d7a34a706cfa4ef37c62a369101e1b36\_img.jpg\) ELECTRO HYDRAULIC POWER ASSIST STEERING \(EHPAS\) ON-BOARD DIAGNOSIS](#)
- [!\[\]\(7325769475e8f4bf67f57a0cbebc8ab9\_img.jpg\) DTC B1238](#)
- [!\[\]\(1a468f12cdfc63dc07896d0781cf55ec\_img.jpg\) DTC B1317, B1318](#)
- [!\[\]\(a9a0baec8ceb7d7c04180806eca8d32a\_img.jpg\) DTC B1342](#)
- [!\[\]\(c1ab807d6aebb565b3082513037b5622\_img.jpg\) DTC B1352](#)
- [!\[\]\(083bb479299cb5e55cd99db0433ca6ba\_img.jpg\) DTC B2141, B2477](#)
- [!\[\]\(ede41f318336daae6cce8449321d11ea\_img.jpg\) DTC C1099](#)
- [!\[\]\(b0cd9d88e5935e4c3891570bfdded05c\_img.jpg\) DTC C1278, C1956](#)
- [!\[\]\(81bb4e52f43acc06353225c332f66031\_img.jpg\) ELECTRO HYDRAULIC POWER ASSIST STEERING \(EHPAS\) SYSTEM WIRING DIAGRAM](#)
- [!\[\]\(4862a3d83a50b6aa02d9ef677ec36116\_img.jpg\) FOREWORD](#)
- [!\[\]\(b564abb3972f4216a833af91832e1619\_img.jpg\) PRECAUTION](#)
- [!\[\]\(3e91863309aa91e589b5ab92c8ebd53f\_img.jpg\) SYMPTOM TROUBLESHOOTING](#)
- [!\[\]\(bf6def3f21dfdb4b0473718404626f2c\_img.jpg\) NO.1 POOR POWER STEERING ASSIST](#)