


# **Electrical Wiring Diagram**

**IS 200** 

GXE 10 Series Jan., 1999



# **FOREWORD**

This wiring diagram manual has been prepared to provide information on the electrical system of the IS 200.

Applicable models: GXE10 Series

For service specifications and repair procedures of the above models other than those listed in this manual, refer to the following manuals;

Manual Name	Pub. No.
LEXUS IS 200 Repair Manual	
Volume 1	RM684E1
Volume 2	RM684E2
<ul><li>LEXUS IS 200 New Car Features</li></ul>	NCF165E

All information in this manual is based on the latest product information at the time of publication. However, specifications and procedures are subject to change without notice.

## TOYOTA MOTOR CORPORATION

NOTICE

When handling supplemental restraint system components (removal, installation or inspection, etc.), always follow the direction given in the repair manuals listed above to prevent accidents and supplemental restraint system malfunction.

# IS 200 ELECTRICAL WIRING DIAGRAM

(English)	Section No.	Page	
INTRODUCTION	A	4	
HOW TO USE THIS MANUAL	В	5	
TROUBLESHOOTING		14	
ABBREVIATIONS		19	i E
GLOSSARY OF TERMS AND SYMBOLS		20	
RELAY LOCATIONS		76	Français
ELECTRICAL WIRING ROUTING		96	ō
SYSTEM CIRCUITS	н	132	
GROUND POINT		464	
POWER SOURCE (Current Flow Chart)		476	
CONNECTOR LIST		486	
PART NUMBER OF CONNECTORS		514	
OVERALL ELECTRICAL WIRING DIAGRAM			
		518	

# SCHEMA DE CABLAGE ELECTRIQUE DE LA IS 200

(Français)	N° de section	Page
INTRODUCTION	A	22
COMMENT UTILISER CE MANUEL		23
DEPANNAGE	C	32
ABREVIATIONS	D	37
GLOSSAIRE DES TERMES ET SYMBOLES		38
EMPLACEMENTS DES RELAIS		76
ACHEMINEMENT DES FILS ELECTRIQUES	G	96
CIRCUITS DU SYSTEME	н	134
POINT DE MISE A LA TERRE	1	464
SOURCE D'ALIMENTATION (Schéma du Courant)	J	476
LISTE DE CONNECTEUR	κ	486
INFORMATIONS SUR LE CONNECTEUR	<i>L</i>	496
REFERENCE DES CONNECTEURS	М	514
SCHEMA GENERAL DE CABLAGE ELECTRIQUE	N	520

# ©1999 TOYOTA MOTOR CORPORATION

All rights reserved. This book may not be reproduced or copied, in whole or in part, without the written permission of Toyota Motor Corporation.

# © 1999 TOYOTA MOTOR CORPORATION

Tous droits réservés. Cette publication ne peut être reproduite, copiée, en totalité ou en partie, sans l'autorisation écrite de Toyota Motor Corporation. This manual consists of the following 14 sections:

No.	Section	Description
	INDEX	Index of the contents of this manual.
A	INTRODUCTION	Brief explanation of each section.
В	HOW TO USE THIS MANUAL	Instructions on how to use this manual.
С	TROUBLE- SHOOTING	Describes the basic inspection procedures for electrical circuits.
D	ABBREVIATIONS	Defines the abbreviations used in this manual.
E	GLOSSARY OF TERMS AND SYMBOLS	Defines the symbols and functions of major parts.
F	RELAY LOCATIONS	Shows position of the Electronic Control Unit, Relays, Relay Block, etc. This section is closely related to the system circuit.
G	ELECTRICAL WIRING ROUTING	Describes position of Parts Connectors, Splice points, Ground points, etc. This section is closely related to the system circuit.
	INDEX	Index of the system circuits.
Н	SYSTEM CIRCUITS	Electrical circuits of each system are shown from the power supply through ground points. Wiring connections and their positions are shown and classified by code according to the connection method. (Refer to the section, "How to use this manual"). The "System Outline" and "Service Hints" useful for troubleshooting are also contained in this section.
1	GROUND POINT	Shows ground positions of all parts described in this manual.
J	POWER SOURCE (Current Flow Chart)	Describes power distribution from the power supply to various electrical loads.
К	CONNECTOR LIST	Describes the form of the connectors for the parts appeared in this book.  This section is closely related to the system circuit.
L	CONNECTOR INFORMATION	Indicates the reference page (See Page) showing the part name corresponding to the part number, and the installation position of the part in the vehicle. (For French, Spanish, German manuals only)
М	PART NUMBER OF CONNECTORS	Indicates the part number of the connectors used in this manual.
N	OVERALL ELECTRICAL WIRING DIAGRAM	Provides circuit diagrams showing the circuit connections.

This manual provides information on the electrical circuits installed on vehicles by dividing them into a circuit for each system.

The actual wiring of each system circuit is shown from the point where the power source is received from the battery as far as each ground point. (All circuit diagrams are shown with the switches in the OFF position.)

When troubleshooting any problem, first understand the operation of the circuit where the problem was detected (see System Circuit section), the power source supplying power to that circuit (see Power Source section), and the ground points (see Ground Point section). See the System Outline to understand the circuit operation.


When the circuit operation is understood, begin troubleshooting of the problem circuit to isolate the cause. Use Relay Location and Electrical Wiring Routing sections to find each part, junction block and wiring harness connectors, wiring harness and wiring harness connectors, splice points, and ground points of each system circuit. Internal wiring for each junction block is also provided for better understanding of connection within a junction block.

Wiring related to each system is indicated in each system circuit by arrows (from\_\_, to\_\_). When overall connections are required, see the Overall Electrical Wiring Diagram at the end of this manual.

# **B HOW TO USE THIS MANUAL**



\* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the SYSTEM CIRCUITS SECTION.




- [A] : System Title
- [B] : Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B

Example: 1 Indicates Relay Block No.1

- [C] : ( ) is used to indicate different wiring and connector, etc. when the vehicle model, engine type, or specification is different.
- [D] : Indicates related system.
- [E] : Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows ( ⋈ ).


Outside numerals are pin numbers.



The first letter of the code for each wiring harness and wiring harness connector(s) indicates the component's location, e.g, "E" for the Engine Compartment, "I" for the Instrument Panel and Surrounding area, and "B" for the Body and Surrounding area.

When more than one code has the first and second letters in common, followed by numbers (e.g, IH1, IH2), this indicates the same type of wiring harness and wiring harness connector.

- [F] : Represents a part (all parts are shown in sky blue). The code is the same as the code used in parts position.
- [G] : Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it). Junction Blocks are shaded to clearly separate them from other parts.



[H]: When 2 parts both use one connector in common, the parts connector name used in the wire routing section is shown in square brackets [ ].

[I] : Indicates the wiring color.

Wire colors are indicated by an alphabetical code.

 $B = Black \quad W = White \quad BR = Brown$ 


L = Blue V = Violet SB = Sky Blue R = Red G = Green LG = Light Green

P = Pink Y = Yellow GR = Gray

O = Orange

The first letter indicates the basic wire color and the second letter indicates the color of the stripe.

Example: L - Y



[J] : Indicates a wiring Splice Point (Codes are "E" for the Engine Room, "I" for the Instrument Panel, and "B" for the Body).



The Location of splice Point I 5 is indicated by the shaded section.

[K]: Indicates a shielded cable.




[L] : Indicates the pin number of the connector. The numbering system is different for female and male connectors.

Example: Numbered in order from upper left to lower right

bered in order upper left to right Numbered in order from upper right to lower left





[M] : Indicates a ground point.

The first letter of the code for each ground point(s) indicates the component's location, e.g, "E" for the Engine Compartment, "I" for the Instrument Panel and Surrounding area, and "B" for the Body and Surrounding area.

[N] : Page No.

# **B HOW TO USE THIS MANUAL**

### - SYSTEM OUTLINE -

Current is applied at all times through the STOP fuse to TERMINAL 2 of the stop light SW.

When the ignition SW is turned on, current flows from the GAUGE fuse to TERMINAL 8 of the light failure sensor, and also flows through the rear lights warning light to TERMINAL 4 of the light failure sensor.

## STOP LIGHT DISCONNECTION WARNING

When the ignition SW is turned on and the brake pedal is pressed (Stop light SW on), if the stop light circuit is open, the current flowing from TERMINAL 7 of the light failure sensor to TERMINALS 1, 2 changes, so the light failure sensor detects the disconnection and the warning circuit of the light failure sensor is activated.

As a result, the current flows from TERMINAL 4 of the light failure sensor to TERMINAL 11 to GROUND and turns the rear lights warning light on. By pressing the brake pedal, the current flowing to TERMINAL 8 of the light failure sensor keeps the warning circuit on and holds the warning light on until the ignition SW is turned off.

### SERVICE HINTS

### S6 STOP LIGHT SW

2-1: Closed with the brake pedal depressed

### L4 LIGHT FAILURE SENSOR

1, 2, 7-GROUND : Approx. 12 volts with the stop light SW on

4, 8-GROUND : Approx. 12 volts with the ignition SW at ON position

11-GROUND: Always continuity

# [Q] : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C7	34	L4	36	R7	37
H17	36	R6	37	S6	35

### : RELAY BLOCKS

ode	See Page	Relay Blocks (Relay Block Location)	
180	-		
1	18	R/B No.1 (Instrument Panel Left)	

# : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
IB	20	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
20	22	Instrument Panel Wire and J/B No.3 (Instrument Panel Left Side)

# [T] : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	Acres de la constante de la co
IE1	42	Floor Wire and Instrument Panel Wire (Left Kick Panel)	
BV/1	50	Luggage Room Wire and Floor Wire (Luggage Compartment Left)	

# : GROUND POINTS

_			
Code	See Page	Ground Points Location	
BL	50	Under the Left Quarter Pillar	
ВО	50	Back Panel Center	

# : SPLICE POINTS

Code See Page Wire Harness with Splice Points				See Page	Wire Harness with Splice Points	
Code	de la de	Cowl Wire	B18	50	Luggage Room Wire	
15	44	COMITABLE	5.0	0.0	50 0	

[0]: Explains the system outline.

[P]: Indicates values or explains the function for reference during troubleshooting.

[Q]: Indicates the reference page showing the position on the vehicle of the parts in the system circuit.

Example: Part "L4" (Light Failure Sensor) is on page 36 of the manual.

\* The letter in the code is from the first letter of the part, and the number indicates its order in parts starting with that letter.

> Example: L Parts is 4th in order Light Failure Sensor

[R]: Indicates the reference page showing the position on the vehicle of Relay Block Connectors in the system circuit.

Example: Connector "1" is described on page 18 of this manual and is installed on the left side of the instrument panel.

[S]: Indicates the reference page showing the position on the vehicle of J/B and Wire Harness in the system circuit.

Example: Connector "3C" connects the Instrument Panel Wire and J/B No.3. It is described on page 22 of this manual, and is installed on the instrument panel left side.

[T]: Indicates the reference page describing the wiring harness and wiring harness connector (the female wiring harness is shown first, followed by the male wiring harness).

Example: Connector "IE1" connects the floor wire (female) and Instrument panel wire (male). It is described on page 42 of this manual, and is installed on the left side kick panel.

[U]: Indicates the reference page showing the position of the ground points on the vehicle.

Example: Ground point "BO" is described on page 50 of this manual and is installed on the back panel center.


[V]: Indicates the reference page showing the position of the splice points on the vehicle.

Example: Splice point "I5" is on the Cowl Wire Harness and is described on page 44 of this manual.

The ground points circuit diagram shows the connections from all major parts to the respective ground points. When troubleshooting a faulty ground point, checking the system circuits which use a common ground may help you identify the problem ground quickly. The relationship between ground points ( $\nabla^{EA}$ ,  $\nabla^{IE}$ ) and  $\nabla^{IC}$  shown below) can also be checked this way.

# I GROUND POINT

**B HOW TO USE THIS MANUAL** 




\* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the SYSTEM CIRCUITS SECTION.

The "Current Flow Chart" section, describes which parts each power source (fuses, fusible links, and circuit breakers) transmits current to. In the Power Source circuit diagram, the conditions when battery power is supplied to each system are explained. Since all System Circuit diagrams start from the power source, the power source system must be fully understood.


# J POWER SOURCE (Current Flow Chart)

The chart below shows the route by which current flows from the battery to each electrical source (Fusible Link, Circuit Breaker, Fuse, etc.) and other parts.




## Engine Room R/B (See Page 20)

	Fuse	System	Page
20A	STOP	ABS ABS and Traction Control Cruise Control Electronically Controlled Transmission and A/T Indicator Multiplex Communication System	
10A	DOME	Cigarette Lighter and Clock Combination Meter Headlight Interior Light	214 230 112 122
DOW/		Key Reminder and Seat Belt Warning Light Auto Turn Off	



\* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the SYSTEM CIRCUITS SECTION.


# K CONNECTOR LIST



[A]: Indicates connector to be connected to a part. (The numeral indicates the pin No.)


### [B]: Junction Connector

Indicates a connector which is connected to a short terminal.



Junction connector in this manual include a short terminal which is connected to a number of wire harnesses. Always perform inspection with the short terminal installed. (When installing the wire harnesses, the harnesses can be connected to any position within the short terminal grouping. Accordingly, in other vehicles, the same position in the short terminal may be connected to a wire harness from a different part.)

Wire harness sharing the same short terminal grouping have the same color.



In this manual, the type of splice connector shown in the illustration on the left is used at splice points.

Each wire harness is connected to the other positions within the short terminal group.

The location of the wiring harness within the group is not fixed, so the locations may be different on another vehicle.

Wiring harnesses from the same group share the same color.

[C]: Parts Code

The first letter of the code is taken from the first letter of part, and the numbers indicates its order in parts which start with the same letter.

[D]: Connector Color

Connectors not indicated are milky white in color.

# M PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number	
A 1	A/C Ambient Temp. Sensor	90980-11070	D 4	Diode (Door Courtesy Light)	90980-11608	
A 2	A/C Condenser Fan Motor	90980-11237	D 5	Diode (Key Off Operation)	90980-10962	
А3	A/C Condenser Fan Relay	90980-10940	D 6	Diode (Luggage Compartment Light)	90980-11608	
A 4	A/C Triple Pressure SW (A/C Dual and	00000 10010	D 7	Door Lock Control Relay	90980-10848	
	Single Pressure SW)	90980-10943	D 8	Door Courtesy Light LH		
[A]	A/T Oil Temp. Sensor [B]	909 <b>[C]</b> 413	D 9	Door Courtesy Light RH	90980-11148	
A 6	ABS Actuator	90980-11151	D10	Door Courtesy SW LH	200	
A 7	ABS Actuator	90980-11009	D11	Door Courtesy SW RH	90980-11097	
A 8	ABS Speed Sensor Front LH	90980-10941	D12	Door Courtesy SW Front LH		
A 9	ABS Speed Sensor Front RH	90980-11002	D13	Door Courtesy SW Front RH		
A10	Airbag Sensor Front LH	00000 44050	D14	Door Courtesy SW Rear LH	90980-11156	
A11	Airbag Sensor Front RH	90980-11856	D15	Door Courtesy SW Rear RH		
Ala		90980-11194	Die	Unlock SW LH		
		90980		TOH	90980-11170	

[A]: Part Code

[B]: Part Name

[C]: Part Number

Toyota Part Number are indicated.

Not all of the above part numbers of the connector are established for the supply. In case of ordering a connector or terminal with wire, please confirm in advance if there is supply for it using "Parts Catalog News" (published by Parts Engineering Administration Dept.).

# To Ignition SW IG Terminal Fuse [A] SW 1 Voltmeter Relay Solenoid

# **VOLTAGE CHECK**

(a) Establish conditions in which voltage is present at the check point.

### Example:


[A] - Ignition SW on

[B] - Ignition SW and SW 1 on

[C] - Ignition SW, SW 1 and Relay on (SW 2 off)


(b) Using a voltmeter, connect the negative lead to a good ground point or negative battery terminal, and the positive lead to the connector or component terminal.

This check can be done with a test light instead of a voltmeter.



### **CONTINUITY AND RESISTANCE CHECK**


- (a) Disconnect the battery terminal or wire so there is no voltage between the check points.
- (b) Contact the two leads of an ohmmeter to each of the check points.




If the circuit has diodes, reverse the two leads and check again.

When contacting the negative lead to the diode positive side and the positive lead to the negative side, there should be continuity.

When contacting the two leads in reverse, there should be no continuity.



(c) Use a volt/ohmmeter with high impedance (10  $k\Omega/V$  minimum) for troubleshooting of the electrical circuit.



## **FINDING A SHORT CIRCUIT**

- (a) Remove the blown fuse and disconnect all loads of the fuse.
- (b) Connect a test light in place of the fuse.
- (c) Establish conditions in which the test light comes on.

### Example:

[A] - Ignition SW on

[B] - Ignition SW and SW 1 on

[] - Ignition SW, SW 1 and Relay on (Connect the Relay) and SW 2 off (or Disconnect SW 2)

(d) Disconnect and reconnect the connectors while watching the test light.

The short lies between the connector where the test light stays lit and the connector where the light goes out.

(e) Find the exact location of the short by lightly shaking the problem wire along the body.


### CAUTION:

- (a) Do not open the cover or the case of the ECU unless absolutely necessary. (If the IC terminals are touched, the IC may be destroyed by static electricity.)
- (b) When replacing the internal mechanism (ECU part) of the digital meter, be careful that no part of your body or clothing comes in contact with the terminals of leads from the IC, etc. of the replacement part (spare part).

# DISCONNECTION OF MALE AND FEMALE CONNECTORS

To pull apart the connectors, pull on the connector itself, not the wire harness.

HINT: Check to see what kind of connector you are disconnecting before pulling apart.



# Reference: (mm)

# HOW TO REPLACE TERMINAL (with terminal retainer or secondary locking device)

1. PREPARE THE SPECIAL TOOL

HINT: To remove the terminal from the connector, please construct and use the special tool or like object shown on

2. DISCONNECT CONNECTOR

# Example: Up Tool (Case 1) Terminal Retainer

- 3. DISENGAGE THE SECONDARY LOCKING DEVICE OR TERMINAL RETAINER.
  - (a) Locking device must be disengaged before the terminal locking clip can be released and the terminal removed from the connector.
  - (b) Use a special tool or the terminal pick to unlock the secondary locking device or terminal retainer.

### NOTICE:


Do not remove the terminal retainer from connector body.




HINT: The needle insertion position varies according to the connector's shape (number of terminals etc.), so check the position before inserting it.

### "Case 1"

Raise the terminal retainer up to the temporary lock position.





[Retainer at Temporary Lock Position]




"Case 2"

Open the secondary locking device.







# Example: Terminal Retainer (Case 2) Press Down Press Down

[Female]

[Male]

# [B] For Waterproof Type Connector

HINT: Terminal retainer color is different according to connector body.

## Example:

Terminal Retainer: Connector Body

Black or White : Gray Black or White : Dark Grav Gray or White : Black

### "Case 1'


Type where terminal retainer is pulled up to the temporary lock position (Pull Type).

Insert the special tool into the terminal retainer access hole ( Mark) and pull the terminal retainer up to the temporary lock position.


HINT: The needle insertion position varies according to the connector's shape (Number of terminals etc.), so check the position before inserting it.

### "Case 2"


Type which cannot be pulled as far as Power Lock insert the tool straight into the access hole of terminal retainer as shown.



Push the terminal retainer down to the temporary lock position.



(c) Release the locking lug from terminal and pull the terminal out from rear.




4. INSTALL TERMINAL TO CONNECTOR

(a) Insert the terminal.

### JINIT

- 1. Make sure the terminal is positioned correctly.
- 2. Insert the terminal until the locking lug locks firmly.
- 3. Insert the terminal with terminal retainer in the temporary lock position.



- (b) Push the secondary locking device or terminal retainer in to the full lock position.
- 5. CONNECT CONNECTOR

# **ABBREVIATIONS**

The following abbreviations are used in this manual.

ABS = Anti-Lock Brake System

A/C = Air Conditioner

ACIS = Acoustic Control Induction System

A/T = Automatic Transmission

COMB. = Combination

DLC3 = Data Link Connector 3

ECT = Electronically Controlled Transmission

ECU = Electronic Control Unit

EFI = Electronic Fuel Injection

ESA = Electronic Spark Advance

ETCS-i = Electronic Throttle Control System-intelligent

EVAP = Evaporative Emission

IC = Integrated Circuit

J/B = Junction Block

LH = Left-Hand

LHD = Left-Hand Drive

MPX = Multiplex

M/T = Manual Transmission

O/D = Overdrive

R/B = Relay Block

RH = Right-Hand

RHD = Right-Hand Drive

SRS = Supplemental Restraint System

SW = Switch

TEMP. = Temperature

TRC = Traction Control

VSC = Vehicle Stability Control


VSV = Vacuum Switching Valve


w/ = With

w/o = Without


<sup>\*</sup> The titles given inside the components are the names of the terminals (terminal codes) and are not treated as being abbreviations.

# E GLOSSARY OF TERMS AND SYMBOLS







# [Engine Compartment] (LHD)




(RHD)




# [Instrument Panel] (LHD)




(RHD)



[Body]




# **F RELAY LOCATIONS**




F

(Inner Circuit : See Page 86)










(Inner Circuit : See Page 87)

: Passenger Side J/B Right Kick Panel (See Page 77)







# [Driver Side J/B Inner Circuit]




# [Passenger Side J/B Inner Circuit]






# **Position of Parts in Engine Compartment**



- A 1 A/C Ambient Temp. Sensor
- A 2 A/C Condenser Fan Motor
- A 3 A/C Magnetic Clutch
- A 4 A/C Triple Pressure SW (A/C Dual and Single Pressure SW)
- A 5 ABS and Traction Actuator
- A 6 ABS and Traction Actuator
- A 7 ABS Speed Sensor Front LH
- A 8 ABS Speed Sensor Front RH
- A 9 Accel Position Sensor
- A10 Airbag Sensor Front LH
- A 11 Airbag Sensor Front RH
- A12 Alternator
- A13 Alternator
- B 1 Back-Up Light SW
- B 2 Brake Fluid Level Warning SW
- C 1 Camshaft Position Sensor
- C 2 Camshaft Timing Oil Control Valve
- C 3 Check Connector
- C 4 Crankshaft Position Sensor

- E 1 ECT Solenoid
- E 2 Engine ECU (M/T) or Engine and ECT ECU (A/T)
- E 3 Engine ECU (M/T) or Engine and ECT ECU (A/T)
- E 4 Engine and ECT ECU
- E 5 Engine ECU (M/T) or Engine and ECT ECU (A/T)
- E 6 Engine ECU (M/T) or Engine and ECT ECU (A/T)
- E 8 Engine Oil Level Sensor
- E 9 Engine Oil Pressure SW
- F 1 Front Clearance Light LH
- F 2 Front Clearance Light RH
- F 3 Front Fog Light LH
- F 4 Front Fog Light RH
- F 5 Front Side Turn Signal Light LH
- F 6 Front Side Turn Signal Light RH
- F 7 Front Turn Signal Light LH
- F 8 Front Turn Signal Light RH
- F 9 Front Window Deicer
- F10 Front Wiper Motor

# **Position of Parts in Engine Compartment**



- H 1 Headlight Beam Level Control Actuator LH
- H 2 Headlight Beam Level Control Actuator RH
- H 3 Headlight Cleaner Control Relay
- H 4 Headlight Cleaner Motor
- H 5 Headlight LH (High) H 6 Headlight LH (Low)


- H 7 Headlight RH (High) H 8 Headlight RH (Low)
- H 9 Heated Oxygen Sensor (Bank 1 Sensor 1) H10 Heated Oxygen Sensor (Bank 2 Sensor 1)
- H11 Horn LH
- H12 Horn RH
- I Ignition Coil and Igniter No.1
  I 2 Ignition Coil and Igniter No.2
  I 3 Ignition Coil and Igniter No.3

- 4 Ignition Coil and Igniter No.4 5 Ignition Coil and Igniter No.5 6 Ignition Coil and Igniter No.6
- 7 Injector No.1
- 8 Injector No.2
- 9 Injector No.3 I 10 Injector No.4
- I 11 Injector No.5
- I 12 Injector No.6
- I 13 Intake Air Temp. Sensor
- J 1 Junction Connector
- J 2 Junction Connector
- J 3 Junction Connector J 4 Junction Connector

- K 1 Knock Sensor 1 K 2 Knock Sensor 2
- N 1 Neutral Start SW
- N 2 Noise Filter (Ignition)
- P 1 Power Steering Oil Pressure SW
- R 1 Radiator Fan Motor
- Speed Sensor (Combination Meter)
- S 2 Speed Sensor (Transmission Input)
- S 3 Speed Sensor (Transmission Output)
- S 4 Starter
- S 5 Starter
- T 1 Throttle Control Motor
- T 2 Throttle Position Sensor
- V 1 Vacuum Sensor
- V 2 VSV (ACIS)
- V 3 VSV (EVAP)
- W 1 Washer Motor W 2 Water Temp. Sensor
- W 3 Water Temp. SW

# **Position of Parts in Instrument Panel**


# [LHD]



- A14 A/C Control Assembly
- A15 A/C Control Assembly
- A16 A/C Room Temp. Sensor
- A17 A/C Solar Sensor
- A18 A/C Thermistor
- A19 A/T Shift Position Illumination
- A20 ABS and Traction ECU
- A21 ABS and Traction ECU
- A22 ABS and Traction ECU
- A23 ABS and Traction ECU
- A24 Air Inlet Control Servo Motor
- A25 Air Mix Control Servo Motor
- A26 Air Vent Mode Control Servo Motor
- A27 Airbag Squib (Front Passenger Airbag Assembly)
- A28 Airbag Squib (Steering Wheel Pad)
- A29 Antenna Amplifier
- A30 Ashtray Illumination
- B 3 Blower Motor
- B 4 Blower Motor Controller
- B 5 Blower Motor Controller
- B 6 Body ECU
- B 7 Body ECU

- C 5 Center Airbag Sensor Assembly
- C 6 Center Airbag Sensor Assembly
- C 7 Center Airbag Sensor Assembly
- C 8 Cigarette Lighter
- C 9 Cigarette Lighter Illumination
- C10 Combination Meter
- C11 Combination Meter
- C12 Combination SW
- C13 Combination SW
- C14 Combination SW
- D 1 Daytime Running Light Relay
- D 3 Diode (A/C)
- D 4 DLC3

# **Position of Parts in Instrument Panel**




- E10 ECT Pattern Select SW
- G 1 Glove Box Light
- H13 Headlight Beam Level Control SW
- H14 Headlight Cleaner SW
- I 14 Ignition Key Cylinder Light
- I 15 Ignition SW
- J 5 Junction Connector
- J 6 Junction Connector
- J 7 Junction Connector
- J 8 Junction Connector
- J 9 Junction Connector
- J 11 Junction Connector
- K 3 Kick Down SW
- M 1 Multi-Display
- P 2 Parking Brake SW

- R 2 Radio and Player
- R 3 Radio and Player
- R 4 Radio and Player
- R 5 Radio and Player
- R 6 Radio and Player
- R 7 Rear Fog Light SW
- R 8 Remote Control Receiver
- R 9 Rheostat
- S 6 Seat Heater SW (Driver's Seat)
- S 7 Seat Heater SW (Passenger's Seat)
- S 8 Shift Lock Control ECU
- S 9 Stereo Component Amplifier
- S10 Stereo Component Amplifier
- S 11 Stop Light SW
- T 3 Telephone Microphone
- T 6 Traction Cut SW (A/T), Traction Cut SW and Snow SW (M/T)
- T 7 Transponder Key Amplifier
- U 1 Unlock Warning SW and Key Interlock Solenoid

# **Position of Parts in Body**

# [LHD]




- A32 ABS Speed Sensor Rear LH A33 ABS Speed Sensor Rear RH
- B 8 Buckle SW LH
- B 11 Buckle SW RH and Seat Belt Warning Occupant Detection Sensor
- D 5 Door Courtesy Light Front LH
- D 6 Door Courtesy Light Front RH

- D 7 Door Courtesy SW Front LH
  D 8 Door Courtesy SW Front RH
  D 9 Door Courtesy SW Rear LH
  D10 Door Courtesy SW Rear RH
- D11 Door Lock Motor, Door Key Lock and Unlock SW and Door Lock Detection SW Front LH
- D14 Door Lock Motor and Door Lock Detection SW Front RH
- D15 Door Lock Motor and Door Lock Detection SW Rear LH
- D16 Door Lock Motor and Door Lock Detection SW Rear RH
- F 11 Front Door Speaker LH
- F12 Front Door Speaker RH
- F13 Front Door Tweeter Speaker LH
- F14 Front Door Tweeter Speaker RH
- F15 Fuel Pump and Sender
- F16 Fuel Sender (Sub)

- H15 Heated Oxygen Sensor (Bank 1 Sensor 2)
- H16 High Mounted Stop Light
- I 16 Interior Light
- J 12 Junction Connector
- J 13 Junction Connector
- J 14 Junction Connector
- J 15 Junction Connector
- J 16 Junction Connector
- J 17 Junction Connector
- L 1 License Plate Light LH
- L 2 License Plate Light RH
- L 3 Light Failure Sensor
- L 4 Luggage Compartment Door Courtesy SW and
- L 6 Luggage Compartment Door Opener Relay
- L 7 Luggage Compartment Light
- M 2 Moon Roof Control ECU
- M 3 Moon Roof Control SW and Personal Light

# **Position of Parts in Body**



- N 3 Navigation ECU
- N 4 Navigation ECU N 5 Navigation ECU
- N 6 Navigation ECU
  N 7 Noise Filter (Rear Window Defogger)
  N 8 Noise Filter (Stop Light)


- P 3 Personal Light P 5 Power Window Control SW Front RH
- P 6 Power Window Control SW Rear LH
- P 7 Power Window Control SW Rear RH
- P 8 Power Window Master SW
- P 9 Power Window Motor Front LH
- P10 Power Window Motor Front RH
- P11 Power Window Motor Rear LH
- P12 Power Window Motor Rear RH
- P13 Pretensioner LH
- P14 Pretensioner RH
- R10 Rear Combination Light LH
- R11 Rear Combination Light RH
- R12 Rear Fog Light LH R13 Rear Fog Light RH
- R14 Rear Speaker LH
- R15 Rear Speaker RH
- R16 Remote Control Mirror LH
- R17 Remote Control Mirror RH
- R18 Remote Control Mirror SW

- S12 Seat Heater (Driver's Seat)
- S13 Seat Heater (Passenger's Seat)
- S14 Side Airbag Sensor LH
- S15 Side Airbag Sensor RH
- S16 Side Airbag Squib LH
- S17 Side Airbag Squib RH
- T 8 Telephone Transceiver and Speaker Relay
- T 9 Telephone Transceiver and Speaker Relay
- V 4 Vanity Light LH V 5 Vanity Light RH
- W 4 Wireless Door Lock ECU
- W 5 Woofer Speaker LH
- W 6 Woofer Speaker RH

# **G ELECTRICAL WIRING ROUTING**

# **Position of Parts in Seat**

# [LHD]



\*1 : w/ Power Seat

B 8 Buckle SW LH

P15 Power Seat Control SW

P16 Power Seat Motor (Driver's Seat Front Vertical Control)


P17 Power Seat Motor (Driver's Seat Rear Vertical Control)

P18 Power Seat Motor (Driver's Seat Reclining Control)


P19 Power Seat Motor (Driver's Seat Slide Control)

S12 Seat Heater (Driver's Seat)

# **G ELECTRICAL WIRING ROUTING**





# **Connector Joining Wire Harness and Wire Harness**




Code	Joining Wire Harness and Wire Harness (Connector Location)			
EA1	Engine Wire and Engine Room Main Wire (Inside of the ECU Box)			
EA2				


# : Location of Splice Points










: Location of Ground Points





# **Connector Joining Wire Harness and Wire Harness**
















Code	Joining Wire Harness and Wire Harness (Connector Location)		
IA1			
IA2	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)		
IA3			
IB1	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)		
IB2			
IC1	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)		
ID1	Instrument Panel No.2 Wire and Instrument Panel Wire (Left Side of the Instrument Panel)		







# ○ : Location of Splice Points




# **Connector Joining Wire Harness and Wire Harness**




Code	Joining Wire Harness and Wire Harness (Connector Location)			
IE1	Floor No.3 Wire and Floor No.2 Wire (Near the Steering Column)			
IF1	Instrument Benefit Mineral A (O.O. I. Min. of A (O.I. A)			
IF2	Instrument Panel Wire and A/C Sub Wire (Left Side of the Blower Unit)			
IG1	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)			
IH1				
IH2	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)			
IH3				
li1	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)			



# : Location of Splice Points




# **Connector Joining Wire Harness and Wire Harness**




Code	Joining Wire Harness and Wire Harness (Connector Location)			
BA1	Rear Door No.2 Wire and Floor No.2 Wire (Left Center Pillar)			
BB1	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)			
BC1	Floor No.2 Wire and Floor Wire (Under the Right Rear Cushion)			
BD1	Floor No.2 Wire and Luggage Room Wire (Right Side of the Luggage Door)			
BD2	- Floor No.2 Wire and Euggage Hoom Wire (Hight Side of the Euggage Door)			

☐ : Location of Connector Joining Wire Harness and Wire Harness


[LHD]



# : Location of Splice Points



# **Connector Joining Wire Harness and Wire Harness**



Code Joining Wire Harness an		Joining Wire Harness and Wire Harness (Connector Location)	
	BE1	Floor No.2 Wire and Front Seat LH Wire (Under the Driver's Seat)	


# IS 200 ELECTRICAL WIRING DIAGRAM SYSTEM CIRCUITS


	Page
ABS AND TRACTION CONTROL	366
AUTOMATIC AIR CONDITIONER (LHD)	
AUTOMATIC AIR CONDITIONER (RHD)	
AUTOMATIC LIGHT CONTROL (RHD)	274
BACK-UP LIGHT	
CELLULAR MOBILE TELEPHONE	
CHARGING	
CIGARETTE LIGHTER	378
CLOCK	380
COMBINATION METER	442
CRUISE CONTROL	
DOOR LOCK CONTROL (LHD)	
DOOR LOCK CONTROL (RHD)	
DOUBLE LOCKING (RHD)	312
ECT AND A/T INDICATOR	352
ENGINE CONTROL (LHD)	
ENGINE CONTROL (RHD)	170
ENGINE IMMOBILISER SYSTEM	182
FRONT FOG LIGHT (LHD)	198
FRONT FOG LIGHT (RHD)	200
FRONT WINDOW DEICER	408
HEADLIGHT (LHD w/ DAYTIME RUNNING LIGHT)	186
HEADLIGHT (LHD w/o DAYTIME RUNNING LIGHT)	190
HEADLIGHT (RHD)	194
HEADLIGHT BEAM LEVEL CONTROL	388
HEADLIGHT CLEANER	384
HORN	382
IGNITION	150
ILLUMINATION (LHD)	214
ILLUMINATION (RHD)	218
INTERIOR LIGHT (LHD)	262
INTERIOR LIGHT (RHD)	268
LEXUS NAVIGATION SYSTEM (LHD)	414
LEXUS NAVIGATION SYSTEM (RHD)	418
LIGHT REMINDER (LHD)	338
LIGHT REMINDER (RHD)	342
MOON ROOF	404
MULTIPLEX COMMUNICATION SYSTEM (COMMUNICATION BUS) (LHD)	230
MULTIPLEX COMMUNICATION SYSTEM (COMMUNICATION BUS) (RHD)	246
MULTIPLEX COMMUNICATION SYSTEM (LHD)	232
MULTIPLEX COMMUNICATION SYSTEM (RHD)	248
POWER SOURCE (LUD)	350
POWER SOURCE (LHD)	140
POWER SOURCE (RHD)	144
POWER WINDOW (BHD)	318
POWER WINDOW (RHD)	324
RADIATOR FAN AND CONDENSER FAN	448

	Page
RADIO AND PLAYER (LHD 6 SPEAKER)	426
RADIO AND PLAYER (LHD 8 SPEAKER)	434
RADIO AND PLAYER (RHD 6 SPEAKER)	430
RADIO AND PLAYER (RHD 8 SPEAKER)	438
REAR FOG LIGHT (LHD)	202
REAR FOG LIGHT (RHD)	206
REAR WINDOW DEFOGGER AND MIRROR HEATER	410
REMOTE CONTROL MIRROR (LHD)	346
REMOTE CONTROL MIRROR (RHD)	348
SEAT BELT WARNING (LHD)	330
SEAT BELT WARNING (RHD)	334
SEAT HEATER	390
SHIFT LOCK	400
SRS	373
STARTING	148
STOP LIGHT	228
TAILLIGHT	210
THEFT DETERRENT (RHD)	306
TURN SIGNAL AND HAZARD WARNING LIGHT (LHD)	222
TURN SIGNAL AND HAZARD WARNING LIGHT (RHD)	224
WIPER AND WASHER (LHD)	392
WIPER AND WASHER (RHD)	396
WIRELESS DOOR LOCK CONTROL (LHD)	290
WIRELESS DOOR LOCK CONTROL (RHD)	298

POWER SOURCE (LHD)

\* 1 : W/ DAYTIME RUNNING LIGHT
\* 2 : W/O DAYTIME RUNNING LIGHT





# **POWER SOURCE (LHD)**

### — SERVICE HINTS —

## **HEAD LP RELAY**

2-1 : Closed with light control SW at **HEAD** position or dimmer SW at **FLASH** position

### TAIL RELAY

5-3 : Closed with light control SW at TAIL or HEAD position

### **115 IGNITION SW**

2-3 : Closed with ignition key at ACC or ON position

2-4 : Closed with ignition key at **ON** or **ST** position

7-6 : Closed with ignition key at **ON** or **ST** position

7-8 : Closed with ignition key at ST position

# : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
l15	99 (LHD)				

# : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)	
1	80 (LHD)	ine Room No.1 R/B (Engine Compartment Right)	
2	80 (LHD)	ine Room No.2 R/B (Engine Compartment Right)	
3	94 (LHD)	ngine Room No.3 R/B (Engine Compartment Right)	

# : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)			
1D	82 (LHD)	Joseph March Daniel Miller and Debay Olds 1/D (Left 1/C) L.D			
1H	- 02 (LND)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)			
10	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)			
2C	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)			
2D	84 (LHD)	notrument Panal Wire and December Cide UD (Diskt Kiel, David)			
2H	84 (LHD) Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)				
2M	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)			

# **POWER SOURCE (RHD)**

SERVICE HINTS -

### **HEAD LP RELAY**

2-1 : Closed with light control SW at **HEAD** position or dimmer SW at **FLASH** position

### **TAIL RELAY**

5-3 : Closed with light control SW at TAIL or HEAD position

## 115 IGNITION SW

2-3 : Closed with ignition key at **ACC** or **ON** position 2-4 : Closed with ignition key at **ON** or **ST** position 7-6 : Closed with ignition key at **ON** or **ST** position

7-8: Closed with ignition key at ST position

# O : PARTS LOCATION


Code	See Page	Code	See Page	Code	See Page
l15	107 (RHD)			" ' "	

# : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)		
1	81 (RHD)	Ingine Room No.1 R/B (Engine Compartment Left)		
2	81 (RHD)	Engine Room No.2 R/B (Engine Compartment Left)		

# : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

L	Code	See Page Junction Block and Wire Harness (Connector Location)		
	1C	88 (RHD) Engine Room Main Wire and Driver Side J/B (Right Kick Panel)		
	1D	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)	
	2D	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)	
	2K	90 (RHD)	Engine Deem Main Wire and December Cide UD (Left Viel December	
	20	90 (RID)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)	



### SERVICE HINTS -

# S4 (A), S5 (B) STARTER

Points closed with the neutral start SW on and the ignition SW at **ST** position (A/T) Points closed with the ignition SW at **ST** position (M/T)

## N1 NEUTRAL START SW

9-6 : Closed with the A/T shift lever in P or N position

# O : PARTS LOCATION

Code	See Page	Co	ode	See Page	Cc	ode	See Page
115	99 (LHD)	N	11	97 (LHD)	S4	Α	105 (RHD)
	107 (RHD)		•	105 (RHD)	S5	В	97 (LHD)
J5	107 (RHD)	S4	Α	97 (LHD)	33		105 (RHD)

# : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
'	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)

# : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1D	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
L '5	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1K	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2D	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
20	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2K 90 (RHD) Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)		Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2M	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)


# : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

_			
-1	Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
_			
		112 (LHD)	
	EA1		Engine Wire and Engine Room Main Wire (Inside of the ECU Box)
- 1		122 (RHD)	This was and Engine Hoom wait with Children of the EOO Box)

# : GROUND POINTS

Code	See Page	Ground Points Location	
EC	122 (RHD)	Left Fender Apron	
ID	114 (LHD)	Cowl Side Panel LH	
טו	124 (RHD)	- Cowi Side Panei Ln	





# **IGNITION**

### - SERVICE HINTS

115 IGNITION SW

7-6 : Closed with the ignition SW at **ON** or **ST** position

# : PARTS LOCATION

С	ode	See Page	Code	See Page	Code	See Page
	E6	96 (LHD)	13	97 (LHD)	10	97 (LHD)
	LO	104 (RHD)	l is	105 (RHD)	- 16	105 (RHD)
	11	97 (LHD)	14	97 (LHD)	145	99 (LHD)
	11	105 (RHD)	14	105 (RHD)	115	107 (RHD)
	12	97 (LHD)	15	97 (LHD)	N2	97 (LHD)
	12	105 (RHD)	2	105 (RHD)	INZ	105 (RHD)

# : RELAY BLOCKS

	Code	See Page	Relay Blocks (Relay Block Location)
	1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
ı	•	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)

# : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1D	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1K	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2D	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
20	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2K	30 (I II ID)	Linguile noom ivially value and rassenger side 5/B (Leit Nick Pariet)
2M	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)

# : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


	Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
	EA1	112 (LHD)	Engine Wire and Engine Room Main Wire (Inside of the ECU Box)
ı	LAI	122 (RHD)	Linguie valle and Engine Room Main valle (inside of the ECO Box)


# : GROUND POINTS

Code	See Page	Ground Points Location
EB	112 (LHD)	Rear Side of Cylinder Head
6	122 (RHD)	- Near Side of Cylinder Head

# : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	112 (LHD)		E2	122 (RHD)	
	122 (RHD)	Engine Wire	E3	112 (LHD)	Engine Wire
E2	112 (LHD)	7	=3	122 (RHD)	7





# **CHARGING**

### SERVICE HINTS

## A12 (A), A13 (B) ALTERNATOR

(A) 1-GROUND: 13.9-15.1 volts with engine running at 2000 rpm and 25°C
13.5-14.3 volts with engine running at 5000 rpm and 115°C
(B) 3-GROUND: 0-4 volts with ignition SW at ON position and engine not running

# : PARTS LOCATION

Code		See Page	Co	de	See Page	Co	de	See Page
A12	Α	96 (LHD)	B6	А	98 (LHD)	E3	В	104 (RHD)
		104 (RHD)	- 50		106 (RHD)	E6	E	96 (LHD)
A13	В	96 (LHD)		10	98 (LHD)			104 (RHD)
/110		104 (RHD)		10	106 (RHD)	J2	Α	97 (LHD)
A14	Α	98 (LHD)	D	2	106 (RHD)			105 (RHD)
		106 (RHD)	E2	٨	96 (LHD)	10		97 (LHD)
	В	98 (LHD)		LA	104 (RHD)	J3	В	105 (RHD)
		106 (RHD)	E3	В	96 (LHD)	Т	5	107 (RHD)

# : RELAY BLOCKS

	Code	See Page	Relay Blocks (Relay Block Location)
	1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
L	·	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)

# : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1E	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
L ''	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1K	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2H	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)

# : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
EA1	112 (LHD)	Engine Wire and Engine Room Main Wire (Incidental to EQUID)	
	122 (RHD)	Engine Wire and Engine Room Main Wire (Inside of the ECU Box)	
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)	
	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)	


# : GROUND POINTS

Code	See Page	Ground Points Location
IH	114 (LHD)	Front Floor Panel Center LH
	124 (RHD)	Front Floor Panel Center RH


**ENGINE CONTROL (LHD)** 









ENGINE CONTROL (LHD)




160



\* 1 : SHIELDED





### **ENGINE CONTROL (LHD)**

#### SYSTEM OUTLINE

The engine control system utilizes a microcomputer and maintains overall control of the engine, transmission etc. An outline of the engine control is given here.

#### 1. INPUT SIGNALS

(1) Engine coolant temp. signal circuit

The water temp. sensor detects the engine coolant temp. and has a built-in thermister with a resistance, which varies according to the engine coolant temp. The engine coolant temp. which is input into TERMINAL THW of the engine ECU (M/T) or engine and ECT ECU (A/T) as a control signal.

(2) Intake air temp. signal circuit

The intake air temp. sensor is installed in the air flow meter and detects the intake air temp. which is input as a control signal to TERMINAL THA of the engine ECU (M/T) or engine and ECT ECU (A/T).

(3) Oxygen density signal circuit

The oxygen density in the exhaust emission is detected by the heated oxygen sensors and input as a control signal to TERMINALS OX1A, OX2A and OX1B of the engine ECU (M/T) or engine and ECT ECU (A/T).

(4) RPM signal circuit

Camshaft position is detected by the camshaft position sensor and its signal is input to TERMINAL G2 of the engine ECU (M/T) or engine and ECT ECU (A/T) as a control signal.

Also, engine RPM is detected by the crankshaft position sensor and is input as a control signal to TERMINAL NE+.

(5) Throttle position signal circuit

The throttle position sensor detects the throttle valve opening angle as a control signal, which is input into TERMINAL VTA of the engine ECU (M/T) or engine and ECT ECU (A/T).

(6) Vehicle speed circuit

The speed sensor (Combination meter) detects the vehicle speed and inputs a control signal to TERMINAL SPD of the engine ECU (M/T).

(7) Battery signal circuit

Voltage is constantly applied to TERMINAL BATT of the engine ECU (M/T) or engine and ECT ECU (A/T). With the ignition SW turned on, the voltage for engine ECU (M/T) or engine and ECT ECU (A/T) start-up power supply is applied to TERMINALS B, B2 of the engine ECU (M/T) or engine and ECT ECU (A/T) via the EFI relay.

The current flowing through the IGN fuse flows to TERMINAL IGSW of the engine ECU (M/T) or engine and ECT ECU (A/T).

Voltage is constantly applied to TERMINAL BM of the engine ECU (M/T) or engine and ECT ECU (A/T).

(8) Intake air vacuum signal circuit

Intake air vacuum is detected by the vacuum sensor and the signal is input to TERMINAL PIM of the engine ECU (M/T) or engine and ECT ECU (A/T) as a control signal.

(9) Stop light SW signal circuit

The stop light SW is used to detect whether the vehicle is braking or not and the signal is input into TERMINAL STP of the engine ECU (M/T) or engine and ECT ECU (A/T) as a control signal.

(10) Starter signal circuit

To confirm whether the engine is cranking, the voltage is applied to the starter motor during cranking is detected and the signal is input into TERMINAL STA of the engine ECU (M/T) or engine and ECT ECU (A/T) as a control signal.

(11) Engine knock signal circuit

Engine knocking is detected by knock sensors and the signal is input into TERMINALS KNK1 and KNK2 as a control signal.

#### 2. CONTROL SYSTEM

\* EFI system

The EFI system monitors the engine condition through the signals input from each sensor (Input signals from (1) to (11) etc.) to the engine ECU (M/T) or engine and ECT ECU (A/T). And the control signal is output to TERMINALS #10, #20, #30, #40, #50 and #60 of the engine ECU (M/T) or engine and ECT ECU (A/T) to operate the injector (Inject the fuel). The EFI system controls the fuel injection operation by the engine ECU (M/T) or engine and ECT ECU (A/T) in response to the driving conditions.

\* ESA system

The ESA system monitors the engine condition through the signals input to the engine ECU (M/T) or engine and ECT ECU (A/T) from each sensor (Input signals from (1), (2), (4), to (11) etc.). The best ignition timing is decided according to this data and the memorized data in the engine ECU (M/T) or engine and ECT ECU (A/T) and the control signal is output to TERMINALS IGT, IGT2, IGT3, IGT4, IGT5 and IGT6. This signal controls the igniter to provide the best ignition timing for the driving conditions.

\* Heated oxygen sensor heater control system

The heated oxygen sensor heater control system turns the heater on when the intake air volume is low (Temp. of exhaust emissions is low), and warms up the oxygen sensors to improve detection performance of the sensors. The engine ECU (M/T) or engine and ECT ECU (A/T) evaluates the signals from each sensor (Input signals from (1), (2), (4), (7), to (9) etc.), and outputs current to TERMINALS HT1A, HT2A and HT1B to control the heater.

\* ACIS

ACIS includes a valve in the bulkhead separating the surge tank into two parts. This valve is opened and closed in accordance with the driving conditions to control the intake manifold length in two stages for increased engine output in all ranges from low to high speeds.

\* ETCS-i

The ETCS-i controls the engine output at its optimal level corresponding to the opening of the accel. pedal under all driving conditions.

\* MPX

The MPX communicates with the combination meter, A/C control assembly, as well as body ECU of the multiplex communication system

#### 3. DIAGNOSIS SYSTEM

With the diagnosis system, when there is a malfunction in the engine ECU (M/T) or engine and ECT ECU (A/T) signal system, the malfunctioning system is recorded in the memory. The malfunctioning system can be found by reading the code displayed by the check engine warning light.

#### 4. FAIL-SAFE SYSTEM

When a malfunction has occurred in any system, if there is a possibility of engine trouble being caused by continued control based on the signals from that system, the fail-safe system either controls the system by using data (Standard values) recorded in the engine ECU (M/T) or engine and ECT ECU (A/T) memory or else stops the engine.

### SERVICE HINTS

#### **EFI RELAY**

5-3 : Closed with ignition SW at ON or ST position

#### **E8 ENGINE OIL LEVEL SENSOR**

1-2 : Closed with float up and engine oil temp. at below approx. **50**°C Open with float down and engine oil temp. at above approx. **60**°C

#### **E9 ENGINE OIL PRESSURE SW**

1-GROUND: With oil pressure below approx. 0.2 kgf/cm<sup>2</sup> (2.8 psi, 20 kpa)

#### W2 WATER TEMP. SENSOR

1-2 : Approx. **15.0** kΩ (**-20**°C) Approx. **2.45** kΩ (**20**°C) Approx. **0.32** kΩ (**80**°C) Approx. **0.14** kΩ (**110**°C)

### E2 (A), E3 (B), E5 (D), E6 (E) ENGINE ECU (M/T) OR ENGINE AND ECT ECU (A/T)

BATT-GROUND : Always approx. 12 volts BM-GROUND : Always approx. 12 volts

IGSW-GROUND : Approx. 12 volts with ignition SW at **ON** or **ST** position B, B2-GROUND : Approx. 12 volts with ignition SW at **ON** or **ST** position

VC-GROUND: 4.5-5.5 volts with ignition SW on

VTA2-GROUND : 2.0-2.9 volts with ignition SW on and throttle valve fully closed

4.6-5.0 volts with ignition SW on and throttle valve fully opened

VTA-GROUND: **0.4-1.0** volts with ignition SW on and throttle valve fully closed **3.2-4.8** volts with ignition SW on and throttle valve fully opened

VPA-GROUND: 0.25-0.9 volts with ignition SW at on and accelerator fully closed

3.2-4.8 volts with ignition SW at on and accelerator fully opened

VPA2-GROUND : 1.8-2.7 volts with ignition SW at on and accelerator fully closed

4.7-5.0 volts with ignition SW at on and accelerator fully opened

THA-GROUND: **0.5-3.4** volts with idling, intake air temp. **20**°C THW-GROUND: **0.2-1.0** volts with idling, coolant temp. **80**°C

STA-GROUND: 6.0 volts or more with cranking

TC-GROUND : 9.0-14.0 volts with ignition SW on

W-GROUND : 9.0-14.0 volts with idling

0-3.0 volts with ignition SW on

ACMG-GROUND: 0-1.5 volts with A/C SW on (at idling)

7.5-14.0 volts with A/C SW off and throttle valve fully open

#10, #20, #30, #40, #50, #60-GROUND: 9.0-14.0 volts with ignition SW on pulse generation with idling

### 17, 18, 19, 110, 111, 112 INJECTOR NO.1, NO.2, NO.3, NO.4, NO.5, NO.6

1–2 : **13.4–14.2**  $\Omega$ 

### : PARTS LOCATION

Co	de	See Page	Code	See Page	Code	See Page
Α	<b>.</b> 9	96 (LHD)	H9	97 (LHD)	J3 B	97 (LHD)
A14	Α	98 (LHD)	H10	97 (LHD)	J4	97 (LHD)
A15	В	98 (LHD)	H15	100 (LHD)	J9	99 (LHD)
A	22	98 (LHD)	11	97 (LHD)	J11	99 (LHD)
B6	Α	98 (LHD)	12	97 (LHD)	J17	100 (LHD)
C	1	96 (LHD)	13	97 (LHD)	K1	97 (LHD)
C	2	96 (LHD)	14	97 (LHD)	K2	97 (LHD)
	:3	96 (LHD)	15	97 (LHD)	N1	97 (LHD)
C	<b>;</b> 4	96 (LHD)	16	97 (LHD)	P1	97 (LHD)
C10	Α	98 (LHD)	17	97 (LHD)	S11	99 (LHD)
C11	В	98 (LHD)	18	97 (LHD)	· T1	97 (LHD)
	14	98 (LHD)	19	97 (LHD)	T2	97 (LHD)
E2	Α	96 (LHD)	l10	97 (LHD)	T7	99 (LHD)
E3	В	96 (LHD)	l11	97 (LHD)	U1	99 (LHD)
E5	۵	96 (LHD)	l12	97 (LHD)	V1	97 (LHD)
E6	E	96 (LHD)	113	97 (LHD)	V2	97 (LHD)
E	8	96 (LHD)	l15	99 (LHD)	V3	97 (LHD)
E	9	96 (LHD)	J1	97 (LHD)	W2	97 (LHD)
F	15	100 (LHD)	J2 A	97 (LHD)		

### : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
2	80 (LHD)	Engine Room No.2 R/B (Engine Compartment Right)

#### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)			
1D	82 (LHD)	Instrument Panal Wire and Driver Side I/D (Let Viel Panal)			
1E	- 02 (LND)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)			
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)			
1H	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)			
11	82 (LHD)	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)			
1K	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)			
2A	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)			
2B	) of (E110)	Lingine Adom Main Wire and Passenger Side J/B (Right Nick Parier)			
2D					
2E					
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)			
2H					
21					
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)			
2M	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)			

#### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)		
EA1	112 (LHD)	Engine Wire and Engine Room Main Wire (Inside of the ECU Box)		
IA2	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)		
IA3	114 (2116)	Institution of a life white and Engine Hoom Main White (Near the Driver Side 3/b)		
IB1	- 114 (LHD)	Instrument Panel Wire and Floor No 2 Wire (Near the Driver Side 1/P)		
IB2	114 (6110)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)		

# **ENGINE CONTROL (LHD)**

## : GROUND POINTS


Code	See Page	Ground Points Location	
EA	112 (LHD)	Front Side of Cylinder Head	
EB	112 (LHD)	Rear Side of Cylinder Head	
EC	112 (LHD)	Left Fender Apron	
ID	114 (LHD)	Cowl Side Panel LH	
IH	114 (LHD)	Front Floor Panel Center LH	
BK	118 (LHD)	Left Quarter Panel LH	·
BL	118 (LHD)	Front Floor Panel RH	




## : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E3			E7		
E4	112 (LHD)	Engine Wire	E8	112 (LHD)	Engine Wire
E5	112 (LND)	Engine wife	E9		
E6		11	E10	112 (LHD)	Engine Room Main Wire

## **ENGINE IMMOBILISER SYSTEM**





## **ENGINE IMMOBILISER SYSTEM**

### SERVICE HINTS —

**EFI RELAY** 

5-3 : Closed with the ignition SW at ON position

U1 UNLOCK WARNING SW

1-2: Closed with ignition key in cylinder

## O : PARTS LOCATION

Co	ode	See Page	Co	ode	See Page	Code	See Page
В6	A	98 (LHD)		08	108 (RHD)	10	99 (LHD)
	_ ^	106 (RHD)		09	100 (LHD)	J9	107 (RHD)
B7	В	98 (LHD)		9	108 (RHD)	J11	107 (RHD)
		106 (RHD)		10	100 (LHD)	110	100 (LHD)
C10	Α	98 (LHD)		10	108 (RHD)	J13	108 (RHD)
		106 (RHD)	E2	Α	96 (LHD)	Т7	99 (LHD)
C11	В	98 (LHD)		В	104 (RHD)		107 (RHD)
		106 (RHD)	E3		96 (LHD)	U1	99 (LHD)
	7	100 (LHD)			104 (RHD)		107 (RHD)
	•	108 (RHD)	J	11	105 (RHD)		
	8	100 (LHD)	J	15	107 (RHD)		

### : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
<u> </u>	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)
9	80 (LHD)	Engine Room No.2 R/B (Engine Compartment Right)
	81 (RHD)	Engine Room No.2 R/B (Engine Compartment Left)


### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
21	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
<u>4-</u> 1	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2M	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2N	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
1/1/2	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
IA3	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
IB1	124 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)
IH3	116 (LHD)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
BC1	118 (LHD)	Floor No 2 Wire and Floor Wire (Under the Bight Barry Continue)
	128 (RHD)	Floor No.2 Wire and Floor Wire (Under the Right Rear Cushion)

Code	See Page	Ground Points Location	
EC	122 (RHD)	Left Fender Apron	*****
ID	114 (LHD)	Coul Side Denel III	
טו	124 (RHD)	Cowl Side Panel LH	
IH	114 (LHD)	Front Floor Panel Center LH	
ш	124 (RHD)	Front Floor Panel Center RH	
BJ	128 (RHD)	Front Floor Panel LH	
BL	118 (LHD)	Front Floor Panel RH	





## **HEADLIGHT (w/ DAYTIME RUNNING LIGHT)**

#### SYSTEM OUTLINE

Current is constantly applied from the battery as follows:

ALT fuse to tail relay (Coil side) to TERMINAL 3 of the daytime running light relay. MAIN fuse to HEAD LP relay (Coil side) to TERMINAL 5 of the daytime running light relay. ECU-B2 fuse to TERMINAL 12 of the daytime running light relay. When the ignition SW is turned to ON, the current flows from ECU-IG fuse to TERMINAL 1 of the daytime running light relay.

#### 1. DAYTIME RUNNING LIGHT OPERATION

When the engine is started, a signal from the alternator is input to TERMINAL 5 of the daytime running light relay. This activates the daytime running light relay, allowing the current to flow as follows, and light up the related lights:

Tail relay (Point side) to TAIL fuse, PANEL fuse to taillight, front clearance light, license plate light, illumination. As the same time, the current also flows from HEAD LP relay (Point side) to H-LP L LWR fuse, H-LP R LWR fuse to headlight LH, RH (Low), and light up the headlights.

#### 2. TAILLIGHT OPERATION

When the light control SW is turned to TAIL position, a signal is input to TERMINAL 2 of the daytime running light relay, and the current flows as follows, and turns the tail relay ON:

ALT fuse to tail relay (Coil side) to TERMINAL 3 of the daytime running light relay to TERMINAL 2 to TERMINAL 14 of the light control SW to GROUND. At this time, the current also flows from the tail relay (Point side) to TAIL fuse, PANEL fuse to taillight, front clearance light, license plate light, illumination, and light up the related lights.

#### 3. HEADLIGHT OPERATION

\* When the light control SW is turned to HEAD position

The signal input to TERMINAL 5 of the daytime running light relay allows the current to flow as follows, and turns the HEAD LP relay ON:

MAIN fuse to HEAD LP relay (Coil side) to TERMINAL 5 of the daytime running light relay to TERMINAL 4 to TERMINAL 13 of the light control SW to GROUND. At the same time, the current flows from HEAD LP relay (Point side) to H-LP L LWR fuse, H-LP R LWR fuse to head light LH, RH (Low), and light up the lights.

\* When the Dimmer SW is turned to HIGH position

The current flows as follows, and turns the DIMMER relay ON:

DRL fuse to DIMMER relay (Coil side) to TERMINAL 14 of the daytime running light relay to TERMINAL 13 to TERMINAL 7 of the comb. SW to TERMINAL16 to GROUND. At the same time, the current flows from DIMMER relay (Point side) to HEAD L UPR fuse, HEAD R UPR fuse to headlight LH, RH (High), and light up the lights.

\* When the Dimmer SW is turned to FLASH position

The current flows as follows, and turns the HEAD LP relay ON:

MAIN fuse to HEAD LP relay (Coil side) to TERMINAL 5 of the daytime running light relay to TERMINAL 6 to TERMINAL 8 of the comb. SW to TERMINAL 16 to GROUND. At the same time, the current flows as follows, and turns the DIMMER relay ON:

DRL fuse to DIMMER relay (Coil side) to TERMINAL 14 of the daytime running light relay to TERMINAL 6 to TERMINAL 8 of the comb. SW to TERMINAL 16 to GROUND. This lights up the headlight LH, RH (High) and headlight LH, RH (Low), as when the dimmer SW is turned to HIGH position.

#### SERVICE HINTS

#### **HEAD LP RELAY**

1-2: Closed with light control SW at **HEAD** position or dimmer SW at **FLASH** position

#### **DIMMER RELAY**

1-2 : Closed with daytime running light operation

Closed with light control SW at HEAD position and dimmer SW at HIGH position

Closed with dimmer SW at FLASH position

#### C14 COMBINATION SW

13-16 : Closed with light control SW at HEAD position

14-16 : Closed with light control SW at TAIL or HEAD position

8-16 : Closed with dimmer SW at FLASH position

7-16 : Closed with dimmer SW at HIGH or FLASH position

#### D1 DAYTIME RUNNING LIGHT RELAY

12-GROUND : Always approx. 12 volts

10-GROUND : Always continuity

4-GROUND : Continuity with the light control SW at HEAD position

2-GROUND : Continuity with the light control SW at TAIL or HEAD position

6-GROUND : Continuity with the light control SW at FLASH position

13-GROUND : Continuity with the light control SW at HIGH or FLASH position

1-GROUND : Approx. 12 volts with the ignition SW at ON position

### : PARTS LOCATION

Code		See Page	Co	ode	See Page	Code	See Page
A13		96 (LHD)	С	14	98 (LHD)	H6	97 (LHD)
A14	Α	98 (LHD)		)1	98 (LHD)	H7	97 (LHD)
A15	В	98 (LHD)	E2	A	96 (LHD)	H8	97 (LHD)
B6	Α	98 (LHD)	E3	В	96 (LHD)	J5	99 (LHD)
C10	Α	98 (LHD)	E6	E	96 (LHD)	J9	99 (LHD)
C11	В	98 (LHD)	H	15	97 (LHD)	J11	99 (LHD)

#### : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
2	80 (LHD)	Engine Room No.2 R/B (Engine Compartment Right)
3	94 (LHD)	Engine Room No.3 R/B (Engine Compartment Right)


### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)			
1A					
1E	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)			
1F	7				
1G	60 (I FID)	Engine Dean Main With and Disc Old 1/D (1 010 1 D			
10	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)			
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)			
2F					
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)			
21	1				
2M	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)			

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)

Code	See Page	Ground Points Location		
EC	112 (LHD)	Left Fender Apron		
ID	114 (LHD)	Cowl Side Panel LH		
IG	114 (LHD)	Cowl Side Panel RH		





## **HEADLIGHT (LHD w/o DAYTIME RUNNING LIGHT)**

### SERVICE HINTS -

### **HEAD LP RELAY**

1-2: Closed with the light control SW at **HEAD** position or the dimmer SW at **FLASH** position

### **C14 COMBINATION SW**

7-16 : Closed with the dimmer SW at HIGH or FLASH position

8-16 : Closed with the dimmer SW at **FLASH** position

13-16 : Closed with the light control SW at HEAD position

### : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C10	98 (LHD)	H6	97 (LHD)	J5	99 (LHD)
C14	98 (LHD)	H7	97 (LHD)	R7	99 (LHD)
H5	97 (LHD)	H8	97 (LHD)		

### : RELAY BLOCKS

	Code	See Page	Relay Blocks (Relay Block Location)
ŀ	1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
	2	80 (LHD)	Engine Room No.2 R/B (Engine Compartment Right)

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	Code See Page Junction Block and Wire Harness (Connector Location)				
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)			
1F		instrument Fanel Wife and Driver Side J/B (Left Nick Panel)	and Driver Side 3/B (Left Rick Panel)		
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)	-		
2F	84 (LHD)	Instrument Panel Wire and Researce Cide I/R (Bight Kiel, Benell)			
21	7 04 (LND)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)			
2M	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)			

### : GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
IG	114 (LHD)	Cowl Side Panel RH

## **HEADLIGHT (RHD)**

### - SERVICE HINTS

#### **HEAD LP RELAY**

1-2 : Closed with the light control SW at **HEAD** position or the dimmer SW at **FLASH** position

### C14 (A), (B) COMBINATION SW

(A) 7, (B) 2-(A)16, (B)17: Closed with the dimmer SW at **HIGH** or **FLASH** position (A) 8, (B) 1-(A)16, (B)17: Closed with the light control SW at **FLASH** position

(A)13, (B)15-(A)16, (B)17: Closed with the dimmer SW at HEAD position

### O : PARTS LOCATION

C	ode	See Page	Code	See Page	Code	See Page
C10		106 (RHD)	H6	105 (RHD)	J9	107 (RHD)
C14	Α	106 (RHD)	H7	105 (RHD)	R7	107 (RHD)
014	В	106 (RHD)	H8	105 (RHD)	T4	107 (RHD)
H5		105 (RHD)	J5	107 (RHD)	<u> </u>	

### : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)
2	81 (RHD)	Engine Room No.2 R/B (Engine Compartment Left)

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)		
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)		
1B	7 00 (NND)			
1E		Instrument Panel Wire and Driver Side J/B (Right Kick Panel)		
1F	1F 88 (RHD) 1G			
1G				
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)		
2L 90 (RHD) Instrument Panel Wire and Passenger Side J		Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)		

### : GROUND POINTS

196

	Code	See Page	Ground Points Location		 	 
ĺ	EC	122 (RHD)	Left Fender Apron	· · · · · · · · · · · · · · · · · · ·	 	
	ID	124 (RHD)	Cowl Side Panel LH		 	 
ı		124 (RHD)	Cowl Side Panel RH	· · · · · · · · · · · · · · · · · · ·	 · ,	 

- \* 1 : W/ DAYTIME RUNNING LIGHT \* 2 : W/O DAYTIME RUNNING LIGHT \* 3 : FRONT FOG LIGHT SW



### SERVICE HINTS

FR FOG RELAY 5-3 : Closed with the light control SW at TAIL or HEAD position and the fog light SW at ON position


### : PARTS LOCATION


Code		See Page	Code See Page		Code	See Page	
C10	Α	98 (LHD)	D1	98 (LHD)	J5	99 (LHD)	
C11	В	98 (LHD)	F3	96 (LHD)	J9	99 (LHD)	
С	14	98 (LHD)	F4	96 (LHD)			

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)	
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)	
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)	
1H	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)	
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)	
2F			
2G	84 (LHD)	Instrument Penel Wire and Peneggar Cide VP (Pinht Viel, Penel)	
2H		Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)	
21			

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
D	114 (LHD)	Cowl Side Panel LH
IG	114 (LHD)	Cowl Side Panel RH
IH	114 (LHD)	Front Floor Panel Center LH





## **REAR FOG LIGHT (LHD)**

### - SERVICE HINTS

### **R7 REAR FOG LIGHT SW**

1-GROUND : Approx. 12 volts with the light control SW at HEAD or TAIL position and the rear fog light SW at ON position

2-GROUND : Approx. 12 volts with the light control SW at HEAD or TAIL position

7-GROUND : Always continuity

3, 4, 5-GROUND : Always approx. 12 volts

### : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C14	98 (LHD)	J9	99 (LHD)	J17	100 (LHD)
D1	98 (LHD)	J11	99 (LHD)	R7	99 (LHD)
J5	99 (LHD)	J14	100 (LHD)	R12	101 (LHD)
J8	99 (LHD)	J16	100 (LHD)	R13	101 (LHD)

### : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)			
1A	—— 82 (LHD)				
1E		Instrument Panel Wire and Driver Side J/B (Left Kick Panel)			
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)			
2B	84 (LHD) Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)				
2F	2F	leader and Dec. (1977).			
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)			
2M	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)			


### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Ĺ	Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
	IB1	114 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)

### : GROUND POINTS

Code	See Page	Ground Points Location	
EC	112 (LHD)	Left Fender Apron	
ID	114 (LHD)	Cowl Side Panel LH	
IG	114 (LHD)	Cowl Side Panel RH	
BJ	118 (LHD)	Front Floor Panel LH	
BK	118 (LHD)	Left Quarter Panel LH	

\* 3 : LHD W/ DAYTIME RUNNING LIGHT \* 4 : LHD W/O DAYTIME RUNNING LIGHT





### **TAILLIGHT**

### SYSTEM OUTLINE -

When the light control SW is turned to TAIL or HEAD position, the current flows to TERMINAL 3 of the light failure sensor through the TAIL fuse.

When the ignition SW is turned on, the current flows from the GAUGE fuse to TERMINAL 8 of the light failure sensor, and also flows through the rear light warning light to TERMINAL 4 of the light failure sensor.

### **TAILLIGHT DISCONNECTION WARNING**

With the ignition SW on and the light control SW turned to TAIL or HEAD position, if the taillight circuit is open, the light failure sensor detects the failure by the change in current flowing from TERMINAL 3 of the light failure sensor to TERMINAL 9 and the warning circuit of the light failure sensor is activated.

As a result, the current flows from TERMINAL 4 of the light failure sensor to TERMINAL 11 to GROUND and turns the rear lights warning light on, which remains on until the light control SW is turned off.

### - SERVICE HINTS

#### **TAIL RELAY**

5-3 : Closed with the light control SW at TAIL or HEAD position

### L3 LIGHT FAILURE SENSOR

4, 8-GROUND : Approx. 12 volts with ignition SW at ON or ST position

3, 9-GROUND : Approx. 12 volts with light control SW at TAIL or HEAD position

11-GROUND : Always continuity

### : PARTS LOCATION

Co	de	See Page	Code	See Page	Code	See Page
C10	Α	98 (LHD)	J5	99 (LHD)	L1	108 (RHD)
		106 (RHD)		107 (RHD)	1.0	100 (LHD)
C11	В	98 (LHD)	J9	107 (RHD)	L2	108 (RHD)
		106 (RHD)	J14	100 (LHD)	10	100 (LHD)
C14	A	98 (LHD)	314	108 (RHD)	L3	108 (RHD)
		106 (RHD)	J15	100 (LHD)	D10	101 (LHD)
	В	106 (RHD)		108 (RHD)		109 (RHD)
D	1	98 (LHD)	J16	100 (LHD)	D11	101 (LHD)
F	1	96 (LHD)	310	108 (RHD)		109 (RHD)
	<u>.</u>	104 (RHD)	J17	100 (LHD)	T4	107 (RHD)
F2		96 (LHD)	317	108 (RHD)		
		104 (RHD)	L1	100 (LHD)		

#### : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
1	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)

## C

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)	
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)	
1B	99 (DHD)		
1C	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)	
1E	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)	
, L	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)	
1F	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)	
	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)	
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)	
1H	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)	
	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)	
11	82 (LHD)	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)	
1K	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)	
10	OZ (ZI IB)	Eligine Room Main Wire and Driver Side J/B (Left Rick Panel)	
2A	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)	
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)	
2H	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)	
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)	
21	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)	
2K	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)	
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)	


### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)			
IB1	114 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)			
	124 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)			
BD1	118 (LHD)				
	128 (RHD)	Floor No 3 Wire and Luggers Deam Wire (Binh) Cide of the Luggers Deam			
BD2	118 (LHD)	Floor No.2 Wire and Luggage Room Wire (Right Side of the Luggage Door)			
	128 (RHD)				


Code	See Page	Ground Points Location			
EC	112 (LHD)	Left Fender Apron			
	122 (RHD)	Lett Ferider Aproli			
ID	114 (LHD)	Cowl Side Panel LH			
טו	124 (RHD)	Cowi Side Fariei Lh			
IF	124 (RHD)	Coul Side Bonel BU			
IG	114 (LHD)	Cowl Side Panel RH			
BK	118 (LHD)	Left Quarter Panel LH			
אט	128 (RHD)	Tell Qualler Failer Ln			

**ILLUMINATION (LHD)** 

\* 3 : W/ LEXUS NAVIGATION SYSTEM \* 4 : W/ DAYTIME RUNNING LIGHT \* 5 : W/O DAYTIME RUNNING LIGHT J 8 JUNCTION CONNECTOR







SERVICE HINTS

### **TAIL RELAY**

5-3: Closed with light control SW at TAIL or HEAD position

### C14 LIGHT CONTROL SW [COMB. SW]

14-16 : Closed with light control SW at TAIL or HEAD position

### : PARTS LOCATION

Code	See Page		ode	See Page	Co	de	See Page
A14	98 (LHD)	J	15	99 (LHD)	R	17	99 (LHD)
A19	98 (LHD)	J	J7	99 (LHD)	R	18	99 (LHD)
A30	98 (LHD)	J	J8	99 (LHD)	R	19	99 (LHD)
C9	98 (LHD)	J	19	99 (LHD)	S	6	99 (LHD)
C10	98 (LHD)	J	11	99 (LHD)	S	7	99 (LHD)
C14	98 (LHD)	J	13	100 (LHD)	S9	Α	99 (LHD)
D1	98 (LHD)	N	<b>/</b> 11	99 (LHD)	S10	В	99 (LHD)
E10	99 (LHD)	N3	Α	101 (LHD)	Т6	Α	99 (LHD)
G1	99 (LHD)	N6	D	101 (LHD)	一 '°	В	99 (LHD)
H13	99 (LHD)	R4	С	99 (LHD)			
H14	99 (LHD)	R6	В	99 (LHD)			

### : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)				
1A						
1E	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)				
1F						
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)				
10	02 (L110)	Engine Room Main Wire and Driver Side J/B (Leit Rick Panel)				
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)				
2F	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)				
2G	] 04 (E11D)	Institution ratio wife and rassenger side J/D (night NCK Panel)				
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)				

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

	Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
	IH1	116 (LHD)	Instrument Basel Wire and Floor Wire (Near the Deceases Cids 1/D)
[	IH2	110 (LND)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)


### : GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
ID	114 (LHD)	Cowl Side Panel LH
ΙE	114 (LHD)	Instrument Panel Center
IG	114 (LHD)	Cowl Side Panel RH
11	114 (LHD)	Front Floor Panel Center RH
BL	118 (LHD)	Front Floor Panel RH

### : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
4	116 (LHD)	Instrument Panel Wire			

## **TURN SIGNAL AND HAZARD WARNING LIGHT (LHD)**



### SERVICE HINTS

### **FLSH RELAY**

4-GROUND : Always approx. 12 volts

1-GROUND : Approx. 12 volts with ignition SW at ON or ST position

7-GROUND : Always continuity

### O : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A15	98 (LHD)	F6	96 (LHD)	J17	100 (LHD)
B6	98 (LHD)	F7	96 (LHD)	R10	101 (LHD)
C10	98 (LHD)	F8	96 (LHD)	R11	101 (LHD)
C14	98 (LHD)	J5	99 (LHD)		
F5	96 (LHD)	J7	99 (LHD)		

### ) : RELAY BLOCKS

İ	Code	See Page	Relay Blocks (Relay Block Location)
	1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)			
1A	82 (LHD)	Instrument Benel Wire and Driver Side I/B (Left Viels Benel)			
1E	02 (1110)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)			
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)			
1H	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)			
11	82 (LHD)	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)			
1K	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)			
1L	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)			
2A	84 (LHD)	Engine Poem Main Wire and Researcer Side VP (Dight Viels Benel)			
2B	07 (2110)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)			
2F	84 (LHD)	Instrument Panel Wire and Resconger Side I/D (Dight Viels Danel)			
2H	ן טק (בו וט)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)			

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
ID .	114 (LHD)	Cowl Side Panel LH
IG	114 (LHD)	Cowl Side Panel RH
IH	114 (LHD)	Front Floor Panel Center LH
BK	118 (LHD)	Left Quarter Panel LH

FROM POWER SOURCE SYSTEM (SEE PAGE 140, 144) □ (A) □ (B) □ (B) J2A, J3B JUNCTION CONNECTOR N 1 (A)
BACK-UP LIGHT SW
[NEUTRAL START SW]
B 1 (B)
BACK-UP LIGHT SW J2A, J3B R10 BACK-UP LIGHT LH [REAR COMB. LIGHT LH] R11 BACK-UP LIGHT RH [REAR COMB. LIGHT RH] J17 JUNCTION CONNECTOR

### SERVICE HINTS -

### N1 (A) BACK-UP LIGHT SW [NEUTRAL START SW] (A/T)

3-2 : Closed with the shift lever at R position

### B1 (B) BACK-UP LIGHT SW (M/T)

2-1 : Closed with the shift lever at R position

### O : PARTS LOCATION


Code		See Page		de	See Page	Code	See Page
B1	В	96 (LHD)	J3 B		105 (RHD)	R10	101 (LHD)
		104 (RHD)	J17		100 (LHD)		109 (RHD)
J2	Δ	97 (LHD)	317		108 (RHD)	R11	101 (LHD)
] "	^	105 (RHD)	N1	۸	97 (LHD)	NII	109 (RHD)
J3	В	97 (LHD)	INI	Α	105 (RHD)		

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
11	82 (LHD)	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)
1K	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1L	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2H	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
21	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)

Code	See Page	Ground Points Location
BK	118 (LHD)	Left Quarter Panel LH
	128 (RHD)	Leit Quarter Failer Err

### STOP LIGHT



### SYSTEM OUTLINE -

Current is applied at all times through a STOP fuse to TERMINAL 2 of the stop light SW. When the ignition SW is turned on, current flows from the GAUGE fuse to TERMINAL 8 of the light failure sensor, and also flows through the rear light warning light to TERMINAL 4 of the light failure sensor.

### STOP LIGHT DISCONNECTION WARNING

When the ignition SW is turned on and the brake pedal is depressed (Stop light SW on), if the stop light circuit is open, the current flowing from TERMINAL 7 of the light failure sensor to TERMINALS 1, 2 changes, so the light failure sensor detects the disconnection and the warning circuit of the light failure sensor is activated. As a result, the current flows from TERMINAL 4 of the light failure sensor to TERMINAL 11 to GROUND and turns the rear lights warning light on. By depressing the brake pedal, the current flowing to TERMINAL 8 of the light failure sensor keeps the warning circuit on and the warning light on until the ignition SW is turned off.

#### SERVICE HINTS

#### **S11 STOP LIGHT SW**

2-1: Closed with the brake pedal depressed

#### L3 LIGHT FAILURE SENSOR

1, 2, 7-GROUND : Approx. 12 volts with stop light SW on

4, 8-GROUND : Approx. 12 volts with ignition SW at ON or ST position

11-GROUND : Always continuity

### : PARTS LOCATION

Code		See Page	Code	See Page	Code	See Page
C10	A	98 (LHD)	J15	100 (LHD)	NO	101 (LHD)
		106 (RHD)	313	108 (RHD)	- N8	109 (RHD)
C11	В	98 (LHD)	J16	100 (LHD)	B40	101 (LHD)
	U	106 (RHD)		108 (RHD)	R10	109 (RHD)
ш	16	100 (LHD)	J17	100 (LHD)	D44	101 (LHD)
<u>'</u>		108 (RHD)		108 (RHD)	R11	109 (RHD)
.11	14	100 (LHD)	L3	100 (LHD)	C11	99 (LHD)
	I <b>- T</b>	108 (RHD)		108 (RHD)	S11	107 (RHD)

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)			
1E	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)			
1G	1G 88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)			
1H	00 (11112)				
1!	82 (LHD)	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)			
1K	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)			
2H	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)			
21	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)			

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB1	114 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)
	124 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)
IF1	126 (RHD)	Instrument Panel No.3 Wire and Instrument Panel Wire (Right Side of the Instrument Panel)

Code	See Page	Ground Points Location
ВК	118 (LHD)	Left Quarter Panel LH
	128 (RHD)	Lett Quarter Farier Lin


# MULTIPLEX COMMUNICATION SYSTEM (COMMUNICATION BUS) (LHD)




## MULTIPLEX COMMUNICATION SYSTEM (COMMUNICATION BUS) (LHD)


### MULTIPLEX COMMUNICATION SYSTEM INCLUDES FOLLOWING SYSTEMS


- \* ABS AND TRACTION CONTROL
- \* AUTOMATIC AIR CONDITIONER
- \* CHARGING
- \* COMBINATION METER
- \* CRUISE CONTROL
- \* DOOR LOCK CONTROL
- \* ECT AND A/T INDICATOR
- \* ENGINE CONTROL
- \* ENGINE IMMOBILISER SYSTEM
- \* FRONT WINDOW DEICER
- \* HEADLIGHT (w/ DAYTIME RUNNING LIGHT)
- \* INTERIOR LIGHT
- \* LIGHT REMINDER
- \* POWER WINDOW
- \* REAR WINDOW DEFOGGER AND MIRROR HEATER
- \* SEAT BELT WARNING
- \* WIRELESS DOOR LOCK CONTROL







## **MULTIPLEX COMMUNICATION SYSTEM (LHD)**








# MULTIPLEX COMMUNICATION SYSTEM (LHD)














## **MULTIPLEX COMMUNICATION SYSTEM (LHD)**

#### - SYSTEM OUTLINE -

### **MULTIPLEX COMMUNICATION SYSTEM**

The system is comprised of the communication modes of the body ECU, engine ECU (M/T) or engine and ECT ECU (A/T), power window master SW, combination meter and A/C control assembly. The body electrical systems are controlled by a serial communication in which each ECU is linked to another via a single communication line. This system is also equipped with a self-diagnosis function.

The table below shows the systems under the control of the MPX communication system and related ECUs (Communication nodes).

	Body ECU	Engine ECU (M/T) or Engine and ECT ECU (A/T)	Combination Meter	A/C Control Assembly	Double Door Lock ECU	Power Window Master SW	Wireless Door Lock ECU
Door Lock Control	1	_	1	_	2	2	2
Wireless Door Lock	2	_	_	_	2	1	1
Illuminated Entry	1	_	_	_	_	-	_
Light Reminder	1	_	2	-	_	-	_
Luggage Compartment Door Opener	1	_	-	_	_	_	
C-BEST System	1	-	2	2	-	-	_
Diagonosis System	1	_	2	2	-	-	-
Seat Belt Warning	1	_	2	ı	-	-	_
ECT Signal	_	1	2	2	-	_	-
A/C Control	_	2	-	1	_	_	_
Multi Information Display	2	2	1	2	-	_	-
Double Door Lock	_	_	-	_	1	_	_

1 : Master control 2 : Sub control

#### 1. COMMUNICATION OUTLINE

Communication is implemented among the combination meter, power window master SW, A/C control assembly, body, engine ECU (M/T) or engine and ECT ECUs (A/T).

Upon receiving signals from applicable switches such as the door lock control switch or door courtesy light switch, each ECU determines the conditions of the switches as well as of the doors, and after converting this information into digital signals, outputs them to other ECUs via serial data communication. The ECU that receives these digital signals determines the conditions of the switches and doors so that it can implement various controls such as to activate a door lock motor.

However, if there are no changes in the input signals because no doors were opened and no switches were used within 30 seconds, the body ECU interrupts the communication to save electricity. Following this interruption, any changes in the input signals will cause the communication to resume.

For details please refer to the new car features and repair manuals.

#### SERVICE HINTS -

### B6 (A), B7 (B) BODY ECU

3-GROUND : Approx. 12 volts with ignition SW at ON or ST position

1-GROUND : Always approx. 12 volts 2-GROUND : Always approx. 12 volts

12-GROUND : Always continuity

4-GROUND : Approx. 12 volts with ignition SW at ACC or ON position

(A)19-GROUND: Always continuity

### : PARTS LOCATION

Code		See Page	Code		See Page	Code		See Page	
A14	Α	98 (LHD)	D14		100 (LHD)	L6		100 (LHD)	
A15	В	98 (LHD)	D15		100 (LHD)	L7		100 (LHD)	
B6	Α	98 (LHD)	D.	16	100 (LHD)	М3	Α	100 (LHD)	
B7	В	98 (LHD)	E2	Α	96 (LHD)	P3	В	101 (LHD)	
P	38	100 (LHD)	<b>E</b> 3	В	96 (LHD)	Р	5	101 (LHD)	
		102 (LHD)	F.	15	100 (LHD)	Р	6	101 (LHD)	
В	11	100 (LHD)	F.	16	100 (LHD)	P	7	101 (LHD)	
С	10	98 (LHD)	l14		99 (LHD)	P8		101 (LHD)	
С	14	98 (LHD)	l16		100 (LHD)	P9		101 (LHD)	
	)1	98 (LHD)	J5		99 (LHD)	P10		101 (LHD)	
	)4	98 (LHD)	J8		99 (LHD)	P11		101 (LHD)	
	)5	100 (LHD)		9	99 (LHD)	P.	12	101 (LHD)	
	)6	100 (LHD)	J1	12	100 (LHD)	U	1	99 (LHD)	
	)7	100 (LHD)	J13		100 (LHD)	V4		101 (LHD)	
D8		100 (LHD)	J1	14	100 (LHD)	V	5	101 (LHD)	
	9	100 (LHD) J16		6	100 (LHD)	W	/4	101 (LHD)	
D	10	100 (LHD)	J1	7	100 (LHD)				
D	11	100 (LHD)	L	4	100 (LHD)				

### ) : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)

# MULTIPLEX COMMUNICATION SYSTEM (LHD)

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)				
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)				
1B	82 (LHD)	Front Door LH Wire and Driver Side J/B (Left Kick Panel)				
1E	82 (LHD)					
1F	02 (LIID)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)				
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)				
1H	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)				
11	82 (LHD)	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)				
1L	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)				
1N	82 (LHD)	Roof Wire and Driver Side J/B (Left Kick Panel)				
10	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)				
2B	84 (LHD)	Engine Poem Main Wire and Poesses Cide UP (Picket Cide P				
2C	04 (LI 1 <i>D)</i>	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)				
2E						
2G	84 (LHD)	Instrument Benel Wire and Beneause Cids I/D /District I				
2H	04 (LND)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)				
21						
2K	84 (LHD)	Front Door RH Wire and Passenger Side J/B (Right Kick Panel)				
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)				

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)	
IB1	114 (LHD)	Instrument Decal Miles and Elevan April 2015	
IB2	114 (LND)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)	
IC1	114 (LHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)	
IH3	116 (LHD)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)	
II1	116 (LHD)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)	
BA1	118 (LHD)	Rear Door No.2 Wire and Floor No.2 Wire (Left Center Pillar)	
BB1	118 (LHD)	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)	
BC1	118 (LHD)	Floor No.2 Wire and Floor Wire (Under the Right Rear Cushion)	
BE1	120 (LHD)	Floor No.2 Wire and Front Seat LH Wire (Under the Driver's Seat)	·

### : GROUND POINTS


Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
ID	114 (LHD)	Cowl Side Panel LH
IG	114 (LHD)	Cowl Side Panel RH
IH	114 (LHD)	Front Floor Panel Center LH
BJ	118 (LHD)	Front Floor Panel LH
BK	118 (LHD)	Left Quarter Panel LH
BL	118 (LHD)	Front Floor Panel RH
ВМ	118 (LHD)	Roof Panel



## : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B2	118 (LHD)	Roof Wire			


## MULTIPLEX COMMUNICATION SYSTEM (COMMUNICATION BUS) (RHD)




### MULTIPLEX COMMUNICATION SYSTEM INCLUDES FOLLOWING SYSTEMS


- \* ABS AND TRACTION CONTROL
- \* AUTOMATIC AIR CONDITIONER
- \* AUTOMATIC LIGHT CONTROL
- \* CHARGING
- \* COMBINATION METER
- \* CRUISE CONTROL
- \* DOOR LOCK CONTROL
- \* DOUBLE LOCKING
- \* ECT AND A/T INDICATOR
- \* ENGINE CONTROL
- \* ENGINE IMMOBILISER SYSTEM
- \* FRONT WINDOW DEICER
- \* INTERIOR LIGHT
- \* LIGHT REMINDER
- \* POWER WINDOW
- \* REAR WINDOW DEFOGGER AND MIRROR HEATER
- \* SEAT BELT WARNING
- \* THEFT DETERRENT
- \* WIRELESS DOOR LOCK CONTROL


## **INTERIOR LIGHT (LHD)**





\* 1 : W/ MOON ROOF \* 2 : W/O MOON ROOF





### **INTERIOR LIGHT (LHD)**

### - SYSTEM OUTLINE

#### **ILLUMINATED ENTRY SYSTEM**

This system provides various functions listed below through communication control of the body ECU and door ECU etc.

- \* Each relevant light lights up if any door is opened.
- \* If all the doors are closed with the ignition SW set at OFF after any door is opened, each light lights up for 15 sec., and then fades out when the time set on the timer has elapsed.
- \* If any door is unlocked from the driver side or if any door is unlocked with the unlock SW on the transmitter after all the doors are closed and locked, each light lights up for 15 sec., and then fades out when the time set on the timer has elapsed.
- \* If the ignition SW is turned to the ACC or ON position while each light is being lit by the timer, the timer lighting is cancelled and the light fades out.
- \* If all the doors are closed and locked from the driver side or with the lock SW on the transmitter while each light is being lit, the timer lighting is cancelled and the light fades out.
- \* If all the doors are closed with the ignition SW set at ACC or ON after any door is opened, the timer lighting is cancelled and the light fades out.
- \* Each light above is the interior light, ignition key cylinder light, and any door is opened.

#### SERVICE HINTS -

### D7, D8, D9, D10 DOOR COURTESY SW FRONT LH, RH, REAR LH, RH

1-GROUND : Closed with door open

### L4 LUGGAGE COMPARTMENT DOOR COURTESY SW

2-GROUND : Closed with luggage compartment door open

### W4 WIRELESS DOOR LOCK ECU

5-GROUND : Always approx. **12** volts 1-GROUND : Always continuity

### B6 (A) BODY ECU

BECU-GROUND : Always approx. 12 volts BSUB-GROUND : Always approx. 12 volts

IG-GROUND : Approx. 12 volts with ignition SW at **ON** or **ST** position ACC-GROUND : Approx. 12 volts with ignition SW at **ACC** or **ON** position

GND1-GROUND : Always continuity GND2-GROUND : Always continuity

### : PARTS LOCATION

Code		See Page	Co	de	See Page	Co	de	See Page
A14	Α	98 (LHD)	D	11	100 (LHD)	J.	4	100 (LHD)
A15	В	98 (LHD)	D	14	100 (LHD)	J-	16	100 (LHD)
B6	Α	98 (LHD)	D.	15	100 (LHD)	J1	17	100 (LHD)
В7	В	98 (LHD) D16		16	100 (LHD)	L	4	100 (LHD)
С	10	98 (LHD)	E2	Α	96 (LHD)	L	7	100 (LHD)
	)4	98 (LHD)	E3	В	96 (LHD)	M3	Α	100 (LHD)
	)5	100 (LHD)	11	4	99 (LHD)	P3	В	101 (LHD)
D6		100 (LHD)	l1	6	100 (LHD)	P	8	101 (LHD)
С	7	100 (LHD)	J	5	99 (LHD)	V	4	101 (LHD)
	8	100 (LHD)	J	9	99 (LHD)	V	5	101 (LHD)
D	9	100 (LHD)	J1	2	100 (LHD)	w	/4	101 (LHD)
D	10	100 (LHD)	J1	3	100 (LHD)			

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	82 (LHD)	Front Door LH Wire and Driver Side J/B (Left Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	82 (LHD)	Instrument Penal Mire and Driver Cide I/D /Left Viels Denal)
1L	- 02 (END)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1N	82 (LHD)	Roof Wire and Driver Side J/B (Left Kick Panel)
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2E		
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2H		
2K	84 (LHD)	Front Door RH Wire and Passenger Side J/B (Right Kick Panel)
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)

#### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
IB1	114 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)
IC1	114 (LHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IH3	116 (LHD)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
ll1	116 (LHD)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
BA1	118 (LHD)	Rear Door No.2 Wire and Floor No.2 Wire (Left Center Pillar)
BB1	118 (LHD)	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)
BC1	118 (LHD)	Floor No.2 Wire and Floor Wire (Under the Right Rear Cushion)


### : GROUND POINTS


Code	See Page	Ground Points Location	
EC	112 (LHD)	Left Fender Apron	
ID	114 (LHD)	Cowl Side Panel LH	
IG	114 (LHD)	Cowl Side Panel RH	
IH	114 (LHD)	Front Floor Panel Center LH	
BK	118 (LHD)	Left Quarter Panel LH	
BL	118 (LHD)	Front Floor Panel RH	
ВМ	118 (LHD)	Roof Panel	


### : SPLICE POINTS


Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B2	118 (LHD)	Roof Wire			

## **DOOR LOCK CONTROL (LHD)**









## **DOOR LOCK CONTROL (LHD)**

#### SYSTEM OUTLINE -

The door lock control is controlled through the various signals input into the body ECU through communication control of the body ECU etc.

#### 1. MANUAL OPERATION

All doors can be Locked/Unlocked through the operation of the driver side door lock control SW.

#### 2. MANUAL UNLOCK PROTECTION

Once the doors are locked by the door knob (Key less operation), the door key or the transmitter, they can not be unlocked by the door lock control SW. The protection is canceled when the ignition SW is turned on or unlock operation is made by the door key or the transmitter.

### SERVICE HINTS

### D11 DOOR LOCK MOTOR, DOOR KEY LOCK AND UNLOCK SW AND DOOR LOCK DETECTION SW FRONT LH

5-GROUND : Approx. 12 volts with door lock motor at lock operate

6-GROUND : Approx. 12 volts with door lock motor at unlock operate

4-2 : Closed with door lock cylinder locked with key

3-2: Closed with door lock cylinder unlocked with key

### D14 DOOR LOCK MOTOR AND DOOR LOCK DETECTION SW FRONT RH

1-GROUND : Approx. 12 volts with door lock motor at lock operate

2-GROUND : Approx. 12 volts with door lock motor at unlock operate

### D15 DOOR LOCK MOTOR AND DOOR LOCK DETECTION SW REAR LH

3-GROUND : Approx. 12 volts with door lock motor at lock operate

4-GROUND : Approx. 12 volts with door lock motor at unlock operate

### D16 DOOR LOCK MOTOR AND DOOR LOCK DETECTION SW REAR RH

1-GROUND : Approx. 12 volts with door lock motor at lock operate

2-GROUND : Approx. 12 volts with door lock motor at unlock operate

### : PARTS LOCATION

Code		See Page	Co	ode	See Page	Code	See Page	
A14	Α	98 (LHD)	C	9	100 (LHD)	J5	99 (LHD)	
A15	В	98 (LHD)	D	10	100 (LHD)	J9	99 (LHD)	
B6	Α	98 (LHD)	D	11	100 (LHD)	J12	100 (LHD)	
В7	В	98 (LHD)	D	14	100 (LHD)	J13	100 (LHD)	
C.	10	98 (LHD)	D	15	100 (LHD)	J16	100 (LHD)	
D	)4	98 (LHD)	D	16	100 (LHD)	J17	100 (LHD)	
D7		100 (LHD)	E2	Α	96 (LHD)	P8	101 (LHD)	
D8		100 (LHD)	E3	В	96 (LHD)	U1	99 (LHD)	

#### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	82 (LHD)	Front Door LH Wire and Driver Side J/B (Left Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
11	82 (LHD)	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)
1L	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2E		
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2H	04 (LIID)	
21		
2K	84 (LHD)	Front Door RH Wire and Passenger Side J/B (Right Kick Panel)
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)


### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)	
IH3	116 (LHD)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)	
II1	116 (LHD)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)	
BA1	118 (LHD)	Rear Door No.2 Wire and Floor No.2 Wire (Left Center Pillar)	
BB1	118 (LHD)	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)	
BC1	118 (LHD)	Floor No.2 Wire and Floor Wire (Under the Right Rear Cushion)	


## $\nabla$


### : GROUND POINTS

Code	See Page	Ground Points Location	
EC	112 (LHD)	Left Fender Apron	
ID	114 (LHD)	Cowl Side Panel LH	
IG	114 (LHD)	Cowl Side Panel RH	
ВК	118 (LHD)	Left Quarter Panel LH	
BL	118 (LHD)	Front Floor Panel RH	









# **DOOR LOCK CONTROL (RHD)**

#### SYSTEM OUTLINE

The door lock control is controlled through the various signals input into the body ECU through communication control of the body ECU etc.

#### 1. MANUAL OPERATION

All doors can be Locked/Unlocked through the operation of the driver side door lock control SW.

#### 2. MANUAL UNLOCK PROTECTION

Once the doors are locked by the door knob (Key less operation), the door key or the transmitter, they can not be unlocked by the door lock control SW. The protection is canceled when the ignition SW is turned on or unlock operation is made by the door key or the transmitter.

#### SERVICE HINTS

#### D12 (A), (B) DOOR LOCK MOTOR, DOOR KEY LOCK AND UNLOCK SW AND DOOR LOCK DETECTION SW FRONT RH

2 (A), 1 (B)-GROUND: Approx. 12 volts with door lock motor at lock operate 3 (A), 2 (B)-GROUND: Approx. 12 volts with door lock motor at unlock operate

3 (B)-5 (B): Closed with door lock cylinder locked with key

4 (B)-5 (B): Closed with door lock cylinder unlocked with key

#### D13 (A), (B) DOOR LOCK MOTOR AND DOOR LOCK DETECTION SW FRONT LH

2 (A), 3 (B)-GROUND: Approx. 12 volts with door lock motor at lock operate

3 (A), 4 (B)-GROUND : Approx. 12 volts with door lock motor at unlock operate

#### D15 (A), (B) DOOR LOCK MOTOR AND DOOR LOCK DETECTION SW REAR LH

2 (A), 3 (B)-GROUND: Approx. 12 volts with door lock motor at lock operate

3 (A), 4 (B)-GROUND : Approx. 12 volts with door lock motor at unlock operate

#### D16 (A), (B) DOOR LOCK MOTOR AND DOOR LOCK DETECTION SW REAR RH

2 (A), 1 (B)-GROUND : Approx. 12 volts with door lock motor at lock operate

3 (A), 2 (B)-GROUND: Approx. 12 volts with door lock motor at unlock operate

#### : PARTS LOCATION

Co	ode	See Page	Co	ode	See Page	Code	See Page
A14	Α	106 (RHD)	D12	Α	108 (RHD)	J9	107 (RHD)
A15	В	106 (RHD)		В	108 (RHD)	J11	107 (RHD)
В6	Α	106 (RHD)	D13	Α	108 (RHD)	J12	108 (RHD)
B7	В	106 (RHD)	] 513	В	108 (RHD)	J13	108 (RHD)
С	10	106 (RHD)	D15	Α	108 (RHD)	J16	108 (RHD)
	)2	106 (RHD)	ן טוס	В	108 (RHD)	J17	108 (RHD)
	)4	106 (RHD)	D16	Α	108 (RHD)	P8	109 (RHD)
	)7	108 (RHD)	] 510	В	108 (RHD)	<b>T</b> 5	107 (RHD)
	8	108 (RHD)	E2	Α	104 (RHD)	U1	107 (RHD)
	9	108 (RHD)	E3	В	104 (RHD)		
D	10	108 (RHD)	J	5	107 (RHD)		

#### $\boldsymbol{\alpha}$ .

#### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1H	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1K	88 (RHD)	Front Door RH Wire and Driver Side J/B (Right Kick Panel)
1L	88 (RHD)	Floor Wire and Driver Side J/B (Right Kick Panel)
2B	90 (RHD)	Front Door LH Wire and Passenger Side J/B (Left Kick Panel)
2E	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2F	2F 90 (NND)	Institution Faller Wile and Fassenger Side 0/D (Left Nick Faller)
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2H	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
21	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)

#### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
IA3	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)	
IB1	124 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)	
IC1	124 (RHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)	
BA1	128 (RHD)	Rear Door No.2 Wire and Floor No.2 Wire (Left Center Pillar)	
BB1	128 (RHD)	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)	
BC1	128 (RHD)	Floor No.2 Wire and Floor Wire (Under the Right Rear Cushion)	


# $\triangle$


#### : GROUND POINTS


Code	See Page	Ground Points Location
EC	122 (RHD)	Left Fender Apron
ID	124 (RHD)	Cowl Side Panel LH
IF	124 (RHD)	Cowl Side Panel RH
BJ	128 (RHD)	Front Floor Panel LH
BK	128 (RHD)	Left Quarter Panel LH
BL	128 (RHD)	Front Floor Panel RH

# **WIRELESS DOOR LOCK CONTROL (LHD)**










# **WIRELESS DOOR LOCK CONTROL (LHD)**



#### SYSTEM OUTLINE

In this system, the wireless door lock receiver receives weak radio wave transmitted from the transmitter built-into the ignition key and outputs the signal to the body ECU. Through communication control of the body ECU etc., all the doors and the luggage door can be unlocked by the remote control.

#### 1. BASIC FUNCTION

When the vehicle receives the radio wave signals from the transmitter, the system determines the condition of respective switches by the function code attached to the identification code, and controls them. In case any door is open, the lock does not function.

#### 2. AUTO LOCK FUNCTION

If the door is not actually opened within approximately 30 seconds after the door has been unlocked by the transmitter, all the doors are locked automatically. Every time the receiver receives the unlock signal from the transmitter, the 30 second timer is canceled.

#### 3. THEFT DETERRENT FUNCTION

Although the data configuration is the same, when the receiver receives 10 kinds of radio wave signals within 10 minutes, which does not comply with the identification code, the system inhibits further control.

#### 4. CAR FINDER FUNCTION

\* Lock

The hazard light flashes once when the signal is sent and the door is locked.

\* Unlock

The hazard light flashes twice when the signal is sent and the door is unlocked.

#### 5. REPEAT FUNCTION

When any door does not respond to the lock/unlock signal, the signal output is repeated maximum twice.

#### 6. ILLUMINATED ENTRY OPERATION

When the body ECU detects that any door is unlocked, the interior light, ignition key cylinder light and door courtesy light front LH, RH comes on.

#### SERVICE HINTS

## W4 WIRELESS DOOR LOCK ECU

1-GROUND : Always continuity

5-GROUND : Always approx. 12 volts

#### L4 LUGGAGE COMPARTMENT DOOR OPENER MOTOR

1-GROUND : Approx. 12 volts with luggage door open operate

## D11 DOOR LOCK MOTOR, DOOR KEY LOCK AND UNLOCK SW AND DOOR LOCK DETECTION SW FRONT LH

5-GROUND : Approx. 12 volts with door lock motor at lock operate

6-GROUND : Approx. 12 volts with door lock motor at unlock operate

4-2: Closed with door lock cylinder locked with key

3-2: Closed with door lock cylinder unlocked with key

## D14 DOOR LOCK MOTOR AND DOOR LOCK DETECTION SW FRONT RH

1-GROUND : Approx. 12 volts with door lock motor at lock operate

2-GROUND: Approx. 12 volts with door lock motor at unlock operate

## D15 DOOR LOCK MOTOR AND DOOR LOCK DETECTION SW REAR LH

3-GROUND : Approx. 12 volts with door lock motor at lock operate

4-GROUND : Approx. 12 volts with door lock motor at unlock operate

## D16 DOOR LOCK MOTOR AND DOOR LOCK DETECTION SW REAR RH

1-GROUND : Approx. 12 volts with door lock motor at lock operate

2-GROUND : Approx. 12 volts with door lock motor at unlock operate

# WIRELESS DOOR LOCK CONTROL (LHD)

# O : PARTS LOCATION

Co	de	See Page	Co	ode	See Page	Code	See Page
A14	Α	98 (LHD)	D	11	100 (LHD)	J14	100 (LHD)
A15	В	98 (LHD)	D	14	100 (LHD)	J16	100 (LHD)
B6	Α	98 (LHD)	D	15	100 (LHD)	J17	100 (LHD)
B7	В	98 (LHD)	D	16	100 (LHD)	L4	100 (LHD)
C.	10	98 (LHD)	E2	Α	96 (LHD)	L6	100 (LHD)
D	4	98 (LHD)	E3	В	96 (LHD)	P8	101 (LHD)
D	7	100 (LHD)	J	5	99 (LHD)	U1	99 (LHD)
D8		100 (LHD)	J9		99 (LHD)	W4	101 (LHD)
D	9	100 (LHD)	J.	12	100 (LHD)		
D1	10	100 (LHD)	J-	13	100 (LHD)		

# : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1B	82 (LHD)	Front Door LH Wire and Driver Side J/B (Left Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
11	82 (LHD)	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)
1L	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2E		
2G	84 (LHD)	Instrument Benel Wire and Becommer Cide I/D (Bight Wiel, Benel)
2H		Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
21	7	
2K	84 (LHD)	Front Door RH Wire and Passenger Side J/B (Right Kick Panel)
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)

# : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
IB1	114 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)
IH3	116 (LHD)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
II1	116 (LHD)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
BA1	118 (LHD)	Rear Door No.2 Wire and Floor No.2 Wire (Left Center Pillar)
BB1	118 (LHD)	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)
BC1	118 (LHD)	Floor No.2 Wire and Floor Wire (Under the Right Rear Cushion)


# : GROUND POINTS


Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
ID	114 (LHD)	Cowl Side Panel LH
IG	114 (LHD)	Cowl Side Panel RH
ВК	118 (LHD)	Left Quarter Panel LH
BL	118 (LHD)	Front Floor Panel RH














# **POWER WINDOW (LHD)**

#### SYSTEM OUTLINE -

#### 1. AUTO OPERATION (DRIVER'S WINDOW)

When the power window master SW is operated to AUTO UP position with the ignition SW on, the current flows from the D FR P/W Fuse to power window master SW TERMINAL 1 to TERMINAL 8 to power window motor front LH TERMINAL 1 to TERMINAL 2 to power window master SW TERMINAL 20 to TERMINAL 9 to GROUND, and the motor rotates to close the window. The motor continues to rotate until the window is fully closed or the DOWN position of the power window master SW is operated.

When the power window master SW is operated to AUTO DOWN position with the ignition SW on, the current flows from the D FR P/W Fuse to power window master SW TERMINAL 1 to TERMINAL 20 to power window motor front LH TERMINAL 2 to TERMINAL 1 to power window master SW TERMINAL 8 to TERMINAL 9 to GROUND, and the motor rotates to open the window. The motor continues to rotate until the window is fully opened or the UP position of the power window master SW is operated.

## 2. MANUAL OPERATION (DRIVER'S WINDOW)

When the power window master SW is operated to UP position with the ignition SW on, the current flows from the D FR P/W Fuse to power window master SW TERMINAL 1 to TERMINAL 8 to power window motor front LH TERMINAL 1 to TERMINAL 2 to power window master SW TERMINAL 20 to TERMINAL 9 to GROUND, and the motor rotates to close the window.

When the power window master SW is operated to DOWN position with the ignition SW on, the current flows from the D FR P/W Fuse to power window master SW TERMINAL 1 to TERMINAL 20 to power window motor front LH TERMINAL 2 to TERMINAL 1 to power window master SW TERMINAL 8 to TERMINAL 9 to GROUND, and the motor rotates to open the window.

#### 3. MANUAL OPERATION (EXCEPT DRIVER'S WINDOW)

When the power window control SW front RH, rear LH, RH is operated to UP position, the current flows to the power window control SW TERMINAL PCT to TERMINAL U to power window motor to power window control SW TERMINAL D to TERMINAL E to GROUND, and the motor rotates to close the window.

When the power window control SW front RH, rear LH, RH is operated to DOWN position, the current flows to the power window control SW TERMINAL PCT to TERMINAL D to power window motor to power window control SW TERMINAL U to TERMINAL E to GROUND, and the motor rotates to open the window.

When controlling the respective windows with the power window master SW, a communication signal is input from the power window master TERMINAL TX to body ECU TERMINAL MPX3, and the current flows from the body ECU to respective power window control SW TERMINAL SU (UP operation), SD (DOWN operation), and the motor rotates in the controlled direction.

#### 4. KEY OFF POWER WINDOW OPERATION

After the ignition SW is turned off, the driver's side power window can be operated for approximately 45 seconds, unless the driver's side door or the front passenger side door is opened. However, if the key off operation time finishes during AUTO operation, the AUTO operation is stopped immediately.

#### 5. CATCHING PREVENTION FUNCTION

If any foreign matter is caught in the window while it is rising, the pulse sensor installed in the power window motor detects changes in the number of motor rotations, forcibly lowers the door window 50 mm or if the door window opening amount is 200 mm or less, the window is lowered so that the opening amount is 200 mm.

#### SERVICE HINTS

#### P5, P6, P7 POWER WINDOW CONTROL SW FRONT RH, REAR LH, RH

3-GROUND : Always continuity

4-GROUND : Approx. 12 volts with ignition SW at ON or ST position

#### **P8 POWER WINDOW MASTER SW**

9-GROUND : Always continuity

4-GROUND : Approx. 12 volts with ignition SW at ON or ST position

1-GROUND : Always approx. 12 volts

### ) : PARTS LOCATION

Co	ode	See Page	Co	de	See Page	Code	See Page
A14	Α	98 (LHD)	E2	Α	96 (LHD)	P6	101 (LHD)
A15	В	98 (LHD)	E3	В	96 (LHD)	P7	101 (LHD)
_B6	Α	98 (LHD)	J	5	99 (LHD)	P8	101 (LHD)
B7	В	98 (LHD)	J	9	99 (LHD)	P9	101 (LHD)
С	10	98 (LHD)	J.	13	100 (LHD)	P10	101 (LHD)
	)4	98 (LHD)	J.	16	100 (LHD)	P11	101 (LHD)
	)7	100 (LHD)	J <sup>-</sup>	17	100 (LHD)	P12	101 (LHD)
	)8	100 (LHD)	P	5	101 (LHD)		

#### : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)		
1B	82 (LHD)	Front Door LH Wire and Driver Side J/B (Left Kick Panel)		
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)		
1H	82 (LHD)	Instrument Panel Wire and Driver Cide I/D (Lett Viels Panel)		
1L	02 (LI10)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)		
2B	84 (LHD)	Engine Room Main Wire and Reseases Side I/D (Dight Viel Republ)		
2C	2C 04 (LID)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)		
2E				
2G	2G 84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)		
2H	1			
2K	84 (LHD)	Front Door RH Wire and Passenger Side J/B (Right Kick Panel)		
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)		


## : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)	
IB2	114 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)	
IC1	114 (LHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)	
IH3	116 (LHD)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)	
II1	116 (LHD)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)	
BA1	118 (LHD)	Rear Door No.2 Wire and Floor No.2 Wire (Left Center Pillar)	
BB1	118 (LHD)	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)	

## Figround Points

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
ID	114 (LHD)	Cowl Side Panel LH
IG	114 (LHD)	Cowl Side Panel RH
BK	118 (LHD)	Left Quarter Panel LH
BL	118 (LHD)	Front Floor Panel RH





# **SEAT BELT WARNING (LHD)**

#### - SYSTEM OUTLINE

#### **SEAT BELT WARNING SYSTEM**

When the ignition SW is turned to the ON position, the signal is input to the body ECU. At this time, to determine whether or not the driver fastens the seat belt, the signal from the buckle SW LH is input to TERMINAL DBKL of the body ECU. If the driver does not fasten the seat belt, the seat belt warning light in the combination meter flashes and the alarm buzzer goes on, in response to the communication control of the body ECU etc.

If the passenger does not fasten the seat belt, the signals from the buckle SW RH and seat belt warning occupant detection sensor are input to TERMINAL P-S/B of the A/C control assembly and through communication control of the body ECU etc. the passenger seat belt warning light in the A/C control assembly is flashed.

#### - SERVICE HINTS

#### **B8 BUCKLE SW LH**

1-2: Continuity with driver's seat belt in use

## B11 BUCKLE SW RH AND SEAT BELT WARNING OCCUPANT DETECTION SENSOR

1-2: Continuity with front passenger's seat belt in use

## **U1 UNLOCK WARNING SW**

1-2: Continuity with ignition key in cylinder

## : PARTS LOCATION

Cc	ode	See Page	Page Code Se		ge Cod		See Page
A14	Α	98 (LHD)	B8	102 (LHD)	E2	Α	96 (LHD)
A15	В	98 (LHD)	B11	100 (LHD)	E3	В	96 (LHD)
B6	Α	98 (LHD)	C10	98 (LHD)	J	5	99 (LHD)
B7	В	98 (LHD)	D4	98 (LHD)	J	9	99 (LHD)
E	38	100 (LHD)	D7	100 (LHD)	U	1	99 (LHD)

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)
1E 82 (LHD) Instrument Panel Wire and Driver Side J/B (Left Kick Panel)		Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	82 (LHD)	Instrument Panel Wire and Driver Side UP (Let Viel Panel)
1L	J OZ (LITD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
2B	2B 84 (LHD) Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)	
2E		
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2H		
21	<u></u>	·
2L 84 (LHD) Floor Wire and Passenger Side J/B (Right Kick Panel)		Floor Wire and Passenger Side J/B (Right Kick Panel)


#### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA3	IA3 114 (LHD) Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)	
IH3	116 (LHD)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
BE1	120 (LHD)	Floor No.2 Wire and Front Seat LH Wire (Under the Driver's Seat)

# : GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
ID	114 (LHD)	Cowl Side Panel LH
IG	114 (LHD)	Cowl Side Panel RH
IH	114 (LHD)	Front Floor Panel Center LH
BJ	118 (LHD)	Front Floor Panel LH
BL	118 (LHD)	Front Floor Panel RH





# **LIGHT REMINDER (LHD)**

#### - SYSTEM OUTLINE -

This system is provided to remind the driver to turn off the taillights and headlights.

#### LIGHT REMINDER OPERATION

In case the driver's side door is opened while the light control SW is at TAIL or HEAD with the ignition SW turned to off from on, through the communication control of the body ECU etc., the light reminder buzzer in the combination meter comes on.

## SERVICE HINTS

## **C14 COMBINATION SW**

14-GROUND : Continuity with light control SW at TAIL or HEAD position

#### **D7 DOOR COURTESY SW FRONT LH**

1-GROUND : Closed with door open

B7 (B) BODY ECU

6-GROUND : Continuity with driver door open

## : PARTS LOCATION

Co	ode	See Page	Code	See Page	Code		See Page	
A14	Α	98 (LHD)	C14	98 (LHD)	E3	В	96 (LHD)	
A15	В	98 (LHD)	D1	98 (LHD)	J	5	99 (LHD)	
B6	Α	98 (LHD)	D4	98 (LHD)	J	8	99 (LHD)	
B7	В	98 (LHD)	D7	100 (LHD)	J	9	99 (LHD)	
C10		98 (LHD)	E2 A	96 (LHD)				

#### : RELAY BLOCKS

ı	Code	See Page	Relay Blocks (Relay Block Location)
	1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)

# : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)		
1A				
1E	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)		
1F	1			
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)		
1H	82 (LHD)	Instrument Denel Mire and Driver Cide 1/D (Lett Kiel, Denel)		
1L	oz (LND)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)		
10	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)		
2B 84 (LHD) Engine Room Main Wire and Passenger Side J/B (F		Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)		
2E				
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)		
2H	]			
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)		


## : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)

## : GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
ID	114 (LHD)	Cowl Side Panel LH
IG	114 (LHD)	Cowl Side Panel RH
İH	114 (LHD)	Front Floor Panel Center LH
BL	118 (LHD)	Front Floor Panel RH

# **REMOTE CONTROL MIRROR (LHD)**



#### SERVICE HINTS -

## **R18 REMOTE CONTROL MIRROR SW**

9-6 : Continuity with the operation SW at **DOWN** or **RIGHT** position

6-10 : Continuity with the operation SW at **UP** or **LEFT** position

4-9, 3-10: Continuity with the retractor SW at **RETRACTION** position

3-9, 4-10: Continuity with the retractor SW at **RETURN** position

9-GROUND : Approx. 12 votls with the ignition SW at ACC or ON position

10-GROUND : Always continuity

## O : PARTS LOCATION

i	Code	See Page	Code	See Page	Code	See Page
	J5	99 (LHD)	R16	101 (LHD)	R18	101 (LHD)
1	J12	100 (LHD)	R17	101 (LHD)		

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)	
1B	82 (LHD)	Front Door LH Wire and Driver Side J/B (Left Kick Panel)	
1G	1G 82 (LHD) Engine Room Main Wire and Driver Side J/B (Left Kick Panel)		
1L	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)	

## : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	114 (LHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
II1	116 (LHD)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
IĞ	114 (LHD)	Cowl Side Panel RH

# **POWER SEAT**



## - SERVICE HINTS -

## P15 POWER SEAT CONTROL SW

1-GROUND : Always approx. **12** volts 4-GROUND : Always continuity

## O : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
P15	102 (LHD)	P17	102 (LHD)	Dio	102 (LHD)
	110 (RHD)	7	110 (RHD)	P19	110 (RHD)
P16	102 (LHD)	P18	102 (LHD)		
1 10	110 (RHD)	7 518	110 (RHD)		,

# : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)
1	82 (LHD)	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)
1L	88 (RHD)	Floor Wire and Driver Side J/B (Right Kick Panel)


## : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
BE1	120 (LHD)	Floor No.2 Wire and Front Seat LH Wire (Under the Driver's Seat)
	130 (RHD)	Floor Wire and Front Seat RH Wire (Under the Driver's Seat)


Code	See Page	Ground Points Location
BJ	118 (LHD)	Front Floor Panel LH
BL	128 (RHD)	Front Floor Panel RH

# **ECT AND A/T INDICATOR**









## **ECT AND A/T INDICATOR**

#### SYSTEM OUTLINE -

Previous automatic transmissions have selected each gear shift using mechanically controlled throttle hydraulic pressure, governor hydraulic pressure and lock-up hydraulic pressure. The electronically controlled transmission, however, electrically controls the line pressure, throttle pressure, lock-up pressure and accumulator pressure etc. through the solenoid valve. The ECT is a system which precisely controls gear shift timing and lock-up timing in response to the vehicle's driving conditions and the engine condition detected by various sensors. It makes smooth driving possible by shift selection for each gear which is the most appropriate to the driving conditions at that time, and by preventing downing, squat and gear shift shock when starting off.

#### 1. GEAR SHIFT OPERATION

When driving, the engine warm up condition is input as a signal to TERMINAL THW of the engine and ECT ECU from the water temp. sensor and the vehicle speed signal from speed sensor (Transmission Output) is input to TERMINAL SP2+ of the engine and ECT ECU. At the same time, the throttle valve opening signal from the throttle position sensor is input to TERMINALS VTA and VTA2 of the engine and ECT ECU as throttle angle signal.

Based on these signals, the engine and ECT ECU selects the best shift position for the driving conditions and sends current to the ECT solenoid.

#### 2. LOCK-UP OPERATION

When the engine and ECT ECU decides based on each signal that the lock-up condition has been met, the current flows through TERMINAL SLU+ of the engine and ECT ECU to TERMINAL 3 of the ECT solenoid to TERMINAL 7 to TERMINAL SLU- of the engine and ECT ECU to GROUND.

#### 3. STOP LIGHT SW CIRCUIT

If the brake pedal is depressed (Stop light SW on) when driving in lock-up condition, a signal is input to TERMINAL STP of the engine and ECT ECU. The engine and ECT ECU operates and cuts the current to the solenoid to release lock-up.

## 4. ECT PATTERN SELECT SW CIRCUIT

When the ECT pattern select SW is switched to PWR, a signal is input to TERMINAL PWR of the A/C control assembly, and control signals are distributed to the engine and ECT ECU through communication control of the A/C control assembly. This enables shift-up and shift-down at a higher speed range.

#### SERVICE HINTS -

#### **E1 ECT SOLENOID**

9-15: **5.1-5.5**  $\Omega$ 

 $3-7: 5.1-5.5 \Omega$ 

4, 8-GROUND : 11-15 Ω

#### **E10 ECT PATTERN SELECT SW**

2-4 : Closed with select SW at PWR position

5-4 : Only closed with select SW at **SNOW** position

## S2 SPEED SENSOR (TRANSMISSION INPUT)

1-2: **560-680**  $\Omega$ 

## S3 SPEED SENSOR (TRANSMISSION OUTPUT)

1–2 : **560–680**  $\Omega$ 

#### E2 (A), E3 (B), E4 (C), E5 (D), E6 (E) ENGINE AND ECT ECU

BATT-E1: Always approx. 12 volts

B-E1: Approx. 12 volts with ignition SW ON or ST position B2-E1 : Approx. 12 volts with ignition SW ON or ST position MREL-E1: Approx. 12 volts with ignition SW ON or ST position

STA-E1: Approx. 12 volts with ignition SW ST position and shift lever other than P or N position

## N1 A/T INDICATOR LIGHT SW [NEUTRAL START SW]

3-1: Closed with shift lever in P position

3-2: Closed with shift lever in R position

3-5: Closed with shift lever in N position

3-7: Closed with shift lever in **D** position or **3** position

3-4 : Closed with shift lever in 2 position

3-8: Closed with shift lever in L position

## : PARTS LOCATION

Code		See Page	Co	ode	See Page	Code	See Page
A9		96 (LHD)	- E4	С	96 (LHD)	144	99 (LHD)
		104 (RHD)	] =4	"	104 (RHD)	J11	107 (RHD)
A14	А	98 (LHD)		D	96 (LHD)	J16	100 (LHD)
		106 (RHD)	- E5	"	104 (RHD)	J17	100 (LHD)
A15	В	98 (LHD)	E6	Е	96 (LHD)	КЗ	99 (LHD)
		106 (RHD)		-	104 (RHD)	A14	97 (LHD)
В6	A	98 (LHD)		10	99 (LHD)	N1	105 (RHD)
		106 (RHD)	]	10	107 (RHD)	00	97 (LHD)
(	23	96 (LHD)	l13		97 (LHD)	S2	105 (RHD)
		104 (RHD)	] ''	J	105 (RHD)		97 (LHD)
C	10	98 (LHD)	J <sub>1</sub>	Α	97 (LHD)	S3	105 (RHD)
		106 (RHD)	] "'	В	105 (RHD)	00	99 (LHD)
D	)2	106 (RHD)	J2	А	97 (LHD)	- S8	107 (RHD)
Г	)4	98 (LHD)	] "		105 (RHD)	C44	99 (LHD)
		106 (RHD)	J3	В	97 (LHD)	S11	107 (RHD)
Е	:1	96 (LHD)	] "		105 (RHD)	TO	97 (LHD)
		104 (RHD)		1	97 (LHD)	T2	105 (RHD)
E2	Α	96 (LHD)	] '	7	105 (RHD)	T5	107 (RHD)
		104 (RHD)	J	5	107 (RHD)	14/0	97 (LHD)
E3	В	96 (LHD)	J	7	99 (LHD)	- W2	105 (RHD)
_0		104 (RHD)	]	′	107 (RHD)		

### : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
<u> </u>	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)
2	80 (LHD)	Engine Room No.2 R/B (Engine Compartment Right)
	81 (RHD)	Engine Room No.2 R/B (Engine Compartment Left)

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)			
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)			
1E	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)			
	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)			
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)			
	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)			
1H	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)			
1K	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)			
2A	84 (LHD)	Engine Room Main Wire and Researces Side VR (Disht Viel Bersel)			
2B	04 (EI 1D)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)			
2E	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)			
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)			
2F	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)			
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)			
2H	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)			
21	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)			
2K	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)			
	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)			
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)			
2N	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)			

# **ECT AND A/T INDICATOR**

# : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)		
EA1	112 (LHD)	Engine Wire and Engine Room Main Wire (Inside of the ECU Box)		
	122 (RHD)	Linguise while and Engine Room Main White (miside of the ECO Box)		
IA2	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)		
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)		
1/1/3	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)		
IB1	114 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)		
IE1	116 (LHD)	Floor No.3 Wire and Floor No.2 Wire (Near the Steering Column)		
IF1	126 (RHD)	Instrument Panel No.3 Wire and Instrument Panel Wire (Right Side of the Instrument Panel)		


# : GROUND POINTS


Code	See Page	Ground Points Location				
EA	112 (LHD)	Front Side of Cylinder Head				
	122 (RHD)	Tront Side of Cylinder Flead				
EB	112 (LHD)	Rear Side of Cylinder Head				
	122 (RHD)	Hear Side of Cyllinder Head				
EC	112 (LHD)	oft Fender Apron				
	122 (RHD)	Lett Ferider Aprofi				
ID	114 (LHD)	Cowl Side Panel LH				
	124 (RHD)	COWI SIDE PAILEI LIT				
IH	114 (LHD)	Front Floor Panel Center LH				
	124 (RHD)	Front Floor Panel Center RH				
BJ	128 (RHD)	Front Floor Panel LH				
ВК	118 (LHD)	Left Quarter Panel LH				
BL	118 (LHD)	Front Floor Panel RH				


# : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points	
<b>E</b> 7	112 (LHD)		E8	122 (RHD)	Engine Wire	
L/	122 (RHD)	Engine Wire	E9	112 (LHD)	- Engine wire	
E8	112 (LHD)	1	_ E9	122 (RHD)	Engine Room Main Wire	

# **CRUISE CONTROL**







#### SYSTEM OUTLINE

The cruise control system allows the driver to control the vehicle speed at a constant speed, such as on a high way, without depressing the accelerator pedal. By operating the SW, the engine throttle valve is automatically adjusted to control the vehicle speed at a constant speed.

#### 1. SET OPERATION

The actual vehicle speed is compared with the memorized vehicle speed, and when the actual vehicle speed is faster than the memorized speed, a signal is output to rotate the electronic throttle motor to close the throttle valve. When the actual vehicle speed is slower than the memorized speed, a signal is output to rotate the electronic throttle motor to open the throttle valve.

#### 2. SET SPEED CONTROL

While traveling (within the set speed limit) with the main SW on (power indicator on), the speed when the SET/COAST SW is operated to off is memorized and the vehicle is controlled at that speed.

#### 3. COAST CONTROL

When the SET/COAST SW is operated to on during cruise control driving, the cruise control opening angle requirement is controlled to 0 to decrease the vehicle speed (however the throttle valve itself is not fully closed due to ISC etc.), and the speed when the SW is operated to off is memorized, and the vehicle is controlled at that speed. Furthermore, every time the SET/COAST SW is operated to on momentarily (approximately 0.5 seconds), the memorized vehicle speed is decreased by approximately 1.5km/h.In case of tap down operation where the difference between the memorized vehicle speed and the actual vehicle speed is more than 5km/h, the speed when the SW is operated to off is memorized, and the vehicle is controlled at that speed.

#### 4. ACCEL CONTROL

When the RESUME/ACCEL SW is operated to on during cruise control driving, the electronic throttle motor is rotated so that the throttle valve opens to increase the vehicle speed, and the speed when the SW is operated to off is memorized, and the vehicle is controlled at that speed.

Furthermore, every time the RESUME/ACCEL SW is operated to on momentarily (approximately 0.5 seconds), the memorized vehicle speed is increased by approximately 1.5km/h.

In case of tap up operation where the difference between the memorized vehicle speed and the actual vehicle speed is more than 5km/h, the memorized speed will not be changed.

#### 5. MANUAL CANCEL MECHANISM

If any of the following signals are input during cruise control driving, the current to the motor flows in the direction to close the throttle valve, and the cruise control is canceled. (Vehicle speed memory will not be not erased)

- \* Stop light SW is on (Brake pedal is depressed)
- \* D position circuit in the neutral start SW is turned from on to off

(Shift position is changed from D to N, 2, or 1)

- \* The CANCEL SW of the control SW is on
- \* The main SW is off (Vehicle speed memory will be erased)

#### 6. RESUME CONTROL

After canceling the cruise control (except when the main SW is off) if the vehicle speed is above the minimum speed limit (approximately 40km/h, 25mph) operating the RESUME/ACCEL SW from off to on will cause the system to accelerate to resume the vehicle speed before manual cancellation.

#### 7. OVERDRIVE CONTROL FUNCTION

During cruise control driving, the overdrive may be cut on an uphill grade.

After the overdrive is cut, if the vehicle speed reaches the overdrive resume speed (set speed minus 2km/h), and if the system determines that the uphill grade has finished, the overdrive will resume after overdrive resume timer operation. However, if the actual vehicle speed becomes slower than the overdrive resume speed before the timer operation has finished, the timer will be reset, and will start again when the vehicle speed reaches the overdrive resume speed.

# **CRUISE CONTROL**

#### 8. AUTO CANCEL OPERATION

(1) If any of the following conditions are detected, the set speed is erased and the control is canceled.

At this time, the power indicator will blink, and control of the system will be prohibited until the main SW is turned on again.

- \* Disconnection and/or short in the stop light SW
- \* Failure in the vehicle speed signal
- \* Failure in the electronic throttle parts

(2) If any of the following conditions are detected, the set speed is erased and the control is canceled.

At this time, the power indicator will blink, and control of the system will be prohibited until the ignition SW is turned off.

- \* Failure in the stop light SW input circuit
- \* Failure in the cancel circuit
- (3) If any of the following conditions are detected, the set speed is erased and the control is canceled. (Reset is possible)
- \* The actual speed becomes slower than the minimum speed limit.
- \* The actual speed becomes -16km/h slower than the set speed.

### - SERVICE HINTS

### E2 (A), E3 (B), E4 (C), E5 (D), E6 (E) ENGINE AND ECT ECU

(A) 9-GROUND : Approx. 12 volts with ignition SW at ON or ST position

(A) 1-GROUND: Always approx. 12 volts

(A) 22, (D)17, (E) 9, (E)21, (E)29, (E)31-GROUND: Always continuity

(B) 6-GROUND : Approx. 12 volts with stop light SW at on

(B)22-GROUND: Continuity with cruise control main SW at on

Approx. **1540**  $\Omega$  with CANCEL SW on in cruise control SW Approx. **240**  $\Omega$  with RES/ACC SW on in cruise control SW Approx. **630**  $\Omega$  with SET/COAST SW on in cruise control SW

#### C13 CRUISE CONTROL SW [COMB. SW]

5–4 : Approx. 1540  $\Omega$  with CANCEL SW on Approx. 240  $\Omega$  with RES/ACC SW on Approx. 630  $\Omega$  with SET/COAST SW on

## : PARTS LOCATION

Co	de	See Page	Co	de	See Page	Code	See Page
Δ	.9	96 (LHD)	E4	С	96 (LHD)	J9	99 (LHD)
		104 (RHD)	]		104 (RHD)	] 39	107 (RHD)
A14	A	98 (LHD)	E5	D	96 (LHD)	N1	97 (LHD)
	, ,	106 (RHD)			104 (RHD)	] '''	105 (RHD)
A15	В	98 (LHD)	- E6	Е	96 (LHD)	S2	97 (LHD)
7110		106 (RHD)	] [	_	104 (RHD)	1 52	105 (RHD)
В6	A	98 (LHD)		Α	97 (LHD)	- S3	97 (LHD)
		106 (RHD)	j <sub>1</sub>	^	105 (RHD)	53	105 (RHD)
С	10	98 (LHD)	] "	В	97 (LHD)	S11	99 (LHD)
		106 (RHD)	<u> </u>		105 (RHD)		107 (RHD)
C	13	98 (LHD)	J2	А	97 (LHD)	T1	97 (LHD)
		106 (RHD)	] ]2		105 (RHD)		105 (RHD)
D	2	106 (RHD)	- J3	В	97 (LHD)	To	97 (LHD)
E2	Α	96 (LHD)	] "	В	105 (RHD)	T2	105 (RHD)
		104 (RHD)	J	1	97 (LHD)	T5	107 (RHD)
E3	В	96 (LHD)		7	105 (RHD)		
		104 (RHD)	J	5	107 (RHD)		

## : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
<u> </u>	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)
,	80 (LHD)	Engine Room No.2 R/B (Engine Compartment Right)
	81 (RHD)	Engine Room No.2 R/B (Engine Compartment Left)

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1E	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1H	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1K	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2A	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Front Door LH Wire and Passenger Side J/B (Left Kick Panel)
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2H	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
21	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2K	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2N	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)

#### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
IAS	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
IF1	126 (RHD)	Instrument Panel No.3 Wire and Instrument Panel Wire (Right Side of the Instrument Panel)


## : GROUND POINTS


Code	See Page	Ground Points Location
EA	112 (LHD)	Front Side of Cylinder Head
	122 (RHD)	Tront Side of Cylinder Head
EB	112 (LHD)	Rear Side of Cylinder Head
LD	122 (RHD)	Hear Side of Cylinder Head
EC	112 (LHD)	Left Fender Apron
	122 (RHD)	Lett Perider Aproli
ID	114 (LHD)	Cowl Side Panel LH
I.U	124 (RHD)	- Cowi Side Fallei En
IH	114 (LHD)	Front Floor Panel Center LH
11.1	124 (RHD)	Front Floor Panel Center RH
BJ	128 (RHD)	Front Floor Panel LH
BL	118 (LHD)	Front Floor Panel RH


# : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points	
<b>E</b> 7	112 (LHD)	Engine Wire	F0	112 (LHD)	E Mr.	
	122 (RHD)	Trigine valle	E8	122 (RHD)	- Engine Wire	









## **ABS AND TRACTION CONTROL**

#### - SYSTEM OUTLINE

(ABS)

ABS is a brake system designed for the purpose to improve the operating ability securing the stability of the vehicle by preventing the looking-up of the vehicle controlling the wheel cylinder pressure of all the four wheels at the time of sudden braking.

#### 1. INPUT SIGNALS

(1) Speed sensor signal

The speed of the wheels is detected and input to TERMINALS FL+, FR+, RL+ and RR+ of the ABS and traction ECU.

(2) Stop light SW signal

A signal is input to TERMINAL STP of the ABS and traction ECU when brake pedal is depressed.

#### 2. SYSTEM OPERATION

When the wheels are to be locked-up, the solenoid inside the actuator will be controlled by the signal from the ABS and traction ECU and the brake fluid in the wheel cylinder will flow through the reservoir and reduce the hydraulic pressure.

While the ABS is in operation, as the ABS and traction ECU always outputs the operation signal to the pump inside the actuator, brake fluid stored inside the reservoir will be suctioned up by the pump inside the actuator and returned to the master cylinder.

When the hydraulic pressure of the wheel cylinder is decompressed or increased until the necessary hydraulic pressure, the solenoid inside the actuator is controlled by the control signal from the ABS and traction ECU and as a result, hydraulic pressure of the wheel cylinder will be closed at both routes of the master cylinder and reservoir sides and the hydraulic pressure of the wheel cylinder will become to be in the holding condition.

If the increase of hydraulic pressure volume of the wheel cylinder becomes necessary, with the control signal from the ABS and traction ECU, the solenoid inside the actuator will be controlled and become the same condition as usual and the brake fluid of the master cylinder will be sent to the wheel cylinder and will increase the hydraulic pressure of the wheel cylinder. At this time, in the case that the brake fluid stays left in the reservoir, it will be sucked up by the pump inside the actuator and will be sent to the wheel cylinder.

Also, increasing speed of the hydraulic pressure is controlled by outputting the increasing and the said holding one after another.

(Traction control)

Traction control system is designed to perform the engine output control by the fuel cut and hydraulic pressure control of driving wheel brake and control the spinning of the driving wheels. By doing this, it improves starting acceleration and operating ability of the vehicle securing the driving ability in accordance with the road surface condition.

#### 3. TRACTION CONTROL OPERATION

Estimating the vehicle speed from the rear wheel speed, comparing it with the front, driving wheel speed and judging the grip condition of the driving wheels. From the estimated vehicle speed, target speed of the driving speed will be set. When the front, driving wheel speed exceeds the control starting speed, it judges that the tire slip is occurred and performs the fuel cut cylinder number control and brake control and then adjust to make the front wheel speed become the traction control target speed. Controlling of the traction control will be completed when the vehicle move on to the road where the driving wheels will not have a tire slip or when the driver decelerate.

### SERVICE HINTS

## A20 (A), A21 (B), A22 (C), A23(D) ABS AND TRACTION ECU

IG1-GROUND: 10-14 volts with the ignition SW at ON position

R+ -SR: 9-14 volts with the ignition SW at ON position and the ABS warning light off

R+ -MR: 0-1 volts with the ignition SW at ON position

WA-GROUND: **0-2** volts with the ignition SW at **ON** position and the ABS warning light on : **10-14** volts with the ignition SW at **ON** position and the ABS warning light off

STP-GROUND: 0-1.5 volts with the stop light SW off: 8-14 volts with the stop light SW on

D/G-GROUND: 10-14 volts with the ignition SW at ON position and the ABS warning light on

MT-GROUND: 0-1.5 volts with the ignition SW at ON position

NEO-GROUND: Pules generation with idling

IND-GROUND: 0-2 volts with the ignition SW at ON position and the TRAC indicator light on

: 10-14 volts with the ignition SW at ON position and the TRAC indicator light off

WT-GROUND: **0-2** volts with the ignition SW at **ON** position and the TRAC OFF indicator light on : **10-14** volts with the ignition SW at **ON** position and the TRAC OFF indicator light off

CSW-GROUND : 0-1.5 volts with the ignition SW at ON position and the traction cut SW pushed

: 8-14 volts with the ignition SW at ON position and the traction cut SW released

TC, TS-GROUND: 8-14 volts with the ignition SW at ON position

TRC+, TRC- -GROUND : Pules generation with the traction control active

ENG+, ENG- -GROUND : Pules generation with the ignition SW at **ON** position

SRLH, SRLR, AST-GROUND: 10-14 volts with the ignition SW at **ON** position and warning light off SFLH, SRRR, SRRH-GROUND: 10-14 volts with the ignition SW at **ON** position and warning light off

SFRR, SFRH, SFLR-GROUND: 10-14 volts with the ignition SW at ON position and warning light off

SRC, SMC, SPC-GROUND : 10-14 Volts with the ignition SW at ON position and the TRAC OFF indicator light off

#### S11 STOP LIGHT SW

2-1: Closed with the brake pedal depressed

## A7, A8 ABS SPEED SENSOR FRONT LH, RH

1-2 : **1.6**-**1.8** kΩ (**20**°C)

#### A32, A33 ABS SPEED SENSOR REAR LH, RH

1-2 : **0.9**-**1.3** kΩ (**20**°C)

#### : PARTS LOCATION

Co	ode	See Page	Co	ode	See Page	Co	de	See Page
A5	Α	96 (LHD)	A23	D	98 (LHD)	E2		96 (LHD)
		104 (RHD)			106 (RHD)	] 🗠	A	104 (RHD)
A6	В	96 (LHD)		32	100 (LHD)	E3	В	96 (LHD)
		104 (RHD)		JZ	108 (RHD)	] =3		104 (RHD)
Δ	.7	96 (LHD)	Δ.	 33	100 (LHD)	J	1	97 (LHD)
	.,	104 (RHD)			108 (RHD)		<u> </u>	99 (LHD)
<b> </b>	.8	96 (LHD)		12	96 (LHD)	J5		107 (RHD)
		104 (RHD)		12	104 (RHD)	J7		99 (LHD)
	14	98 (LHD)		3	96 (LHD)	]	1	107 (RHD)
		106 (RHD)		,,	104 (RHD)		11	99 (LHD)
A20	Α	98 (LHD)	C10	A	98 (LHD)	]	11	107 (RHD)
/		106 (RHD)	0.0	_ ^_	106 (RHD)		A	99 (LHD)
A21	В	98 (LHD)	C11	В	98 (LHD)	T6	^	107 (RHD)
		106 (RHD)			106 (RHD)	1 '8	В	99 (LHD)
A22	С	98 (LHD)		)4	98 (LHD)	1		107 (RHD)
,		106 (RHD)		·Ŧ	106 (RHD)			

#### : RELAY BLOCKS

Г	O	00	
L	Code	See Page	Relay Blocks (Relay Block Location)
ſ	1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
L		81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)
ſ	2	80 (LHD)	Engine Room No.2 R/B (Engine Compartment Right)
ł		81 (RHD)	Engine Room No.2 R/B (Engine Compartment Left)

## **ABS AND TRACTION CONTROL**

# $\bigcirc$

#### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Plack and Wire Harmon (Connector Location)
Code		Junction Block and Wire Harness (Connector Location)
1E	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1F	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1G	88 (RHD)	Instrument Penel Mire and Driver Cide 1/D (Direkt Viel Denel)
1H	00 (11110)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1K	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
. 1L	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
2A	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2D	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2E	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2F	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2H	90 (RHD)	Instrument Penel Wire and December Cide I/D (Left Kiels December)
2L	ן אַס (חודט)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2N	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)				
IA2	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)				
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)				
1/10	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)				
IB1	114 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)				
IF1	126 (RHD)	Instrument Panel No.3 Wire and Instrument Panel Wire (Right Side of the Instrument Panel)				
IG1	116 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)				
	126 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)				
IH3	116 (LHD)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)				
11 10	126 (RHD)	Instrument Panel Wire and Floor Wire (Near the Driver Side J/B)				
BC1	128 (RHD)	Floor No.2 Wire and Floor Wire (Under the Right Rear Cushion)				

# $\nabla$

## : GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
	122 (RHD)	Lett Ferider Aproli
ID	114 (LHD)	Cowl Side Panel LH
	124 (RHD)	Oowi Side Pariei Ln
IF	124 (RHD)	Cowl Side Panel RH
IG	114 (LHD)	Cowi Side Pariei Hn
iH.	114 (LHD)	Front Floor Panel Center LH
	124 (RHD)	Front Floor Panel Center RH




#### : SPLICE POINTS


Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
14	126 (RHD)	Engine Room Main Wire			

SRS

NOTICE: When inspecting or repairing the SRS, perform the operation in accordance with the following precautionary instructions and the procedure and precautions in the Repair Manual for the applicable model year.

- Malfunction symptoms of the SRS are difficult to confirm, so the DTCs become the most important source of information when troubleshooting. When troubleshooting the SRS, always inspect the DTCs before disconnecting the battery.
- Work must be started after 90 seconds from when the ignition switch is turned to the "LOCK" position and the negative (-) terminal cable is disconnected from the battery.
   (The SRS is equipped with a back-up power source so that if work is started within 90 seconds from disconnecting the negative (-) terminal cable of the battery, the SRS may be deployed.)
- When the negative (-) terminal cable is disconnected from the battery, the memory of the clock and audio system will be canceled. So before starting work, make a record of the contents memorized in the audio memory system. When work is finished, reset the audio systems as they were before and adjust the clock. To avoid erasing the memory in each memory system, never use a back-up power supply from outside the vehicle.
- Before repairs, remove the airbag sensor if shocks are likely to be applied to the sensor during repairs.
- Do not expose the steering wheel pad, front passenger airbag assembly, side airbag assembly, seat belt pretensioner, airbag sensor assembly, front airbag sensor or side airbag sensor assembly directly to hot air or flames.
- Even in cases of a minor collision where the SRS does not deploy, the steering wheel pad, front passenger airbag assembly, side airbag assembly, seat belt pretensioner, airbag sensor assembly, front airbag sensor and side airbag sensor assembly should be inspected.
- Never use SRS parts from another vehicle. When replacing parts, replace them with new parts.
- Never disassemble and repair the steering wheel pad, front passenger airbag assembly, side airbag assembly, seat belt pretensioner or airbag sensor assembly in order to reuse it.
- If the steering wheel pad, front passenger airbag assembly, side airbag assembly, seat belt pretensioner, airbag sensor assembly, front airbag sensor or side airbag sensor assembly has been dropped, or if there are cracks, dents or other defects in the case, bracket or connector, replace them with new ones.
- Use a volt/ohmmeter with high impedance (10 kΩ/V minimum) for troubleshooting the system's electrical circuits.
- Information labels are attached to the periphery of the SRS components. Follow the instructions on the notices.
- After work on the SRS is completed, perform the SRS warning light check or SRS side airbag warning light check.
- If the vehicle is equipped with a mobile communication system, refer to the precaution in the IN section of the Repair Manual.





## - SYSTEM OUTLINE -

The SRS is a driver and front passenger protection device which has a supplemental role to the seat belts.

When the ignition SW is turned to ACC or ON, the current from the SRS-ACC fuse flows to TERMINAL (B) 6 of the center airbag sensor assembly. Only when the ignition SW is on does the current flow from the IGN fuse to TERMINAL (B) 5 of the center airbag sensor assembly.

If an accident occurs while driving, when the frontal impact exceeds a set level, the current from the SRS-ACC or IGN fuse flows to TERMINALS (B) 14, (B) 10, (C) 5 and (A) 2 of the center airbag sensor assembly to TERMINAL 1 of the airbag squibs and the pretensioners to TERMINAL 2 to TERMINALS (B) 13, (B) 11, (C) 6 and (A) 1 of the center airbag sensor assembly to TERMINAL (B) 27, (B) 28 or BODY GROUND to GROUND, so that current flows to the airbag squibs and the pretensioners and causes them to operate.

When the side impact also exceeds a set level, the current from the SRS-ACC or IGN fuse flows to TERMINALS (C) 2, (A) 5, (C) 5 and (A) 2 of the center airbag sensor assembly to TERMINAL 1 of the side airbag squibs and the pretensioners to TERMINAL 2 to TERMINALS (C) 1, (A) 6, (C) 6 and (A) 1 of the center airbag sensor assembly to TERMINAL (B) 27, (B) 28 or BODY GROUND to GROUND, causing side airbag squibs and the pretensioners to operate.

The airbag stored inside the steering wheel pad is instantaneously expanded to soften the shock to the driver.

The airbag stored inside the front passenger's instrument panel is instantaneously expanded to soften the shock to the front passenger.

Side airbags are instantaneously expanded to soften the shock of side to the driver and front passenger.

The pretensioners make sure of the seat belt restrainability.

## : PARTS LOCATION

C	ode	See Page	Co	ode	See Page	Code	See Page
Δ	.10	96 (LHD)	C6	В	98 (LHD)	P13	109 (RHD)
		104 (RHD)			106 (RHD)	D44	101 (LHD)
Δ	.11	96 (LHD)	C7	С	98 (LHD)	P14	109 (RHD)
	\	104 (RHD)			106 (RHD)	044	101 (LHD)
Δ	.27	98 (LHD)		10	98 (LHD)	S14	109 (RHD)
		106 (RHD)		10	106 (RHD)	015	101 (LHD)
Δ	28	98 (LHD)		)4	98 (LHD)	S15	109 (RHD)
		106 (RHD)		<b>/</b> 4	106 (RHD)	616	101 (LHD)
c	23	96 (LHD)	Ĵ	1	97 (LHD)	S16	109 (RHD)
		104 (RHD)		5	99 (LHD)	047	101 (LHD)
C5	Α	98 (LHD)		J	107 (RHD)	S17	109 (RHD)
	_^	106 (RHD)	P	13	101 (LHD)		

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)				
1B	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)				
1G	82 (LHD)	ngine Room Main Wire and Driver Side J/B (Left Kick Panel)				
1H	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)				
	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)				
1J	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)				
10	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)				
2A	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)				
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)				
2B	84 (LHD)					
2E	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)				
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)				
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)				
	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)				
2H	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)				
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)				
21	90 (RHD) Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)					
2J	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)				
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)				
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)				
2N	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)				

## : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)			
IA1	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)			
	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)			

V			
Code	See Page	Ground Points Location	
EC	112 (LHD)	Left Fender Apron	
	122 (RHD)	Leit Felider Aproli	
ID	114 (LHD)	Cowl Side Panel LH	
ID	124 (RHD)	- Cowi Side Fallei Ln	
IF	124 (RHD)	Cowl Side Panel RH	
IG	114 (LHD)	- Cowi Side Fallei Nn	
BJ	128 (RHD)	Front Floor Panel LH	
BL	118 (LHD)	Front Floor Panel RH	
	128 (RHD)		

# **CIGARETTE LIGHTER**



SERVICE HINTS

## **C8 CIGARETTE LIGHTER**

2-GROUND : Approx. 12 volts with ignition SW at ACC or ON position

1-GROUND : Always continuity


# O : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C8	98 (LHD)	J5	99 (LHD)		
	106 (RHD)				

# : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
16	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1L	88 (RHD)	Floor Wire and Driver Side J/B (Right Kick Panel)

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
IG	114 (LHD)	Cowl Side Panel RH
BL	128 (RHD)	Front Floor Panel RH



SERVICE HINTS

# A14 CLOCK [A/C CONTROL ASSEMBLY]

5-GROUND: Always approx. 12 volts (Power for clock)
4-GROUND: Approx. 12 volts with ignition SW at ACC or ON position (Power for indication)

14-GROUND : Always continuity

# O : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A14	98 (LHD)	J6	99 (LHD)	J7	99 (LHD)
	106 (RHD)		107 (RHD)		107 (RHD)

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	ee Page Junction Block and Wire Harness (Connector Location)			
1A	82 (LHD)	.HD) Instrument Panel Wire and Driver Side J/B (Left Kick Panel)			
11	88 (RHD) Instrument Panel Wire and Driver Side J/B (Right Kick Panel)				
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)			
2F	84 (LHD)	D) Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)			
21	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)	·		
21	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)			
2L	90 (RHD) Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)				

Code	See Page	Ground Points Location
ĪD	114 (LHD)	Cowl Side Panel LH
BJ	128 (RHD)	Front Floor Panel LH

FROM POWER SOURCE SYSTEM (SEE PAGE 140, 144) C13 HORN SW [COMB. SW]

## SERVICE HINTS

## **HORN RELAY**

5-3 : Closed horn SW on

# : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C13	98 (LHD)	H11	105 (RHD)	J11	107 (RHD)
010	106 (RHD)	H12	97 (LHD)		
H11	97 (LHD)	1112	105 (RHD)		


# : RELAY BLOCKS


Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
'	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)
2	80 (LHD)	Engine Room No.2 R/B (Engine Compartment Right)
	81 (RHD)	Engine Room No.2 R/B (Engine Compartment Left)

# : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
IA3	124 (RHD)	Instrument Penel Wire and Engine Pener Main Wire (Nearth - Peners City UP)	
IG1	116 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)	

\* 3 : LHD W/ DAYTIME RUNNING LIGHT \* 4 : LHD W/O DAYTIME RUNNING LIGHT





# **HEADLIGHT CLEANER**

## SERVICE HINTS

## H3 HEADLIGHT CLEANER CONTROL RELAY

5-2: Closed with ignition SW at ON position, light control SW at HEAD position and headlight cleaner SW on

# O : PARTS LOCATION

Code		See Page	Code	See Page	Code	See Page
C14	Α	98 (LHD)	H4	105 (RHD)	—— J11 ⊢	99 (LHD)
	^	106 (RHD)	H14 99 (LHD)	99 (LHD)		107 (RHD)
017	В	98 (LHD)	114	107 (RHD)	D7	99 (LHD)
		106 (RHD)		99 (LHD)	R7	107 (RHD)
НЗ		97 (LHD)		107 (RHD)	T4	107 (RHD)
	i O	105 (RHD)	J9	99 (LHD)		
H4		97 (LHD)		107 (RHD)		

# : RELAY BLOCKS

L	Code	See Page	Relay Blocks (Relay Block Location)			
ı	1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)			
L		81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)			

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1B	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1F	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
2F	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)

## : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

	Code	See Page	oining Wire Harness and Wire Harness (Connector Location)			
	IA2	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)			
Į		124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)			


## : GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
	122 (RHD)	Leit Felider Aproli
ID	124 (RHD)	Cowl Side Panel LH
lF.	124 (RHD)	Cowl Side Panel RH
IG	114 (LHD)	- Cowi Side Fallei Nn

# : SPLICE POINTS

	Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
L	E9	122 (RHD)	Engine Room Main Wire	E11	112 (LHD)	Engine Room Main Wire

# **HEADLIGHT BEAM LEVEL CONTROL**



#### SERVICE HINTS -

## H1, H2 HEADLIGHT BEAM LEVEL CONTROL ACTUATOR LH, RH

3-GROUND : Approx. 12 volts with light control SW at HEAD position or dimmer SW at FLASH position

1-GROUND : Always continuity

## O : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
H1	97 (LHD)	H13	99 (LHD)	- 10	99 (LHD)
	105 (RHD)		107 (RHD)	J9	107 (RHD)
H2	97 (LHD)	J1	105 (RHD)		
	105 (RHD)	J5	107 (RHD)		

## : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)			
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)			
	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)			

# : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2H	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)


## : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)			
IA2	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)			
	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)			

Code	See Page	Ground Points Location	
EC	112 (LHD)	Left Fender Apron	
	122 (RHD)	Lett ender Aproli	
ID	114 (LHD)	Cowl Side Panel LH	
	124 (RHD)	JOWN SIDE FAITELET	
IF	124 (RHD)	Cowl Side Panel RH	

**SEAT HEATER** 

\* 1 : W/ POWER SEAT \* 2 : W/O POWER SEAT



## SERVICE HINTS -

# S6, S7 SEAT HEATER SW (DRIVER'S SEAT, PASSENGER'S SEAT)

3-GROUND : Approx. 12 volts with ignition SW at ON or ST position

2-GROUND : Always continuity

# : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
J7	99 (LHD)	S7	99 (LHD)	040	109 (RHD)
	107 (RHD)	3/	107 (RHD)	S12	110 (RHD)
S6	99 (LHD)	S12	101 (LHD)	040	101 (LHD)
	107 (RHD)	312	102 (LHD)	— S13	109 (RHD)

# : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)
11	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1L	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2F	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
21	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)

## : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB2	114 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)
	124 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)
IH3	116 (LHD)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
	126 (RHD)	Instrument Panel Wire and Floor Wire (Near the Driver Side J/B)
BE1	120 (LHD)	Floor No.2 Wire and Front Seat LH Wire (Under the Driver's Seat)
	130 (RHD)	Floor Wire and Front Seat RH Wire (Under the Driver's Seat)

Code	See Page	Ground Points Location	
ID	114 (LHD)	Cowl Side Panel LH	
BJ	118 (LHD)	Front Floor Panel LH	
	128 (RHD)		
BL	118 (LHD)	Front Floor Panel RH	
	128 (RHD)		

### **WIPER AND WASHER (LHD)**



#### SYSTEM OUTLINE

With the ignition SW turned on, the current flows to TERMINAL 17 of the front wiper and washer SW, and TERMINAL 2 of the front wiper motor through the WIPER fuse, TERMINAL 2 of washer motor through the WASHER fuse.

#### 1. LOW SPEED POSITION

With wiper SW turned to LO position, the current flows from TERMINAL 17 of the front wiper and washer SW to TERMINAL 7 to TERMINAL 1 of the front wiper motor to TERMINAL 5 to GROUND and causes the front wiper motor to run at low speed.

#### 2. HIGH SPEED POSITION

With wiper SW turned to HI position, the current flows from TERMINAL 17 of the front wiper and washer SW to TERMINAL 8 to TERMINAL 4 of the front wiper motor to TERMINAL 5 to GROUND and causes the front wiper motor to run at high speed.

#### 3. INT POSITION

With wiper SW turned to INT position, the relay operates and the current which is connected by relay function flows from TERMINAL 17 of the front wiper and washer SW to TERMINAL 2 to GROUND. This flow of current operates the intermittent circuit and the current flows from TERMINAL 17 of the front wiper and washer SW to TERMINAL 7 to TERMINAL 1 of the front wiper motor to TERMINAL 5 to GROUND and operates the wiper.

The intermittent operation is controlled by the charge/discharge function of the condenser installed in the relay, and the intermittent time is controlled by a time control SW to change the charging time of the condenser.

#### 4. MIST POSITION

With wiper SW turn MIST position, the current flows from TERMINAL 17 of the front wiper and washer SW to TERMINAL 7 to TERMINAL 1 of the wiper motor to TERMINAL 5 to GROUND and causes the wiper motor to run at low speed.

#### 5. WASHER CONTINUOUS OPERATION

With washer SW turned to on, the current flows from TERMINAL 2 of the washer motor to TERMINAL 1 to TERMINAL 11 of the front wiper and washer SW to TERMINAL 2 to GROUND and causes to the washer motor to run, and the window washer emits a water spray. This causes the current to flow to washer continuous operation circuit in TERMINAL 17 of the front wiper and washer SW to TERMINAL 7 to TERMINAL 1 of the front wiper motor to TERMINAL 5 to GROUND and operates the wiper.

#### SERVICE HINTS -

### C12 FRONT WIPER AND WASHER SW [COMB. SW]

2-GROUND : Always continuity

17-GROUND : Approx. 12 volts with the ignition SW at ON or ST position

7-GROUND : Approx. 12 volts with the front wiper and washer SW at LO position

Approx. 12 volts approx. 1.6 to 10.7 seconds intermittently with the front wiper and washer SW at INT position

16-GROUND: Approx. 12 volts with the ignition SW on unless the front wiper motor at STOP position

8-GROUND : Approx. 12 volts with the front wiper and washer SW at HI position

### F10 FRONT WIPER MOTOR

2-3 : Closed unless the wiper motor at STOP position

### : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C12	98 (LHD)	J5	99 (LHD)		
F10	96 (LHD)	W1	97 (LHD)		

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)

#### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)

# WIPER AND WASHER (LHD)

: GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
IG	114 (LHD)	Cowl Side Panel RH

### SHIFT LOCK



#### SYSTEM OUTLINE

When the ignition SW is turned to ACC position, the current from the RADIO NO.2 fuse flows to TERMINAL 4 of the shift lock ECU. When the ignition SW is turned to ON position, the current from the ECU-IG fuse flows to TERMINAL 5 of the ECU.

#### 1. SHIFT LOCK MECHANISM

With the ignition SW on, when a signal that the brake pedal is depressed (Stop light SW on) and a signal that the shift lever is put in P position (Continuity between P1 and P of the shift lock control SW) is input to the ECU, the ECU activates and the current flows from TERMINAL 5 of the ECU to TERMINAL SLS+ of the shift lock solenoid to solenoid to TERMINAL SLS- to TERMINAL 9 of the ECU to GROUND. This causes the shift lock solenoid to turn on (Lock plate disengages) and the shift lever can be shifted into other position than the P position

#### 2. KEY INTER LOCK MECHANISM

With the ignition SW ON or ACC position, when the shift lever is put in P position (No continuity between P2 and P of shift lock control SW), the current flowing from TERMINAL 8 of the ECU to the key interlock solenoid is cut off. This causes the key interlock solenoid to turn off (Lock plate disengages from LOCK position) and the ignition key can be turned from ACC to LOCK position.

#### SERVICE HINTS

#### **S8 SHIFT LOCK ECU**

4-GROUND : Approx. 12 volts with the ignition SW at ACC or ON position 5-GROUND : Approx. 12 volts with the ignition SW at ON or ST position

9-GROUND : Always continuity

10-GROUND : Approx. 12 volts with the brake pedal depressed

### S11 STOP LIGHT SW

2-1: Closed with the brake pedal depressed

### : PARTS LOCATION

Code		See Page	Code See Page		Code	See Page
A14		98 (LHD)	J5	107 (RHD)	N1	105 (RHD)
ζ		106 (RHD)		99 (LHD)	00	99 (LHD)
	3	96 (LHD)	76	107 (RHD)	S8	107 (RHD)
_	_0	104 (RHD)	J9	99 (LHD)	244	99 (LHD)
J2	Α	97 (LHD)	Ja	107 (RHD)	S11	107 (RHD)
UZ.	^	105 (RHD)	laa	99 (LHD)	1	99 (LHD)
J3	В	97 (LHD)	→ J11	107 (RHD)	<b>─</b> U1	107 (RHD)
J3	3   6	105 (RHD)	N1	97 (LHD)		,

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)		
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)		
1F	OZ (END)	institution Failer wire and Driver Side 5/6 (Left Nick Paner)		
1G	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)		
1H	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)		
	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)		
11	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)		
1K	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)		
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)		
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)		
	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)		
2H	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)		
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)		
21	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)		
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)		

## SHIFT LOCK


## : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)				
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)				
17.0	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)				
IF1	126 (RHD)	Instrument Panel No.3 Wire and Instrument Panel Wire (Right Side of the Instrument Panel)				

## : GROUND POINTS

Code	See Page	Ground Points Location
EC	122 (RHD)	Left Fender Apron
ID	114 (LHD)	Cowl Side Panel LH
	124 (RHD)	Cowi Side Pariei LH

## **MOON ROOF**





#### SYSTEM OUTLINE

In this system, the HALL IC in the moon roof control ECU detects changes in the motor rotation to allow opening/closing and tilting up/down of the moon roof using one touch operation. Additionally, catching prevention mechanism during moon roof operation is also provided.

Voltage is always applied from the S/ROOF fuse to TERMINAL 4 of the moon roof control ECU. When the ignition SW is turned to ON, the voltage is applied from the ECU-IG fuse to TERMINAL 3 of the moon roof control ECU.

#### 1. SLIDE OPEN OPERATION

When the moon roof control SW is pressed to OPEN position (The limit SW No.1 is off and limit SW No.2 is on), the signal is input from TERMINAL 3 of the moon roof control SW to TERMINAL 2 of the moon roof control ECU. This activates the relay and rotates the motor to open the moon roof. After that, when the limit SW No.1 is turned on, and then turned off again, the pulse signal sent from the HALL IC activates the relay, and it determines that the moon roof is fully opened, and stops the motor rotation. If other operation SW or open SW is operated while the moon roof is being opened, the relay is activated to stop the moon roof operation. Additionally, when the moon roof is tilted up, the slide open operation does not function.

#### 2. SLIDE CLOSE OPERATION

When the moon roof control SW is pressed to CLOSE position (The limit SW No.1 is off and limit SW No.2 is off), the signal is input from TERMINAL 6 of the moon roof control SW to TERMINAL 1 of the moon roof control ECU. This activates the relay and rotates the motor to automatically close the moon roof. After that, when the limit SW No.2 is turned on, the pulse signal sent from the HALL IC activates the relay, and it determines that the moon roof is fully closed, and stops the motor rotation. If other operation SW or close SW is operated while the moon roof is being closed, the relay is activated to stop the moon roof operation.

#### 3. TILT UP OPERATION

When the moon roof control SW is pressed to TILT UP position (The limit SW No.1 is off and limit SW No.2 is on), the signal is input from TERMINAL 5 of the moon roof control SW to TERMINAL 5 of the moon roof control ECU. This activates the relay and rotates the motor to automatically tilt up the moon roof. If the pulse signal sent from the HALL IC is not input when the moon roof is fully tilted up, the relay determines that the motor has stopped, and stops the current flowing into the motor.

If other operation SW or tilt up SW is operated while the moon roof is being tilted up, the relay is activated to stop the moon roof operation. Additionally, when the moon roof is open, the tilt up operation does not function.

#### 4. TILT DOWN OPERATION

When the moon roof control SW is pressed to TILT DOWN position (The limit SW No.1 is on and limit SW No.2 is on), the signal is input from TERMINAL 2 of the moon roof control SW to TERMINAL 6 of the moon roof control ECU. This activates the relay and rotates the motor to automatically tilt down the moon roof. When the limit SW No.1 is turned off, the pulse signal sent from the HALL IC activates the relay, and it determines that the moon roof is fully closed, and stops the motor rotation.

If other operation SW or tilt down SW is operated while the moon roof is being tilted down, the relay is activated to stop the moon roof operation.

#### 5. CATCHING PREVENTION FUNCTION

If the moon roof control ECU detects a catching load from changes in the motor rotation during slide close or tilt down operation, the operation is stopped, and then the motor is rotated in the reverse direction.

Slide close operation

The moon roof is moved approximately 200 mm in the reverse direction (Slide open) after a catching load has been detected. However, if the full open position is detected before moving approximately 200 mm completely, the reverse movement is stopped.

Tilt down operation

If a catching load is detected during tilt down operation, the moon roof is fully tilted up.

#### 6. KEY OFF MOON ROOF OPERATION

The moon roof can be operated for approximately 45 seconds, when the ignition SW is turned from ON to OFF with all doors closed. However, when the driver side door or front passenger side door is opened during this time, the operation is canceled.

### 7. FAIL SAFE FUNCTION

If the moon roof is operated continuously in the same operating direction, the current flowing into the motor is cut off when the time shown below has elapsed after the motor operation has been started.

Slide open/close operation with the moon roof control SW Approximately 20 sec.

Tilt up/down operation with the moon roof control SW Approximately 2 sec.

Slide open operation for reverse movement in case of activation of the catching prevention function Approximately 20 sec. Tilt open operation for reverse movement in case of activation of the catching prevention function Approximately 2 sec.

#### SERVICE HINTS

#### **M2 MOON ROOF CONTROL ECU**

4-GROUND : Always approx. 12 volts

3-GROUND : Approx. 12 volts with ignition SW at ON or ST position

7-GROUND : Always continuity

#### M3 MOON ROOF CONTROL SW

5-4 : Closed with moon roof control SW at **TILT UP** position 2-4 : Closed with moon roof control SW at **TILT DOWN** position

3-4 : Closed with moon roof control SW at **OPEN** position 6-4 : Closed with moon roof control SW at **CLOSE** position

4-GROUND : Always continuity

### : PARTS LOCATION

Code		See Page Code See Page		See Page	Code	See Page	
B7	В	98 (LHD) D8 108 (RHD)	M3	100 (LHD)			
		106 (RHD)	M2	100 (LHD)	IVIO	108 (RHD)	
D7		100 (LHD)	] ""2	108 (RHD)			

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)
1M	88 (RHD)	Roof Wire and Driver Side J/B (Right Kick Panel)
1N	82 (LHD)	Roof Wire and Driver Side J/B (Left Kick Panel)

### : GROUND POINTS

Code	See Page	Ground Points Location
ВМ	118 (LHD)	Roof Panel
DIVI	128 (RHD)	1 NOOF FAILE

### : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B1	118 (LHD)	Roof Wire	B1	128 (BHD)	Boof Wire



- SERVICE HINTS

DEICER RELAY

3-5: Closed with ignition SW at  ${
m ON}$  position and defogger SW [A/C control assembly] on

### O : PARTS LOCATION

Code		See Page	Co	ode	See Page	Code		See Page
A14 A	Δ	98 (LHD)		10	98 (LHD)	E3	В	104 (RHD)
		106 (RHD)		10	106 (RHD)			96 (LHD)
A15	В	98 (LHD)		)2	106 (RHD)	—	9	104 (RHD)
AIS	"	106 (RHD)			96 (LHD)	Т	5	107 (RHD)
B6 A	۸	98 (LHD)	E2	A	104 (RHD)			
	^	106 (RHD)	E3	В	96 (LHD)	-		

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)					
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)					
1G	82 (LHD)	Engine Poom Main Wire and Driver Cide I/D (Left Viel, Denell)					
1K	02 (LI ID)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)					


### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)

### : GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
IF	124 (RHD)	Cowl Side Panel RH





## **REAR WINDOW DEFOGGER AND MIRROR HEATER**

### SERVICE HINTS -

### **RR DEF RELAY**

2-1, 3-5: Closed with ignition SW at ON position and defogger SW [A/C control assembly] on

### O : PARTS LOCATION

Co	ode	See Page	Code		See Page	Code	See Page
A14	Α	98 (LHD)	D	2	106 (RHD)	N7	101 (LHD)
	^	106 (RHD)	E2	A	96 (LHD)	197	109 (RHD)
Δ15	A15 B 98 (LHD)	98 (LHD)	] [2	^	104 (RHD)	R16	101 (LHD)
		E3	В	96 (LHD)	1110	109 (RHD)	
B6	Α	98 (LHD)		"	104 (RHD)	R17	101 (LHD)
		106 (RHD)	J	5	99 (LHD)	N17	109 (RHD)
C	10	98 (LHD)	1-	12	100 (LHD)	T5	107 (RHD)
		106 (RHD)		۱۴.	108 (RHD)		

## : RELAY BLOCKS

Ĺ	Code	See Page	Relay Blocks (Relay Block Location)
	1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
	ı	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)


### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1B	82 (LHD)	Front Door LH Wire and Driver Side J/B (Left Kick Panel)
1C	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1D	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
111	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
11	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1K	88 (RHD)	Front Door RH Wire and Driver Side J/B (Right Kick Panel)
1L	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
16	88 (RHD)	Floor Wire and Driver Side J/B (Right Kick Panel)
10	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
20	90 (RHD)	Front Door LH Wire and Passenger Side J/B (Left Kick Panel)
2D	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
20	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2H	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
211	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
21	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2K	84 (LHD)	Front Door RH Wire and Passenger Side J/B (Right Kick Panel)
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)	
IAS	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)	
IC1	114 (LHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)	
111	126 (RHD)	Front Door RH Wire and Instrument Panel Wire (Left Kick Panel)	







## **LEXUS NAVIGATION SYSTEM (LHD)**

### - SYSTEM OUTLINE

The LEXUS navigation system displays the operating status and instructions for the automatic air conditioner or radio and player, as well as trip information. Additionally, the navigation system precisely measures the current vehicle position, displays the map obtained from the map database on the screen, and informs the route to the destination shown on the map using voice guidance.

### SERVICE HINTS

### N6 (D) NAVIGATION ECU

(D) 3-GROUND : Always approx. 12 volts

(D) 9-GROUND : Approx. 12 volts with ignition SW at ACC or ON position

(D) 6-GROUND : Always continuity

### M1 MULTI-DISPLAY

3-GROUND : Always approx. 12 volts

### **R8 REMOTE CONTROL RECEIVER**

5-GROUND : Approx. 12 volts with ignition at ACC or ON position

1-GROUND : Always continuity

### : PARTS LOCATION

Code	See Page	Co	de	See Page	Co	de	See Page
B1 B	96 (LHD)	J3 B 97 (LHD)		97 (LHD)	N4	В	101 (LHD)
C3	96 (LHD)	J	6	99 (LHD)	N5	С	101 (LHD)
C10	98 (LHD)	J9		99 (LHD)	N6	D	101 (LHD)
D4	98 (LHD)	J11		99 (LHD)	R2	Α	99 (LHD)
F11	100 (LHD)	J1	13	100 (LHD)	R3	В	99 (LHD)
F13	100 (LHD)	N	11	99 (LHD)	R5	D	99 (LHD)
J1	97 (LHD)	N1	Α	97 (LHD)	R	8	99 (LHD)
J2 A	97 (LHD)	N3	Α	101 (LHD)	S	9	99 (LHD)

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)				
1A						
1E	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)				
1F	]					
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)				
1K		Engine Room Main Wire and Driver Side J/B (Left Rick Panel)				
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)				
2E	84 (LHD)	Instrument Panel Wire and Passenger Side I/P (Pight Kiek Panel)				
2G	] 04 (E110)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)				
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)				

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Co	ode	See Page	Joining Wire Harness and Wire Harness (Connector Location)
10	C1	114 (LHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
11-	11		
ll ll	<del>1</del> 2	116 (LHD)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
ll-	<del>-</del> 13		


### : GROUND POINTS

Code	See Page	Ground Points Location
ΙD	114 (LHD)	Cowl Side Panel LH
IE	114 (LHD)	Instrument Panel Center
BL	118 (LHD)	Front Floor Panel RH

CELLULAR MOBILE TELEPHONE

\* 1:8 SPEAKER
\* 2:6 SPEAKER





## **CELLULAR MOBILE TELEPHONE**

### SERVICE HINTS

### T8 (A) TELEPHONE TRANSCEIVER AND SPEAKER RELAY

(A) 6-GROUND : Always approx. 12 volts
(A) 7-GROUND : Approx. 12 volts with ignition SW at ON or ST position
(A) 1-GROUND : Always continuity

### O : PARTS LOCATION

Code	See Page	Code		See Page	Code		See Page
C13	98 (LHD)	J17		108 (RHD)	S10		99 (LHD)
	106 (RHD)	R2	Α	99 (LHD)	310	В	107 (RHD)
J9	99 (LHD)	ΠZ	^	107 (RHD)	_		99 (LHD)
	107 (RHD)	R4	С	99 (LHD)	Т	3	107 (RHD)
J14	100 (LHD)	174		107 (RHD)	Т8	۸	101 (LHD)
014	108 (RHD)	R14		101 (LHD)	'°	Α	109 (RHD)
J16	100 (LHD)	R	15	109 (RHD)	Т9	В	101 (LHD)
310	108 (RHD)	S9	Α	99 (LHD)	1 19	0	109 (RHD)
J17	100 (LHD)	39	^	107 (RHD)			

### : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
,	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)				
1H	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)				
11	82 (LHD)	D) Floor No.2 Wire and Driver Side J/B (Left Kick Panel)				
2H	90 (RHD)	nstrument Panel Wire and Passenger Side J/B (Left Kick Panel)				
21	90 (RHD)	90 (RHD) Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)				
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)				
ZL	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)				


### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)				
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)				
1/1/0	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)				
IB1	114 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)				
'6'	124 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)				
IB2	114 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)				
102	124 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)				
BC1	BC1 128 (RHD) Floor No.2 Wire and Floor Wire (Under the Right Rear Cushion)					

### : GROUND POINTS

Code	See Page	round Points Location			
BJ	128 (RHD)	ont Floor Panel LH			
ВК	118 (LHD)	Left Quarter Panel LH			
DIX.	128 (RHD)				
BL	118 (LHD)	Front Floor Panel RH			





# **RADIO AND PLAYER (LHD 6 SPEAKER)**

### SERVICE HINTS

### R5 (D) RADIO AND PLAYER

(D) 4-GROUND : Always approx. 12 volts
(D) 3-GROUND : Approx. 12 volts with the ignition SW at ACC or ON position

(D) 7-GROUND : Always continuity

### O : PARTS LOCATION

Code	See Page	Co	de	See Page	Co	de	See Page
A29	98 (LHD)	N4	В	101 (LHD)	R	14	101 (LHD)
F11	100 (LHD)	N5	С	101 (LHD)	R	15	101 (LHD)
F12	100 (LHD)	R2	Α	99 (LHD)	T8	A	101 (LHD)
F13	100 (LHD)	R3	В	99 (LHD)	T9	В	101 (LHD)
F14	100 (LHD)	R4	С	99 (LHD)			
J6	99 (LHD)	R5	D	99 (LHD)			

### : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


L	Code	See Page	Junction Block and Wire Harness (Connector Location)
	1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)


### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)				
IB1	114 (LHD)	Instrument Denal Miles and Electric No. 2007				
IB2		strument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)				
IC1	114 (LHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)				
IG1	116 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)				
IH2	116 (LHD)					
IH3	7 110 (END)	nstrument Panel Wire and Floor Wire (Near the Passenger Side J/B)				
111	116 (LHD)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)				

### : GROUND POINTS

Code	See Page	Ground Points Location
H T	114 (LHD)	Front Floor Panel Center RH





# **RADIO AND PLAYER (LHD 8 SPEAKER)**

### — SERVICE HINTS —

### **S9 (A) STEREO COMPONENT AMPLIFIER**

(A)16-GROUND : Approx. 12 volts with ignition SW at ACC or ON position

(A) 7-GROUND : Always approx. 12 volts (A)12-GROUND : Always continuity

### : PARTS LOCATION

Code	See Page	Co	de	See Page	Co	de	See Page
A29	98 (LHD)	N4	В	101 (LHD)	S9	Α	99 (LHD)
F11	100 (LHD)	N5	С	101 (LHD)	S10	В	99 (LHD)
F12	100 (LHD)	R3	В	99 (LHD)	T8	Α	101 (LHD)
F13	100 (LHD)	R6	E	99 (LHD)	Т9	В	101 (LHD)
F14	100 (LHD)	R	14	101 (LHD)	V	/5	101 (LHD)
J6	99 (LHD) R15 1		101 (LHD)	V	/6	101 (LHD)	

### : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


L	Code See Page Joining Wire Harness and Wire Harness (Connector Location)		Joining Wire Harness and Wire Harness (Connector Location)			
	IB1	114 (LHD)	Instrument Denel Mire and Floor No O Mire (Mose the Driver Cide 1/D)			
	IB2	114 (LIID)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)			
	IC1	114 (LHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)			
	IG1	116 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)			
	IH2	116 (LHD)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)			
	IH3	110 (LIID)	instrument Famer vviie and Floor vviie (ivear the Fassenger Side J/B)			
	II1	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)				


### : GROUND POINTS

Code	See Page	Ground Points Location
Ш	114 (LHD)	Front Floor Panel Center RH


### : SPLICE POINTS


Code	See Page Wire Harness with Splice Points		Code	See Page	Wire Harness with Splice Points
14	116 (LHD)	Instrument Panel Wire			











## **COMBINATION METER**

SERVICE HINTS -

P2 PARKING BRAKE SW

1-GROUND : Closed with parking brake lever depressed

F15 FUEL SENDER

2-3 : Approx. **2.0**  $\Omega$  at fuel full Approx. **48.7**  $\Omega$  at fuel empty

C10 (A), C11 (B) COMBINATION METER

(A)17-GROUND : Approx. 12 volts with ignition SW at ON or ST position

(A)18-GROUND: Always continuity
(A)19-GROUND: Always continuity
(A)15-GROUND: Always approx. 12 volts
(A)16-GROUND: Always approx. 12 volts

### : PARTS LOCATION

Co	ode	See Page	C	ode	See Page	Code	See Page
A14	A	98 (LHD)		)4	106 (RHD)		99 (LHD)
		106 (RHD)			96 (LHD)	J7	107 (RHD)
A15	В	98 (LHD)	E2	Α	104 (RHD)		99 (LHD)
/		106 (RHD)			96 (LHD)	J8	107 (RHD)
F	31	96 (LHD)	—— E3	В	104 (RHD)		99 (LHD)
		104 (RHD)			100 (LHD)	J9	107 (RHD)
В6	A	98 (LHD)		15	108 (RHD)	J10	107 (RHD)
50		106 (RHD)		10	100 (LHD)		99 (LHD)
B7	В	98 (LHD)		16	108 (RHD)	J11	107 (RHD)
		106 (RHD)	10	Τ.	97 (LHD)		99 (LHD)
C10	Α	98 (LHD)	J2	A	105 (RHD)		107 (RHD)
		106 (RHD)	J3		97 (LHD)		99 (LHD)
C11	В	98 (LHD)		В	105 (RHD)	R9	107 (RHD)
		106 (RHD)		-	99 (LHD)		97 (LHD)
D	1	98 (LHD)		5	107 (RHD)	S1	105 (RHD)
D	2	106 (RHD)			99 (LHD)	T5	107 (RHD)
D4		98 (LHD)		6	107 (RHD)	-	

### : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)	
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)	
	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)	
2	80 (LHD)	Engine Room No.2 R/B (Engine Compartment Right)	
	81 (RHD)	Engine Room No.2 R/B (Engine Compartment Left)	

## $\circ$

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1E	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
_ '-	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1F	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
11	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1K	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2A	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2E	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
26	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2F	2F 84 (LHD) Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)	
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
20	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2H	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
411	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
21	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
21	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2K	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)
<u> </u>	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2M	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)


### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
EA2	112 (LHD)	Engine Wire and Engine Room Main Wire (Inside of the ECU Box)	
L/2	122 (RHD)	Engine wire and Engine hoom Main wire (inside of the ECO Box)	
IA2	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)	
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)	
1/10	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)	
BC1	118 (LHD)	Floor No.2 Wire and Floor Wire (Under the Right Rear Cushion)	
	128 (RHD)	Thou No.2 while and Floor while (Onder the Hight hear Gushlon)	

### : GROUND POINTS

Code	See Page	Ground Points Location	
EC	122 (RHD)	Left Fender Apron	
ID	114 (LHD)	Cowl Side Panel LH	
"	124 (RHD)	Cowi Side Failei Ln	
iн	114 (LHD)	Front Floor Panel Center LH	
"	124 (RHD)	Front Floor Panel Center RH	
BJ	128 (RHD)	Front Floor Panel LH	
BL	118 (LHD)	Front Floor Panel RH	

# RADIATOR FAN AND CONDENSER FAN





## **RADIATOR FAN AND CONDENSER FAN**

### SYSTEM OUTLINE

With the ignition SW turned on, the current through the ECU-IG fuse flows to the FAN NO.1 relay (Coil side), FAN NO.2 relay (Coil side) and FAN NO.3 relay (Coil side).

#### 1. LOW SPEED OPERATION

Only when the A/C system is activated, the A/C condenser fan motor and the radiator fan motor rotates at low speed. When the A/C system is activated, the current from ECU-IG fuse flows to the FAN NO.3 relay (Coil side) to TERMINAL 2 of the diode (A/C) to TERMINAL 3 to TERMINAL 13 of the engine ECU (M/T) or engine and ECT ECU (A/T), causing the FAN NO.3 relay to turn on. As a result, the current through the CDS FAN fuse flows to FAN NO.3 relay (Point side) to TERMINAL 2 of the A/C condenser fan motor to TERMINAL 1 to TERMINAL 3 of the FAN NO.2 relay to TERMINAL 4 to TERMINAL 2 of the radiator fan motor to TERMINAL 1 to GROUND. As this flowing in series for the motors, the motors rotate at low speed.

#### 2. HIGH SPEED OPERATION

With the A/C single pressure SW is turned on and/or the water temp. SW is turned on, the A/C condenser fan motor and the radiator fan motor rotate at high speed.

When the A/C single pressure SW is turned on, the current through the ECU-IG fuse flows to the FAN NO.1 and NO.2 relay (Coil side) to TERMINAL 3 of the A/C single pressure SW to TERMINAL 2 to GROUND, and the current through the ECU-IG fuse flows to the FAN NO.3 relay (Coil side) to TERMINAL 2 of the diode (A/C) to TERMINAL 1 to TERMINAL 3 of the A/C single pressure SW to TERMINAL 2 to GROUND. As a result, FAN NO.1, NO.2, and NO.3 relay is turned on. At the same time, the current from the RDI FAN fuse flows to FAN NO.1 relay (Point side) to TERMINAL 2 of the radiator fan motor to TERMINAL 1 to GROUND, and the current from the CDS FAN fuse flows to FAN NO.3 relay (Point side) to TERMINAL 2 of the A/C condenser fan motor to TERMINAL 1 to TERMINAL 3 of the FAN NO.2 relay to TERMINAL 5 to GROUND.

As the current flowing in parallel for motors as above, the motors rotate at high speed. When the water temp. SW is turned on, the current through the ECU-IG fuse flows to the FAN NO.1 and NO.2 relay (Coil side) to TERMINAL 2 of the water temp. SW to TERMINAL 1 to GROUND, and the current through the ECU-IG fuse flows to the FAN NO.3 relay (Coil side) to TERMINAL 2 of the diode (A/C) to TERMINAL 1 to TERMINAL 2 of the water temp. SW to TERMINAL 1 to GROUND. As a result, FAN NO.1, NO.2 and NO.3 relay is turned on. At the same time, the current from the RDI FAN fuse flows to FAN NO.1 relay (Point side) to TERMINAL 2 of the radiator fan motor to TERMINAL 1 to GROUND, and the current from the CDS FAN fuse flows to FAN NO.3 relay (Point side) to TERMINAL 2 of the A/C condenser fan motor to TERMINAL 3 of the FAN NO.2 relay to TERMINAL 5 to GROUND.

As the current flowing in parallel for motors as above, the motors rotate at high speed.

#### SERVICE HINTS -

#### A4 A/C SINGLE PRESSURE SW

3-2 : Close above approx. **15.5** kgf/cm<sup>2</sup> (**220** psi, **1520** kpa) Open below approx. **12.5** kgf/cm<sup>2</sup> (**178** psi, **1226** kpa)

#### W3 WATER TEMP. SW

1-2 : Close above approx. 95°C

#### : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A2	96 (LHD)	D3	106 (RHD)		97 (LHD)
, <u></u>	104 (RHD)	E3	96 (LHD)	— R1	105 (RHD)
A4	96 (LHD)		104 (RHD)	14/0	97 (LHD)
	104 (RHD)	14	97 (LHD)	— wз	105 (RHD)
D3	98 (LHD)		105 (RHD)		

#### : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)				
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)				
	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)				
3	94 (LHD)	Engine Room No.3 R/B (Engine Compartment Right)				
	94 (RHD)	Engine Room No.3 R/B (Engine Compartment Left)				

## 0

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	unction Block and Wire Harness (Connector Location)			
1H	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)			
	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)			
2A	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)			
2H	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)			
	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)			
2N	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)			

## $\nabla$


### : GROUND POINTS


Code	See Page	Ground Points Location
EC	112 (LHD)	Laft Fonder Apres
LO	122 (RHD)	Left Fender Apron
ID	114 (LHD)	Cowl Side Panel LH
IF	124 (RHD)	Cowl Side Panel RH




#### : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E9	122 (RHD)	Engine Room Main Wire	E10	112 (LHD)	Engine Room Main Wire





## **AUTOMATIC AIR CONDITIONER (LHD)**



#### SYSTEM OUTLINE

#### 1. HEATER BLOWER OPERATION

Manual operation

When the blower speed is set to a certain level using the blower control SW, the A/C control assembly sends the signals to the blower control to control the blower motor speed.

Auto operation

When the auto SW is turned on, the A/C control assembly sends the signals from various sensors and temperature SW to the blower control to automatically control the blower motor speed.

#### 2. AIR INLET CONTROL SERVO MOTOR CONTROL

When the FRESH/RECIRC select SW is set to RECIRC, the motor in the air inlet control servo motor starts rotating to move the damper toward the RECIRC side. The motor is continuously rotated until the damper reaches its stop position. When the FRESH/RECIRC select SW is set to FRESH, the motor in the air inlet control servo motor starts rotating to move the damper toward the FRESH side. The motor is continuously rotated until the damper reaches its stop position.

#### 3. AIR VENT MODE CONTROL SERVO MOTOR CONTROL

When the mode select SW is pushed, the ECU in the A/C control assembly activates the air vent mode control servo motor. This causes the servo motor to rotate to the position (FACE, BI-LEVEL, FOOT, FOOT/DEF, DEF) selected using the mode select SW, and moves the film damper.

#### 4. AIR MIX CONTROL SERVO MOTOR CONTROL

When the temperature control SW is pressed, the ECU in the A/C control assembly sends a signal to the air mix control servo motor. This signal drives the motor to reach the temperature set by the temperature control SW, and moves the film damper.

#### 5. AIR CONDITIONER OPERATION

The A/C control assembly receives various signals, I.E., the engine RPM from the crankshaft position sensor, outlet temperature signal from the A/C ambient temp. sensor, coolant temperature from the water temp. sensor, etc. When the engine is started and the A/C SW is on, a signal is input to the ECU (Built into the A/C control assembly). As a result, the ground circuit in A/C control assembly is closed and current flows from A/C fuse to TERMINAL 1 of the A/C COMP relay to TERMINAL 2 to TERMINAL ACMG of the engine ECU (M/T) or engine and ECT ECU (A/T) to TERMINAL MPX to TERMINAL MPX— of the A/C control assembly to TERMINAL GND to GROUND, turning the relay on so that the A/C magnetic clutch is on and the A/C compressor operates. At the same time, the engine ECU (M/T) or engine and ECT ECU (A/T) detects the magnetic clutch is on and the A/C compressor operates and rotates the motor to the open direction to avoid lowering the engine RPM during A/C operation. When any of the following signals are input to the A/C control assembly, the A/C control assembly operates to turn off the air conditioner.

- \* Coolant temp. signal is high.
- \* A signal that the temperature at the air outlet is low.
- \* A signal that there is a large difference between engine speed and compressor speed.
- \* A signal that the refrigerant pressure is abnormally high or low.

#### SERVICE HINTS

### A4 A/C DUAL PRESSURE SW

1-4 : Open with the refrigerant pressure at less than approx. **216** kpa (**2.2** kgf/cm<sup>2</sup>, **31** psi) or more than approx. **3138** kpa (**32** kgf/cm<sup>2</sup>, **455** psi)

### A14 (A) A/C CONTROL ASSEMBLY

+B-GROUND : Always approx. 12 volts

ACC-GROUND : Approx. 12 volts with ignition SW at ACC or ON position

FRS-GROUND : Approx. 12 volts with FRESH SW on REC-GROUND : Approx. 12 volts with RECIRC SW on

GND-GROUND : Always continuity

### : PARTS LOCATION

Cc	ode	See Page	Co	Code See Page		Code		See Page	
A	.1	96 (LHD)	A.	A18 98 (LHD)		E3	В	96 (LHD)	
Α	٠3	96 (LHD)	A2	A24 98 (LHD)		E5	D	96 (LHD)	
Α	4	96 (LHD)	A2	25	98 (LHD)	J	6	99 (LHD)	
A14	Α	98 (LHD)	- A2	26	98 (LHD)	J	7	99 (LHD)	
A15	В	98 (LHD)	В	3	98 (LHD)	s	8	99 (LHD)	
A.	16	98 (LHD)	B4	Ā	98 (LHD)				
A	17	98 (LHD)	B5	В	98 (LHD)				

# **AUTOMATIC AIR CONDITIONER (LHD)**

### : RELAY BLOCKS

[	Code	See Page	Relay Blocks (Relay Block Location)
[	3	94 (LHD)	Engine Room No.3 R/B (Engine Compartment Right)

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2D		
2F	04 (1 PID)	Instrument Banal Wire and Bassanger Side I/B (Bight Kiek Banal)
2H	- 84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
21		

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


l	Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
	EA1 112 (LHD) Engine Wire and Engine Room Main Wire (Inside of the ECU Box)		Engine Wire and Engine Room Main Wire (Inside of the ECU Box)
	IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
	ID1	114 (LHD)	Instrument Panel No.2 Wire and Instrument Panel Wire (Left Side of the Instrument Panel)
	IF1	116 (LHD)	Instrument Panel Wire and A/C Sub Wire (Left Side of the Blower Unit)
[	IF2	110 (E110)	Institution of a file wife and AVO out wife (Left olde of the blower offit)


### 7 : GROUND POINTS


Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
ID	114 (LHD)	Cowl Side Panel LH
IF	114 (LHD)	Instrument Panel Reinforcement RH

## : SPLICE POINTS


Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
l1	116 (LHD)	A/C Sub Wire	12	116 (LHD)	A/C Sub Wire







- \* 1 : W/ POWER SEAT
- \* 3 : W/ DAYTIME RUNNING LIGHT \* 4 : W/O DAYTIME RUNNING LIGHT
- \* 5 : W/ LEXUS NAVIGATION SYSTEM \* 6 : W/ MOON ROOF
- \* 7: W/O MOON ROOF
- BODY ECU (GND2) GLOVE BOX LIGHT JUNCTION CONNECTOR TRANSPONDER KEY AMPLIFIER W-B A/C CONTROL ASSEMBLY BR COMBINATION METER (ILL-HEADLIGHT BEAM LEVEL CONTROL SW BR W-B RHEOSTAT BR REMOTE CONTROL RECEIVER W-B SEAT HEATER SW (PASSENGER' S SEAT) (\*1) BB HEADLIGHT CLEANER SW (ILL-W-B CRUISE CONTROL SW [COMB. SW] SEAT HEATER SW (DRIVER' S SEAT) (A/T) (\*1) BR TELEPHONE SW [COMB. SW] W-B (\*1) BR W-B A/T SHIFT POSITION ILLUMINATION ASHTRAY ILLUMINATION W-B CIGARETTE LIGHTER ILLUMINATION SHIFT LOCK CONTROL ECU BR W-B (A/T) REAR FOG LIGHT SW ECT PATTERN SELECT SW BR W-B (A/T) W-B TURN SIGNAL SW [COMB. SW] KEY INTERLOCK SOLENOID [UNLOCK WARNING SW] BR TRACTION CUT SW UNLOCK WARNING SW W-B JUNCTION CONNECTOR FRONT FOG LIGHT SW [COMB. SW] HIGH BEAM INDICATOR LIGHT[COMB. METER] W-B



## I GROUND POINT (LHD)

## O : PARTS LOCATION

	Code	See Page	See Page Code		Code	See Page
J2	Α	97 (LHD)	J7	99 (LHD)	J16	100 (LHD)
J3	В	97 (LHD)	J9	99 (LHD)	J17	100 (LHD)
	J4	97 (LHD)	J12	100 (LHD)		
	J5	99 (LHD)	J13	100 (LHD)		

### : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
2	80 (LHD)	Engine Room No.2 R/B (Engine Compartment Right)
3	94 (LHD)	Engine Room No.3 R/B (Engine Compartment Right)

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1B	82 (LHD)	Front Door LH Wire and Driver Side J/B (Left Kick Panel)
1E	82 (LHD)	Instrument Development Development Development
1F	- 02 (LND)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
11	82 (LHD)	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)
1J	82 (LHD)	Instrument Penal Mine and Private City UP (L. 6.16.1. D
1L	902 (LND)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2E		
2F		
2G	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2H		
2J		
2K	84 (LHD)	Front Door RH Wire and Passenger Side J/B (Right Kick Panel)
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	112 (LHD)	Engine Wire and Engine Room Main Wire (Inside of the ECU Box)
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
IB1	114 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)
IE1	116 (LHD)	Floor No.3 Wire and Floor No.2 Wire (Near the Steering Column)
IF1	116 (LHD)	Instrument Panel Wire and A/C Sub Wire (Left Side of the Blower Unit)
IH1	116 (LHD)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
BA1	118 (LHD)	Rear Door No.2 Wire and Floor No.2 Wire (Left Center Pillar)
BB1	118 (LHD)	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)
BD1	118 (LHD)	Floor No 2 Wire and Luggage Beam Wire / Direkt Cide of the Luggage Beam Wire
BD2	110 (2110)	Floor No.2 Wire and Luggage Room Wire (Right Side of the Luggage Door)
BE1	120 (LHD)	Floor No.2 Wire and Front Seat LH Wire (Under the Driver's Seat)


## : GROUND POINTS

Code	See Page	Ground Points Location
EA	112 (LHD)	Front Side of Cylinder Head
EB	112 (LHD)	Rear Side of Cylinder Head
EC	112 (LHD)	Left Fender Apron
ID	114 (LHD)	Cowl Side Panel LH
IE	114 (LHD)	Instrument Panel Center
IF	114 (LHD)	Instrument Panel Reinforcement RH
IG	114 (LHD)	Cowl Side Panel RH
IH	114 (LHD)	Front Floor Panel Center LH
11	114 (LHD)	Front Floor Panel Center RH
BJ	118 (LHD)	Front Floor Panel LH
BK	118 (LHD)	Left Quarter Panel LH
BL	118 (LHD)	Front Floor Panel RH
ВМ	118 (LHD)	Roof Panel

## : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	112 (LHD)	Engine Wire	13	116 (LHD)	Engine Room Main Wire
E10	112 (LHD)	Engine Room Main Wire	B1	118 (LHD)	Roof Wire
E11	112 (2.15)			120 (LHD)	Front Seat LH Wire

The chart below shows the route by which current flows from the battery to each electrical source (Fusible Link, Circuit Breaker, Fuse, etc.) and other Parts.



\*1 : w/ Daytime Running Light \*2 : w/o Daytime Running Light \*3 : Except Australia

**Electrical Source** 


20A P FR P/W

20A D RR P/W

20A P RR P/W

4

\*4 : Australia



10A ECU-IG

15A WASHER

15A SEAT HTR

**10A GAUGE** 

P/W Relay (Point Side) 4 **40A HEATRE** 15A FR FOG 7.5A OBD 7.5A SRS-B 4 15A MIR HTR 7.5A TV 15A DOOR DL 10A H-LP L UPR

15A STOP

20A D FR P/W

30A S/ROOF

30A D P/SEAT

40A RR DEF (LHD) 30A RR DEF (RHD)

10A H-LP R UPR

20A DOOR 20A FR DEF

(5)

[LOCATION] ①: Engine Room No.1 R/B (See page 80 (LHD) or 81 (RHD))

③: Driver Side J/B (See page 82 (LHD) or 88 (RHD))

②: Engine Room No.2 R/B (See page 80 (LHD) or 81 (RHD))

④: Passenger Side J/B (See page 84 (LHD) or 90 (RHD))

2

5: Engine Room No.3 R/B (See Page 94)

## J POWER SOURCE (Current Flow Chart)

## Engine Room No.1 R/B (See Page 80 (LHD) or 81 (RHD) )

	Fuse	System	Page
7.5A	ALT-S	Charging	154
7.5A	TEL	Cellular Mobile Telephone	422
		Headlight (LHD w/ Daytime Running Light)	186
10A	H-LP L LWR	Headlight (LHD w/o Daytime Running Light)	190
		Headlight (RHD)	194
10A	H-LP LVL	Headlight Beam Level Control	388
		Headlight (LHD w/ Daytime Running Light)	186
10A	H-LP R LWR	Headlight (LHD w/o Daytime Running Light)	190
		Headlight (RHD)	194
10A	HORN	Horn	382
. •	7.01.11	Theft Deterrent (RHD)	306
10A	TURN-HAZ		222
		Turn Signal and Hazard Warning Light (RHD)	224
		Cruise Control	360
15A	ETCS		352
		, ,	158
_		Engine Control (RHD)	170
15A	H-LP LH	Headlight (RHD)	194
15A	H-LP RH	Combination Meter	442
		Headlight (RHD)	194
	TEL Cellular Mobile Telephone  Headlight (LHD w/ Daytime Running Light) Headlight (LHD w/o Daytime Running Light) Headlight (RHD)  H-LP LVL Headlight Beam Level Control  Headlight (LHD w/o Daytime Running Light) Headlight (LHD w/o Daytime Running Light) Headlight (RHD)  HORN Horn Theft Deterrent (RHD)  Turn Signal and Hazard Warning Light (LHD) Turn Signal and Hazard Warning Light (RHD)  Cruise Control ECT and A/T Indicator Engine Control (LHD) Engine Control (RHD)  H-LP LH Headlight (RHD)	, ,	158
20A		, ,	170
		150	
		Headlight (LHD w/o Daytime Running Light) Headlight (RHD)  Headlight Beam Level Control  Headlight (LHD w/ Daytime Running Light) Headlight (LHD w/o Daytime Running Light) Headlight (RHD)  Horn Theft Deterrent (RHD)  Turn Signal and Hazard Warning Light (LHD) Turn Signal and Hazard Warning Light (RHD)  Cruise Control ECT and A/T Indicator Engine Control (LHD) Engine Control (RHD)  Headlight (RHD)  Combination Meter Headlight (RHD)  Engine Control (LHD) Engine Control (LHD) Engine Control (LHD) Engine Control (RHD) Ignition Starting  Cruise Control ECT and A/T Indicator Engine Control (LHD) Engine Control (LHD) Engine Homobiliser System  Radio and Player (LHD 6 Speaker) Radio and Player (LHD 8 Speaker) Radio and Player (RHD 8 Speaker) Radiotor Fan and Condenser Fan Headlight Cleaner Radiator Fan and Condenser Fan Automatic Light Control (RHD) Headlight (LHD w/ Daytime Running Light) Headlight (LHD w/o Daytime Running Light)	148
			360
			352
20A	EFI	1 -	158
		- · · · ·	170
			182
		· · · · · · · · · · · · · · · · · · ·	426
20A	RADIO NO.1		430
		, , ,	434
30A	CDS EAN		438
30A			448
30A			384
<del></del>	TIDITAN		448
		` '	274
40A	MAIN		186
70/1	141/2/114		190 194
		, ,	384
		Troduight Oleaner	384

<sup>\*</sup> These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
		Rear Fog Light (LHD)	202
40A	MAIN	Rear Fog Light (RHD)	206
<del>1</del> 0/1	IVICIIN	Starting	148
		Theft Deterrent (RHD)	306
60A	ABS	ABS and Traction Control	366
		ABS and Traction Control	366
		Automatic Light Control (RHD)	274
		Charging	154
		Headlight (LHD w/ Daytime Running Light)	186
		Illumination (LHD)	214
		Illumination (RHD)	218
		Light Reminder (LHD)	214 218 338 342
120A	ALT	Light Reminder (RHD)	
120/		Multiplex Communication System (LHD)	232
		Multiplex Communication System (RHD)	248
		Power Window (LHD)	318
		Power Window (RHD)	324
		Radiator Fan and Condenser Fan	448
		Rear Window Defogger and Mirror Heater	410
		Taillight	210
		Theft Deterrent (RHD)	306

## Engine Room No.2 R/B (See Page 80 (LHD) or 81 (RHD) )

	Fuse	System	Page
7.5A	DRL	Headlight (LHD w/ Daytime Running Light)	186
		Headlight (LHD w/ Daytime Running Light)	186
10A	H-LP L UPR	Headlight (LHD w/o Daytime Running Light)	190
		Headlight (RHD)	194
		Combination Meter	442
10A	H-LP R UPR	Headlight (LHD w/ Daytime Running Light)	186
100		Headlight (LHD w/o Daytime Running Light)	190
		Headlight (RHD)	194

# Driver Side J/B (See Page 82 (LHD) or 88 (RHD) )

Fuse		System	Page
		Combination Meter	442
		Headlight (LHD w/ Daytime Running Light)	186
		Illumination (LHD)	214
7.5A	PANEL	Illumination (RHD)	218
7.5A	.5A PANEL	Light Reminder (LHD)	338
		Light Reminder (RHD)	342
		Multiplex Communication System (LHD)	232
		Multiplex Communication System (RHD)	248

<sup>\*</sup> These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
		Rear Fog Light (LHD)	202
7.5A	PANEL	Rear Fog Light (RHD)	206
		Theft Deterrent (RHD)	306
		ECT and A/T Indicator	352
		Engine Control (LHD)	158
7 <b>5</b> A	STARTER	Engine Control (RHD)	170
7.5A	SIARIER	LEXUS Navigation System (LHD)	414
		LEXUS Navigation System (RHD)	418
		Starting	148
10A	A/C	Automatic Air Conditioner (LHD)	452
UA	TA/C	Automatic Air Conditioner (RHD)	458
		ABS and Traction Control	366
		Automatic Air Conditioner (LHD)	452
		Automatic Air Conditioner (RHD)	458
		Automatic Light Control (RHD)	274
		Door Lock Control (LHD)	278
		Door Lock Control (RHD)	284
		Double Locking (RHD)	312
		Headlight (LHD w/ Daytime Running Light)	186
		Interior Light (LHD)	262
		Interior Light (RHD)	268
		Light Reminder (LHD)	338
0A	ECU-IG	Light Reminder (RHD)	342
IUA	100-10	Moon Roof	404
		Multiplex Communication System (LHD)	232
		Multiplex Communication System (RHD)	248
		Power Window (LHD)	318
		Power Window (RHD)	324
		Radiator Fan and Condenser Fan	448
		Seat Belt Warning (LHD)	330
		Seat Belt Warning (RHD)	334
		Shift Lock	400
		Theft Deterrent (RHD)	306
		Wireless Door Lock Control (LHD)	290
		Wireless Door Lock Control (RHD)	298
		ABS and Traction Control	366
		Back-Up Light	226
		Cellular Mobile Telephone	422
		Charging	154
10A	GAUGE	Combination Meter	442
		Cruise Control	360
		ECT and A/T Indicator	352
		Engine Control (LHD)	158
		Engine Control (RHD)	170

	Fuse	System	Page
-		Front Window Deicer	408
		LEXUS Navigation System (LHD)	414
		LEXUS Navigation System (RHD)	418
		Light Reminder (LHD)	338
		Light Reminder (RHD)	342
		Multiplex Communication System (LHD)	232
		Multiplex Communication System (RHD)	248
		Power Window (LHD)	318
10A	GAUGE	Power Window (RHD)	324
		Rear Window Defogger and Mirror Heater	410
		Seat Belt Warning (LHD)	330
		Seat Belt Warning (RHD)	334
		Shift Lock	400
		Stop Light	228
		Taillight	210
		Turn Signal and Hazard Warning Light (LHD)	222
		Turn Signal and Hazard Warning Light (RHD)	224
		Automatic Air Conditioner (LHD)	452
		Automatic Air Conditioner (RHD)	458
		Clock	380
		Door Lock Control (LHD)	278
		Door Lock Control (RHD)	284
		Double Locking (RHD)	312
		Interior Light (LHD)	262
		Interior Light (RHD)	268
		LEXUS Navigation System (LHD)	414
		LEXUS Navigation System (RHD)	418
		Light Reminder (LHD)	338
		Light Reminder (RHD)	342
		Multiplex Communication System (LHD)	232
10A	RADIO NO.2	Multiplex Communication System (RHD)	248
		Power Window (LHD)	318
		Power Window (RHD)	324
		Radio and Player (LHD 6 Speaker)	426
		Radio and Player (RHD 6 Speaker)	430
		Radio and Player (LHD 8 Speaker)	434
		Radio and Player (RHD 8 Speaker)	438
		Remote Control Mirror (LHD)	346
		Remote Control Mirror (RHD)	348
		Seat Belt Warning (LHD)	330
		Seat Belt Warning (RHD)	334
		Shift Lock	400
		Theft Deterrent (RHD)	306
		Wireless Door Lock Control (LHD)	290
		, ,	

<sup>\*</sup> These are the page numbers of the first page on which the related system is shown.

<sup>\*</sup> These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
10A	RADIO NO.2	Wireless Door Lock Control (RHD)	298
10A	SRS-ACC	SRS	373
		Front Fog Light (LHD)	198
10A	TAIL	Front Fog Light (RHD)	200
		Taillight	210
15A	CIG	Cigarette Lighter	378
15A	SEAT HTR	Seat Heater	390
		ABS and Traction Control	366
		Cruise Control	360
		ECT and A/T Indicator	352
15A	STOP	Engine Control (LHD)	158
		Engine Control (RHD)	170
		Shift Lock	400
- 111		Stop Light	228
		Headlight Cleaner	384
15A	WASHER	Wiper and Washer (LHD)	392
		Wiper and Washer (RHD)	396
		Multiplex Communication System (LHD)	232
20A	D FR PW	Multiplex Communication System (RHD)	248
20, (		·	318
		Power Window (RHD)	324
		Door Lock Control (LHD)	278
		Door Lock Control (RHD)	284
		Double Locking (RHD)	312
	Engine Control (LHD) Engine Control (RHD) Shift Lock Stop Light  Headlight Cleaner Wiper and Washer (LHD) Wiper and Washer (RHD)  Multiplex Communication System (LHD) Multiplex Communication System (RHD) Power Window (LHD) Power Window (RHD)  Door Lock Control (LHD) Door Lock Control (RHD) Double Locking (RHD) Interior Light (LHD) Light Reminder (LHD) Light Reminder (RHD) Multiplex Communication System (LHD) Multiplex Communication System (LHD) Multiplex Communication System (RHD) Power Window (LHD) Power Window (LHD) Power Window (RHD) Seat Belt Warning (LHD) Seat Belt Warning (RHD)		262
		Interior Light (RHD)	268
		, ,	338
		, · ·	342
20A	DOOR	· ·	232
		· · · · · · · · · · · · · · · · · · ·	248
		· /	318
		, ,	324
			330
		,	334
		Theft Deterrent (RHD)	306
		Wireless Door Lock Control (LHD)	290
004	LED DEE	Wireless Door Lock Control (RHD)	298
20A	FR DEF	Front Window Deicer	408
25A	WIPER	Wiper and Washer (LHD)	392
		Wiper and Washer (RHD)	396
30A	D P/SEAT	Power Seat	350
30A	RR DEF	Rear Window Defogger and Mirror Heater	410

<sup>\*</sup> These are the page numbers of the first page on which the related system is shown.

# Passenger Side J/B (See Page 84 (LHD) or 90 (RHD) )

	Fuse	System	Page
30A	S/ROOF	Moon Roof	404
40A	RR DEF	Rear Window Defogger and Mirror Heater	410
		Interior Light (LHD)	262
		Interior Light (RHD)	268
754	DOME	Multiplex Communication System (LHD)	232
7.5A	DOME	Multiplex Communication System (RHD)	248
		Wireless Door Lock Control (LHD)	290
		Wireless Door Lock Control (RHD)	298
		Headlight (LHD w/ Daytime Running Light)	186
7.5A	ECU-B2	Rear Fog Light (LHD)	202
7.57	LOO-B2	Rear Fog Light (RHD)	206
		Theft Deterrent (RHD)	306
		Cruise Control	360
		ECT and A/T Indicator	352
7.5A	IGN	Engine Control (LHD)	158
		Engine Control (RHD)	170
		SRS	373
		Engine Control (LHD)	158
7.5A	OBD	Engine Control (RHD)	170
	7.5A OBD Engine Control (RHD) SRS Combination Meter	373	
		Combination Meter	442
		Interior Light (LHD)	262
7.5A	SRS-B	Interior Light (RHD)	268
7.57	3113-6	Multiplex Communication System (LHD)	232
		Multiplex Communication System (RHD)	248
		SRS	373
7.5A	TV	LEXUS Navigation System (LHD)	414
7.55		LEXUS Navigation System (RHD)	418
		Automatic Air Conditioner (LHD)	452
		Automatic Air Conditioner (RHD)	458
		Automatic Light Control (RHD)	274
		Clock	380
		Combination Meter	442
		Door Lock Control (LHD)	278
10A	MPX-B	Door Lock Control (RHD)	284
	IVII X-B	Double Locking (RHD)	312
		Interior Light (LHD)	262
		Interior Light (RHD)	268
		Light Reminder (LHD)	338
		Light Reminder (RHD)	342
		Multiplex Communication System (LHD)	232
		Multiplex Communication System (RHD)	248

<sup>\*</sup> These are the page numbers of the first page on which the related system is shown.

# J POWER SOURCE (Current Flow Chart)

	Fuse	System	Page
		Power Window (LHD)	318
		Power Window (RHD)	324
		Seat Belt Warning (LHD)	330
10A	MPX-B	Seat Belt Warning (RHD)	334
		Theft Deterrent (RHD)	306
		Wireless Door Lock Control (LHD)	290
		Wireless Door Lock Control (RHD)	298
15A	DOOR DL	Double Locking (RHD)	312
15A	FR FOG	Front Fog Light (LHD)	198
10/1		Front Fog Light (RHD)	200
15A	MIR HTR	Rear Window Defogger and Mirror Heater	410
		Multiplex Communication System (LHD)	232
20A	D RR P/W	Multiplex Communication System (RHD)	248
20/4	D Till T /VV	Power Window (LHD)	318
		Power Window (RHD)	324
		Multiplex Communication System (LHD)	232
20A	P FR P/W	Multiplex Communication System (RHD)	248
20/1		Power Window (LHD)	318
		Power Window (RHD)	324
40A	HEATER	Automatic Air Conditioner (LHD)	452
		Automatic Air Conditioner (RHD)	458


<sup>\*</sup> These are the page numbers of the first page on which the related system is shown.





























A23



A24














































































































#### K CONNECTOR LIST K **E2 E**3 E4 **C7** YELLOW **E**5 C8 C9 C10 C11 GRAY Ш 3 4 5 6 7 8 9 10 11 789101112 C12 BLACK C13 BLACK C14 (Europe) BLACK C14 (Australia) BLACK E6 **E7** BLACK **E8** GRAY **E9** GRAY E10 BLACK 112 123456 D1 BLUE D2 D3 D4 123 **F1** GRAY **F2** GRAY F4 BROWN **F6** GRAY BROWN **GRAY** (12) (12) **F7** GRAY F8 GRAY F9 GRAY F10 BLACK F11 F12 D5 D7 **D8** D9 D11 BLACK D10 12 F13 BLACK F14 **F15** DARK GRAY D12 F16 D12 D13 G1 D13 D14 (w/ Dead Lock) (w/o Dead Lock) BLACK (w/ Dead Lock) (w/o Dead Lock) BLACK BLACK 2 3 4 5 6 1 2 3 4 1 2 3 4 H1 D15 H2 D15 **D16** (w/ Dead Lock) НЗ D16 (w/o Dead Lock) BLACK **E1** GRAY **H**4 H5 (w/o Dead Lock) BLACK **GRAY** (w/ Dead Lock) GRAY **BLACK** BLACK **BLACK** 12 45678 1 2 3 4 1 2 2 3 4




J4



















### **M PART NUMBER OF CONNECTORS**

Code	Code	Ded Name	D	1 6 :		
A 2				Code	I	<b>.</b>
A 3	<u> </u>	· ·		В9		90980-10825
A 4				<b> </b>		
A	A 3		90980-11271	B10		90980-11212
A 5         ABS and Traction Actuator         90980-11698           A 6         ABS and Traction Actuator         90980-11002           A 7         ABS Speed Sensor Front LH         90980-11002           A 8         ABS Speed Sensor Front IRH         90980-11002           A 10         Alxbag Sensor Front LH         90980-11856           A11         Alxbag Sensor Front LH         90980-11856           A12         Alxbag Sensor Front H         90980-11856           A13         Alxbag Sensor Front H         90980-11856           A14         AV Control Research         90980-11856           A15         AC Control Assembly         90980-11856           A15         AV Control Assembly         90980-11859           A16         AV Control Assembly         90980-11859           A17         AV Costrol Assembly         90980-11856           A18         AV Control Assembly         90980-11856           A19         AV Solar Sensor         90980-11869           A19         AV Solar Sensor         90980-11891           A19         AV Solar Sensor         90980-11891           A21         AV Solar Sensor         90980-11891           A22         ABS and Traction ECU         90980-11869	A 4	Single Pressure SW)	90980-10943	B11		1
A Fash and Traction Router         9990-11162           A 7 ABS Speed Sensor Front LH         90980-11002           A 8 ABS Speed Sensor Front RH         90980-11002           A 9 Accel Position Sensor         90980-10711           A 10 Arbag Sensor Front LH         90980-11856           A11 Arbag Sensor Front LH         90980-11856           A12 Arbag Sensor Front RH         90980-11856           A13 Arbag Sensor Front RH         90980-11856           A14 AC Control Assembly         90980-11856           A15 AC Control Assembly         90980-11856           A15 AC Control Assembly         90980-11856           A16 AC Room Temp. Sensor         90980-11865           A17 AC Solar Sensor         90980-11865           A18 AC Thermistor         90980-11865           A19 AC Thermistor         90980-11881           A20 AS and Traction ECU         90980-11893           A21 ABS and Traction ECU         90980-11867           A22 Air Mix Control Servo Motor         90980-11861           A23 Air Mix Control Servo Motor         90980-11861           A24 Air Intel Control Servo Motor         90980-11861           A25 Air Mix Control Servo Motor         90980-11866           A26 Air Mix Control Servo Motor         90980-11866           A27 Air Mix	A 5	ABS and Traction Actuator	90980-11698	]		
ABS Speed Sensor Front RH         90980-11002           A8 BS Speed Sensor Front RH         90980-10711           A9 Accel Position Sensor         90980-10711           A10 Airbag Sensor Front LH         90980-11856           A11 Airbag Sensor Front RH         90980-11856           A12 Alternator         90980-09213           A13 Alternator         90980-11934           A14 AlC Control Assembly         90980-11934           A15 AC Control Assembly         90980-11956           A16 AC Room Temp. Sensor         90980-11958           A17 AC Solar Sensor         90980-10825           A18 AC Thermistor         90980-11934           A19 AC Third Position Illumination         90980-11934           A20 ABS and Traction ECU         90980-11837           A21 ABS and Traction ECU         90980-11837           A22 ABS and Traction ECU         90980-11837           A23 ABS and Traction ECU         90980-11837           A24 Air Inlet Control Servo Motor         90980-11836           A25 Air Mix Control Servo Motor         90980-11836           A26 Air Vent Mode Control Servo Motor         90980-11836           A28 Alrabag Squib (Seering Wheel Pad)         90980-10825           A30 Ashtray Illumination         90980-10825           A31 Base Speed S	A 6	ABS and Traction Actuator	90980-11413			90980-10947
ABS         ABS Speed Sensor Front RH         90980-10711           A1         An Joan Position Sensor         90980-10711           A10         Airbag Sensor Front LH         90980-11856           A11         Altrag Sensor Front RH         90980-11856           A12         Alternator         90980-09213           A13         Alternator         90980-11349           A14         A/C Control Assembly         90980-11566           A15         A/C Control Assembly         90980-11566           A15         A/C Control Assembly         90980-11566           A15         A/C Control Assembly         90980-11469           A16         A/C Control Assembly         90980-11469           A16         A/C Control Assembly         90980-11687           A16         A/C Control Assembly         90980-11686           A17         A/C Solar Sensor         90980-11687           A18         A/C Thermistor         90980-10825           A19         A/T Shift Position Illumination         90980-11637           A20         ABS and Traction ECU         90980-11637           A21         ABS and Traction ECU         90980-11421           A22         ABS and Traction ECU         90980-11269           <	A 7	ABS Speed Sensor Front LH		<u> </u>	Camshaft Timing Oil Control Valve	90980-11162
Accel Prosini Sensor   99990-1071	A 8	ABS Speed Sensor Front RH	90980-11002	ļ		90980-11195
A11	A 9	Accel Position Sensor	90980-10711		Crankshaft Position Sensor	90980-10947
Air   Air	A10	Airbag Sensor Front LH				90980-11869
A13   Alternator   90980-11564     A14   A/C Control Assembly   90980-11565     A15   A/C Control Assembly   90980-11566     A16   A/C Room Temp. Sensor   90980-11082     A17   A/C Solar Sensor   90980-10825     A18   A/C Thermistor   90980-10825     A19   A/T Shift Position Illumination   90980-11933     A20   ABS and Traction ECU   90980-11638     A21   ABS and Traction ECU   90980-11637     A22   ABS and Traction ECU   90980-11467     A23   ABS and Traction ECU   90980-11467     A24   Air Inlet Control Servo Motor   90980-11467     A25   Air Mix Control Servo Motor   90980-11868     A26   Air Vent Mode Control Servo Motor   90980-11868     A22   Air Saguib (Front Passenger Airbag   90980-11868     A23   ABS quib (Steering Wheel Pad)   90980-10825     A33   Automatic Light Control Sensor   90980-11107     A30   Ashtray Illumination   90980-11207     A31   Automatic Light Control Sensor   90980-111207     A32   ABS Speed Sensor Rear LH   90980-111207     A33   ABS Speed Sensor Rear LH   90980-111207     B 2   Brake Fluid Level Warning SW   90980-11207     B 3   Blower Motor Controller   90980-11207     B 4   Blower Motor Controller   90980-11207     B 5   Blower Motor Controller   90980-11979     B 6   Body ECU   90980-11971     B 7   Body ECU   90980-11027     B 8   Buckle SW LH (w/ Power Seat)   90980-10825     B 8   Buckle SW LH (w/ Power Seat)   90980-10825     C 8   Cigarette Lighter Illumination   90980-11180     C 10   Combination Meter   90980-11190     C 10   Combination SW (Curpoe)   90980-11190     C 11   Combination SW (Curpoe)   90980-11190     C 12   Combination SW (Eurpoe)   90980-11190     D 1   Daytime Running Light leave y 90980-11672     D 2   Double Locking ECU   90980-11090     D 3   Double Locking ECU   90980-11090     D 4   DLC3   Double Locking ECU   90980-11090     D 5   Door Courtesy SW Front LH   90980-11090     D 6   Door Courtesy SW Front RH   90980-110	A11	Airbag Sensor Front RH	-  90980-11856 			90980-11872
Art	A12	Alternator	90980-09213			90980-11867
A15   A/C Control Assertiny	A13	Alternator	90980-11349			90980-10760
A16	A14	A/C Control Assembly	90980-11556	C 9	Cigarette Lighter Illumination	90980-11148
A/C   Solar Sensor   99980-11918   C12   Combination SW   99980-11594   A/C   Solar Sensor   99980-11625   A18   A/C   Thermistor   99980-11625   A19   A/T   Shift Position Illumination   99980-11638   A20   ABS and Traction ECU   99980-11638   A21   ABS and Traction ECU   99980-11637   A22   ABS and Traction ECU   99980-11637   A23   ABS and Traction ECU   99980-11421   A24   Air Inlet Control Servo Motor   99980-11421   A25   Air Mix Control Servo Motor   A26   Air Went Mode Control Servo Motor   A27   Airbag Squib (Front Passenger Airbag Assembly)   99980-11886   A28   Airbag Squib (Steering Wheel Pad)   99980-11886   A30   Ashtray Illumination   99980-11886   A31   Automatic Light Control Servo Motor   A32   ABS Speed Sensor Rear LH   99980-11060   A33   ABS Speed Sensor Rear LH   99980-11107   A32   ABS Speed Sensor Rear RH   99980-11107   A33   ABS Speed Sensor Rear RH   99980-11107   A34   ABS Speed Sensor Rear RH   99980-11107   A35   Babwer Motor   99980-11107   B B   Bower Motor Controller   99980-11667   B B   Bower Motor Controller   99980-11971   99980-11971   B B   Bower Motor Controller   99980-11971   99980-11971   B B   Bower Motor Controller   99980-119	A15	A/C Control Assembly	90980-11469	C10	Combination Meter	90980-11915
A	A16	A/C Room Temp. Sensor	90980-10825	C11	Combination Meter	90980-11911
A19	A17	A/C Solar Sensor	90980-11918	C12	Combination SW	90980-11594
A20	A18	A/C Thermistor	90980-10825	C13	Combination SW	90980-11616
A20         ABS and Traction ECU         90980-11638         Combination SW (Australia)         90980-11955           A21         ABS and Traction ECU         90980-11467         D 1         Daytime Running Light Relay         90980-10807           A22         ABS and Traction ECU         90980-11476         D 2         Double Locking ECU         90980-10807           A23         ABS and Traction ECU         90980-11421         D 2         Double Locking ECU         90980-10807           A24         Air Inlet Control Servo Motor         90980-11909         D 3         Diode (A/C)         90980-11251           A25         Air Mix Control Servo Motor         90980-11165         D 5         Door Courtesy Light Front LH         90980-11165           A26         Air Vent Mode Control Servo Motor         90980-11886         D 6         Door Courtesy Light Front RH         90980-11148           A27         Airbag Squib (Front Passenger Airbag Assembly)         90980-11886         D 7         Door Courtesy SW Front LH         D 8         Door Courtesy SW Front RH         D 90980-11148           A29         Antenna Amplifier         90980-10825         D 9         Door Courtesy SW Rear RH         D 1         D 9000 Courtesy SW Rear RH         D 1           A32         ABS Speed Sensor Rear LH         90980-11142         <	A19	A/T Shift Position Illumination	90980-11493	C14	Combination SW (Eurpoe)	90980-11672
A22	A20	ABS and Traction ECU	90980-11638		Combination SW (Australia)	90980-11595
A23   ABS and Traction ECU   90980-11421   D3   Diode (A/C)   90980-11251	A21	ABS and Traction ECU	90980-11637	D 1	Daytime Running Light Relay	90980-10807
A24	A22	ABS and Traction ECU	90980-11476	D 2	Double Locking ECU	90980-10803
A25         Air Mile Control Servo Motor         99980-11909           A25         Air Mix Control Servo Motor         90980-11165           A26         Air Went Mode Control Servo Motor         90980-11165           A27         Airbag Squib (Front Passenger Airbag Assembly)         90980-11886           A28         Airbag Squib (Steering Wheel Pad)         90980-10850           A29         Antenna Amplifier         90980-10871           A30         Ashtray Illumination         90980-10825           A31         Automatic Light Control Sensor         90980-11107           A32         ABS Speed Sensor Rear LH         90980-11107           A33         ABS Speed Sensor Rear RH         90980-111207           B 1         Back-Up Light SW         90980-111207           B 2         Brake Fluid Level Warning SW         90980-11207           B 3         Blower Motor         90980-11207           B 4         Blower Motor Controller         90980-11579           B 5         Blower Motor Controller         90980-11971           B 7         Body ECU         90980-11971           B 8         Buckle SW LH (w/ Power Seat)         90980-10825	A23	ABS and Traction ECU	90980-11421	D3	Diode (A/C)	90980-11251
A26	A24	Air Inlet Control Servo Motor	90980-11909	D 4		90980-11665
A26	A25	Air Mix Control Servo Motor		D 5		90980-11148
A27         Airbag Squib (Notin Passeriger Airbag)         90980–11886         Door Courtesy SW Front RH         90980–10871           A28         Airbag Squib (Steering Wheel Pad)         90980–10850         D9         Door Courtesy SW Rear LH         90980–10871           A30         Ashtray Illumination         90980–10825         D10         Door Lock Motor, Door Key Lock and Unlock SW and Door Lock Detection SW Front LH         D0980–11858           A31         Automatic Light Control Sensor         90980–11107         D11         Door Lock Motor, Door Key Lock and Unlock SW and Door Lock Detection SW Front LH         D0980–11858           B 1         Back-Up Light SW         90980–11142         D12         D00r Lock Motor and Door Lock Detection SW Front RH (w/ Dead Lock)         90980–10799           B 2         Brake Fluid Level Warning SW         90980–11207         D13         D00r Lock Motor, Door Key Lock and Unlock SW and Door Lock Detection SW Front RH (w/o Dead Lock)         90980–11858           B 3         Blower Motor         90980–11667         P000 Lock Motor and Door Lock Detection SW Front RH (w/o Dead Lock)         90980–10799           B 4         Blower Motor Controller         90980–11579         D13         D00r Lock Motor and Door Lock Detection SW Front LH (w/o Dead Lock)         90980–11150           B 5         Blower Motor Controller         90980–11971         D14         D00r Lock	A26	Air Vent Mode Control Servo Motor	90980-11165	D6		30000 11140
A28   Airbag Squib (Steering Wheel Pad)   90980–10850   D9   Door Courtesy SW Front RH	Δ27		00080_11886			
A28         Airbag Squib (Steering Wheel Pad)         90980-10850         D 9         Door Courtesy SW Rear LH           A29         Antenna Amplifier         90980-10871         D10         Door Courtesy SW Rear RH           A30         Ashtray Illumination         90980-10825         D11         Door Lock Motor, Door Key Lock and Unlock SW and Door Lock Detection SW Front LH           A32         ABS Speed Sensor Rear LH         90980-11060         Door Lock Motor and Door Lock Detection SW Front RH (w/ Dead Lock)         90980-10799           B 1         Back-Up Light SW         90980-11142         Door Lock Motor, Door Key Lock and Unlock SW and Door Lock Detection SW Front RH (w/ Dead Lock)         90980-11858           B 3         Blower Motor         90980-11207         Door Lock Motor, Door Key Lock and Unlock SW and Door Lock Detection SW Front RH (w/ Dead Lock)         90980-11858           B 4         Blower Motor Controller         90980-11667         Door Lock Motor and Door Lock Detection SW Front LH (w/ Dead Lock)         90980-11950           B 5         Blower Motor Controller         90980-11971         D13         Door Lock Motor and Door Lock Detection SW Front LH (w/o Dead Lock)         90980-11150           B 6         Body ECU         90980-11911         Door Lock Motor and Door Lock Detection SW Front RH         90980-11150           B 8         Buckle SW LH (w/ Power Seat)         90980-108			90900-11000	D 8	Door Courtesy SW Front RH	90980-10871
A30         Ashtray Illumination         90980-10825           A31         Automatic Light Control Sensor         90980-11107           A32         ABS Speed Sensor Rear LH         90980-11060           A33         ABS Speed Sensor Rear RH         90980-11299           B 1         Back-Up Light SW         90980-11142           B 2         Brake Fluid Level Warning SW         90980-11207           B 3         Blower Motor         90980-11207           B 4         Blower Motor Controller         90980-11667           B 5         Blower Motor Controller         90980-11971           B 6         Body ECU         90980-11911           B 7         Body ECU         90980-11911           B 8         Buckle SW LH (w/ Power Seat)         90980-10825	A28	Airbag Squib (Steering Wheel Pad)	90980-10850	D9	· · · · · · · · · · · · · · · · · · ·	] 00000 100/1
A31         Automatic Light Control Sensor         90980-11107         D11         Unlock SW and Door Lock Detection SW Front LH         90980-11858           A32         ABS Speed Sensor Rear LH         90980-11060         D007 Lock Motor and Door Lock Detection SW Front RH (W/Dead Lock)         90980-10799           B 1         Back-Up Light SW         90980-11142         D007 Lock Motor, Door Key Lock and Unlock SW and Door Lock Detection SW Front RH (W/Dead Lock)         90980-11858           B 2         Brake Fluid Level Warning SW         90980-11207         D007 Lock Motor, Door Key Lock and Unlock SW and Door Lock Detection SW Front RH (W/Dead Lock)         90980-11858           B 3         Blower Motor         90980-11207         D007 Lock Motor and Door Lock Detection SW Front LH (W/Dead Lock)         90980-10799           B 4         Blower Motor Controller         90980-11579         D007 Lock Motor and Door Lock Detection SW Front LH (W/Dead Lock)         90980-11150           B 6         Body ECU         90980-11971         D14         D007 Lock Motor and Door Lock Detection SW Front RH         90980-11150           B 8         Buckle SW LH (W/Power Seat)         90980-10825         D14         SW Front RH         90980-11150	A29	•	90980-10871	D10	Door Courtesy SW Rear RH	
A31 Automatic Light Control Sensor  A32 ABS Speed Sensor Rear LH  A33 ABS Speed Sensor Rear RH  B 1 Back-Up Light SW  B 2 Brake Fluid Level Warning SW  B 3 Blower Motor  B 4 Blower Motor Controller  B 5 Blower Motor Controller  B 6 Body ECU  B 7 Body ECU  B 8 Buckle SW LH (w/ Power Seat)  SW Front LH  Front LH  Door Lock Motor and Door Lock Detection SW Front RH (w/ Dead Lock)  Door Lock Motor, Door Key Lock and Unlock SW and Door Lock Detection SW Front RH (w/o Dead Lock)  Door Lock Motor and Door Lock Detection SW Front LH (w/ Dead Lock)  Door Lock Motor and Door Lock Detection SW Front LH (w/o Dead Lock)  Door Lock Motor and Door Lock Detection SW Front LH (w/o Dead Lock)  Door Lock Motor and Door Lock Detection SW Front LH (w/o Dead Lock)  Door Lock Motor and Door Lock Detection SW Front LH (w/o Dead Lock)  Door Lock Motor and Door Lock Detection SW Front LH (w/o Dead Lock)  Door Lock Motor and Door Lock Detection SW Front LH (w/o Dead Lock)  Door Lock Motor and Door Lock Detection SW Front RH  Door Lock Motor and Door Lock Detection SW Front RH  Door Lock Motor and Door Lock Detection SW Front RH  Door Lock Motor and Door Lock Detection SW Front RH  Door Lock Motor and Door Lock Detection SW Front RH  Door Lock Motor and Door Lock Detection SW Front RH	A30	Ashtray Illumination	90980-10825	D11		00000 11050
A33         ABS Speed Sensor Rear RH         90980-11299           B 1         Back-Up Light SW         90980-11142           B 2         Brake Fluid Level Warning SW         90980-11207           B 3         Blower Motor         90980-10214           B 4         Blower Motor Controller         90980-11667           B 5         Blower Motor Controller         90980-11579           B 6         Body ECU         90980-11971           B 7         Body ECU         90980-11911           B 8         Buckle SW LH (w/ Power Seat)         90980-10825	A31		90980-11107			90960-11656
B 1   Back-Up Light SW   90980-11142   B 2   Brake Fluid Level Warning SW   90980-11207   B 3   Blower Motor   90980-10214   B 4   Blower Motor Controller   90980-11579   B 5   Blower Motor Controller   90980-11579   B 6   Body ECU   90980-11971   B 7   Body ECU   90980-10825   Buckle SW LH (w/ Power Seat)   90980-10825   D12   SW Front RH (w/ Dead Lock)   90980-1150   D13   SW Front RH (w/ Dead Lock)   90980-1150   D14   D14   D00r Lock Motor and D00r Lock Detection SW Front RH (w/ Dead Lock)   90980-11150   D14   D00r Lock Motor and D00r Lock Detection SW Front RH (w/ Dead Lock)   90980-11150   D14   D00r Lock Motor and D00r Lock Detection SW Front RH   D15   D16   D00r Lock Motor and D00r Lock Detection SW Front RH   D15   D16   D00r Lock Motor and D00r Lock Detection SW Front RH   D00r Lock Motor and D00r Lock D00r Loc	A32	ABS Speed Sensor Rear LH	90980-11060		Door Lock Motor and Door Lock Detection	00000 10700
B   Back-Op Light SW   90980-11142   B   Back-Op Light SW   90980-111207   B   Brake Fluid Level Warning SW   90980-11207   B   Blower Motor Controller   90980-11667   B   Blower Motor Controller   90980-11579   B   Body ECU   90980-11971   B   Body ECU   90980-11911   B   Buckle SW LH (w/ Power Seat)   90980-10825   Body ECU   90980-10825   Body ECU   90980-10825   Body ECU   B   Buckle SW LH (w/ Power Seat)   90980-11150   B   Buckle SW LH (w/ Power Seat)   90980-10825   Body ECU   90980	A33	ABS Speed Sensor Rear RH	90980-11299	D40		30300-10799
B 2         Brake Fluid Level Warning SW         90980–11207         Front RH (w/o Dead Lock)           B 3         Blower Motor         90980–10214         Door Lock Motor and Door Lock Detection SW Front LH (w/ Dead Lock)         90980–10799           B 4         Blower Motor Controller         90980–11579         Door Lock Motor and Door Lock Detection SW Front LH (w/o Dead Lock)         90980–11150           B 6         Body ECU         90980–11911         Door Lock Motor and Door Lock Detection SW Front LH (w/o Dead Lock)         90980–11150           B 7         Body ECU         90980–11911         D14         Door Lock Motor and Door Lock Detection SW Front RH         90980–11150           B 8         Buckle SW LH (w/ Power Seat)         90980–10825         D14         D14         D14         D14         D14         D15         D14         D15         D15         D15         D16         D17         D17         D18         D17         D18         D18         D18         D19	B 1		90980-11142	D12		00080_11858
B 4         Blower Motor Controller         90980-11667         D13         SW Front LH (w/ Dead Lock)         90980-10799           B 5         Blower Motor Controller         90980-11579         Door Lock Motor and Door Lock Detection SW Front LH (w/o Dead Lock)         90980-11150           B 6         Body ECU         90980-11911         D14         Door Lock Motor and Door Lock Detection SW Front RH         90980-11150           B 8         Buckle SW LH (w/ Power Seat)         90980-10825         D14         Door Lock Motor and Door Lock Detection SW Front RH         90980-11150	B 2	Brake Fluid Level Warning SW	90980-11207			90900-11030
B 4         Blower Motor Controller         90980–11667           B 5         Blower Motor Controller         90980–11579           B 6         Body ECU         90980–11971           B 7         Body ECU         90980–11911           B 8         Buckle SW LH (w/ Power Seat)         90980–10825             B 8         Buckle SW LH (w/ Power Seat)         90980–10825	В3	Blower Motor	90980-10214		Door Lock Motor and Door Lock Detection	90980, 10790
B 5         Blower Motor Controller         90980-11579         Door Lock Motor and Door Lock Detection SW Front LH (w/o Dead Lock)         90980-11150           B 6         Body ECU         90980-11971         Door Lock Motor and Door Lock Detection SW Front LH (w/o Dead Lock)         90980-11150           B 7         Body ECU         90980-11911         Door Lock Motor and Door Lock Detection SW Front RH         90980-11150           B 8         Buckle SW LH (w/ Power Seat)         90980-10825         Pront RH         90980-11150	B 4	Blower Motor Controller	90980-11667	D13		30300-10733
B 6         Body ECU         90980–11971           B 7         Body ECU         90980–11911           B 8         Buckle SW LH (w/ Power Seat)         90980–10825             Door Lock Motor and Door Lock Detection SW Front RH         90980–11150	B 5	Blower Motor Controller	90980-11579			90980-11150
B 7 Body ECU 90980–11911 D14 SW Front RH 90980–11150  B 8 Buckle SW LH (w/ Power Seat) 90980–10825	В6	Body ECU	90980-11971			
B8	В7	Body ECU	90980-11911	D14		90980-11150
Buckle SW LH (w/o Power Seat) 90980-11212	B 8	Buckle SW LH (w/ Power Seat)	90980-10825			
		Buckle SW LH (w/o Power Seat)	90980-11212			

Note: Not all of the above part numbers of the connector are established for the supply. In case of ordering a connector or terminal with wire, please confirm in advance if there is supply for it using "Parts Catalog News" (published by Parts Engineering Administration Dept.).

Nota: Toutes les références du connecteur ne sont pas définies pour la fourniture. Pour passer une commande d'un connecteur ou d'une borne avec fil, prière de vérifier préalablement si cette pièce est bien disponible en se reportant à "Parts Catalog News" (publié par le Département de la Gestion de l'Ingénierie).

Code	Part Name	Part Number	Code	Part Name	Part Numbe	
	Door Lock Motor and Door Lock Detection	90980-10799	Н8	Headlight RH (Low)	90980-11660	
D15	SW Rear LH (w/ Dead Lock)  Door Lock Motor and Door Lock Detection SW Rear LH (w/o Dead Lock)	90980-11150	H 9	Heated Oxygen Sensor (Bank 1 Sensor 1)	90980-11028	
			H10	Heated Oxygen Sensor (Bank 2 Sensor 1)		
	Door Lock Motor and Door Lock Detection		H11	Horn LH	90980-10619	
D16	SW Rear RH (w/ Dead Lock)	90980-10799	H12	Horn RH	90980-1061	
סוט	Door Lock Motor and Door Lock Detection	90980-11150	H13	Headlight Beam Level Control SW	90980-1079	
	SW Rear RH (w/o Dead Lock)		H14	Headlight Cleaner SW	90980-1101	
E 1	ECT Solenoid	90980-10891	H15	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980-1102	
E 2	Engine ECU (M/T) or Engine and ECT ECU (A/T)	90980-11638	H16	High Mounted Stop Light	90980-1114	
	Engine ECU (M/T) or Engine and ECT ECU	00000 4400=	11	Ignition Coil and Igniter No.1		
E3	(A/T)	90980-11637	12	Ignition Coil and Igniter No.2	]	
E 4	Engine and ECT ECU	90980-11586	13	Ignition Coil and Igniter No.3	00000 4400	
E 5	Engine ECU (M/T) or Engine and ECT ECU	90980-11476	14	Ignition Coil and Igniter No.4	90980-1188	
-	(A/T)		15	Ignition Coil and Igniter No.5	1	
E 6	Engine ECU (M/T) or Engine and ECT ECU (A/T)	90980-11421	16	Ignition Coil and Igniter No.6		
E 7	Engine Hood Courtesy SW	90980-11189	17	Injector No.1		
E 8	Engine Oil Level Sensor	90980-10532	18	Injector No.2	1	
E 9	Engine Oil Pressure SW	90980-11363	19	Injector No.3	1	
E10	ECT Pattern Select SW	90980-10933	110	Injector No.4	90980-1187	
F1	Front Clearance Light LH	90900-10933	l111	Injector No.5	1	
F 2	Front Clearance Light RH	90980-11162	l12	Injector No.6	1	
F3	Front Fog Light LH		l13	Intake Air Temp. Sensor	90980-1116	
F 4	Front Fog Light RH	90980-11660	114	Ignition Key Cylinder Light	90980-1090	
F 5	Front Side Turn Signal Light LH		l15	Ignition SW	90980-1161	
F6	Front Side Turn Signal Light RH	90980-11162	l16	Interior Light	90980-1093	
F7	Front Turn Signal Light LH		117	Interior Light and Radar Sensor	90980-1190	
F8	Front Turn Signal Light RH	90980-11019	J 1	Junction Connector	90980-1154	
		00000 41005	J 2	Junction Connector	-	
F 9	Front Window Deicer	90980-11295	J 3	Junction Connector	90980-1166	
F10	Front Wiper Motor	90980-11599	J 4	Junction Connector	90980-1080	
F11	Front Door Speaker LH	90980-10935	J 5	Junction Connector	90980-1097	
F12	Front Door Speaker RH		J 6	Junction Connector		
F13	Front Door Tweeter Speaker LH	90980-11013	J 7	Junction Connector	1	
F14	Front Door Tweeter Speaker RH		J 8	Junction Connector	-	
F15	Fuel Pump and Sender	90980-11077	J 9	Junction Connector	_	
F16	Fuel Sender (Sub)	90980-11140	J10	Junction Connector	-	
G 1	Glove Box Light	90980-11098	J11	Junction Connector	1	
H1	Headlight Beam Level Control Actuator LH	90980-11016	J12	Junction Connector	-	
H 2	Headlight Beam Level Control Actuator RH		J13	Junction Connector		
H 3	Headlight Cleaner Control Relay	90980-10939	J14	Junction Connector	-	
H 4	Headlight Cleaner Motor	90980-11410		Junction Connector	90980-11542	
H 5	Headlight LH (High)	90980-11659	J15	Junction Connector		
H 6	Headlight LH (Low)	90980-11660	J16			
H 7	Headlight RH (High)	90980-11659	J17	Junction Connector	90980-1097	

Nota: No todos los números de las partes del conector indicados arriba están dispuestos para el suministro. Al pedir un conector o terminal con cable, asegúrese, de antemano, de que esté suministrado refiriéndose a "Parts Catalog News" (publicado por el Departamento Administrativo de Ingeniería de las Partes).

Anmerkung: Nicht alle der obenerwähnten Teile-Nummern der Stecker werden für die Lieferung etabliert. Im Falle der Bestellung von Stecker oder Anschlußklemme mit Draht bestätigen Sie bitte unter Verwendung der "Teile-Prospekt-Nachtrichten" (herausgegeben durch die Teile-Engineering-Verwaltungsabteilung) im voraus, ob es entsprechende Lieferung gibt.

515

### **M PART NUMBER OF CONNECTORS**

	Part Name	Part Number	Code	Part Name	Part Number
K 1	Knock Sensor 1	90980-11166	P18	Power Seat Motor (Driver's Seat Reclining	
K 2	Knock Sensor 2	30300 11100	<u> </u>	Control)	90980-10825
K 3	Kick Down SW	90980-11156	P19	Power Seat Motor (Driver's Seat Slide Control)	
L1	License Plate Light LH	90980-11148	R 1	Radiator Fan Motor	90980-10928
L 2	License Plate Light RH	00000 11140	R2	Radio and Player	90980-11909
L 3	Light Failure Sensor	90980-10803	R3	Radio and Player	90980-10803
L 4	Luggage Compartment Door Courtesy SW and Opener Motor	90980-10825	R 4	Radio and Player	90980-10996
	Luggage Compartment Door Key Unlock		R5	Radio and Player	90980-10997
L 5	sw	90980-11368	R6	Radio and Player	90980-11913
L6	Luggage Compartment Door Opener Relay	90980-10171	R7	Rear Fog Light SW	90980-11533
L 7	Luggage Compartment Light	90980-11148	R8	Remote Control Receiver	90980-11909
M 1	Multi-Display	90980-11877	R9	Rheostat	90980-10214
M 2	Moon Roof Control ECU	90980-10801	R10	Rear Combination Light LH	
М3	Moon Roof Control SW and Personal Light	90980-10367	R11	Rear Combination Light RH	90980-11587
N 1	Neutral Start SW	90980-11784	R12	Rear Fog Light LH	
N 2	Noise Filter (Ignition)	90980-10843	R13	Rear Fog Light RH	90980-10795
N 3	Navigation ECU	90980-11915	R14	Rear Speaker LH	
N 4	Navigation ECU	90980-11913	R15	Rear Speaker RH	90980-11060
N 5	Navigation ECU	90980-10803	R16	Remote Control Mirror LH	
N 6	Navigation ECU	90980-11535	R17	Remote Control Mirror RH	90980-11532
N 7	Noise Filter (Rear Window Defogger)	90980-11259	R18	Remote Control Mirror SW	90980-11450
N 8	Noise Filter (Stop Light)	90980-10825	S 1	Speed Sensor (Combination Meter)	90980-11143
P 1	Power Steering Oil Pressure SW	90980-11428	S 2	Speed Sensor (Transmission Input)	
P 2	Parking Brake SW	90980-10871	S 3	Speed Sensor (Transmission Output)	90980-11156
Р3	Personal Light	90980-10935	S 4	Starter	90980-11400
P 4	Power Window Control SW Front LH		S 5	Starter	90980-09506
Р5	Power Window Control SW Front RH		S 6	Seat Heater SW (Driver's Seat)	
Р6	Power Window Control SW Rear LH	90980-10797	S 7	Seat Heater SW (Passenger's Seat)	90980-10797
Р7	Power Window Control SW Rear RH		S 8	Shift Lock Control ECU	90980-11581
P 8	Power Window Master SW	90980-11469	S 9	Stereo Component Amplifier	90980-10848
- D.O	Power Window Motor Front LH (LHD)	90980-11011	S10	Stereo Component Amplifier	90980-11913
P9	Power Window Motor Front LH (RHD)		S11	Stop Light SW	90980-11118
	Power Window Motor Front RH (LHD)	90980-10860	S12	Seat Heater (Driver's Seat)	
P10	Power Window Motor Front RH (RHD)	90980-11011	S13	Seat Heater (Passenger's Seat)	90980-10905
P11	Power Window Motor Rear LH		S14	Side Airbag Sensor LH	
P12	Power Window Motor Rear RH	90980-10860	S15	Side Airbag Sensor RH	90980-11857
P13	Pretensioner LH		S16	Side Airbag Squib LH	
P14	Pretensioner RH	90980-11862	S17	Side Airbag Squib RH	90980-11864
P15	Power Seat Control SW	90980-10997	T 1	Throttle Control Motor	90980-10942
P16	Power Seat Motor (Driver's Seat Front		T 2	Throttle Position Sensor	90980-10711
F 10	Vertical Control)	90980-10825	Т3	Telephone Microphone	90980-11369
	Power Seat Motor (Driver's Seat Rear Vertical Control)	0000-10020	T 4	Theft Deterrent ECU	90980-11392

Note: Not all of the above part numbers of the connector are established for the supply. In case of ordering a connector or terminal with wire, please confirm in advance if there is supply for it using "Parts Catalog News" (published by Parts Engineering Administration Dept.).

Nota: Toutes les références du connecteur ne sont pas définies pour la fourniture. Pour passer une commande d'un connecteur ou d'une borne avec fil, prière de vérifier préalablement si cette pièce est bien disponible en se reportant à "Parts Catalog News" (publié par le Département de la Gestion de l'Ingénierie).

-	

Code	Part Name	Part Number	Code	Part Name	Part Number
T 5	Theft Deterrent ECU	90980-11424	V 2	VSV (ACIS)	90980-11149
Т6	Traction Cut SW (A/T)	90980-11013	V 3	VSV (EVAP)	90980-11156
10	Traction Cut SW and Snow SW (M/T)	90980-10933	V 4	Vanity Light LH	
T 7	Transponder Key Amplifier (LHD)	90980-10789	V 5	Vanity Light RH	90980-10621
1 7	Transponder Key Amplifier (RHD)	90980-10933	W 1	Washer Motor	90980-10981
T 8	Telephone Transceiver and Speaker Relay	90980-10799	W 2	Water Temp. Sensor	90980-10737
Т9	Telephone Transceiver and Speaker Relay	90980-10798	WЗ	Water Temp. SW	90980-11235
T10	Theft Warning Siren	90980-10942	W 4	Wireless Door Lock ECU	90980-11909
U 1	Unlock Warning SW and Key Interlock Solenoid	90980-10795	W 5	Woofer Speaker LH	00000 11010
			W 6	Woofer Speaker RH	90980-11012
V 1	Vacuum Sensor	90980-10845	W 6	Woofer Speaker RH	


Nota : No todos los números de las partes del conector indicados arriba están dispuestos para el suministro. Al pedir un conector o terminal con cable, asegúrese, de antemano, de que esté suministrado refiriéndose a "Parts Catalog News" (publicado por el Departamento Administrativo de Ingeniería de las Partes).

Anmerkung: Nicht alle der obenerwähnten Teile-Nummern der Stecker werden für die Lieferung etabliert. Im Falle der Bestellung von Stecker oder Anschlußklemme mit Draht bestätigen Sie bitte unter Verwendung der "Teile-Prospekt-Nachtrichten" (herausgegeben durch die Teile-Engineering-Verwaltungsabteilung) im voraus, ob es entsprechende Lieferung gibt.

517

516

\* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the wiring diagram section.



[A] : System Tifle

[B] : Indicates the wiring color.

Wire colors are indicated by an alphabetical code.

B = Black W = White BR = Brown

L = Blue V = Violet SB = Sky Blue


R = Red G = Green LG = Light Green

P = Pink Y = Yellow GR = Gray

O = Orange

The first letter indicates the basic wire color and the second letter indicates the color of the stripe.

Example: L - Y





- [C]: The position of the parts is the same as shown in the wiring diagram and wire routing.
- [D] : Indicates the pin number of the connector.

  The numbering system is different for female and male connectors.

Example: Numbered in order from upper left to lower right

Numbered in order from upper right to lower left






The numbering system for the overall wiring diagram is the same as above.


[E] : Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B.

Example: 1 Indicates Relay Block No.1

[F] : Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it).
Junction Blocks are shaded to clearly separate them from other parts.



- [G] : Indicates related system.
- [H] : Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows ( ⋈ ). Outside numerals are pin numbers.



- [1] : ( ) is used to indicate different wiring and connector, etc. when the vehicle model, engine type, or specification is different.
- [J] : Indicates a shielded cable.



- [K]: Indicates and located on ground point.
- [L] : The same code occurring on the next page indicates that the wire harness is continuous.

# **ELECTRICAL WIRING DIAGRAM**


# SYSTEM INDEX (LHD)


SYSTEMS LOCATION	SYSTEMS LOCATION
ABS and Traction Control	LEXUS Navigation System
Automatic Air Conditioner	Moon Roof 15–1
Back-Up Light5-4	Multiplex Communication System
Cellular Mobile Telephone	Power Seat
Charging1-4	Power Source
Cigarette Lighter	Radiator Fan and Condenser Fan
Clock 19–4	Radio and Player (6 Speaker) 21-2
Combination Meter	Radio and Player (8 Speaker) 22-1
Cruise Control	Rear Fog Light8-2
ECT and A/T Indicator 10-2	Rear Window Defogger and Mirror Heater 18-2
Engine Control and Engine Immobiliser System 2-2	Remote Control Mirror
Front Fog Light	Seat Heater
Front Window Deicer	Shift Lock
Headlight (w/ Daytime Running Light)	SRS 13-1
Headlight (w/o Daytime Running Light)4-1	Starting and Ignition
Headlight Beam Level Control	Taillight and Stop Light5-1
Headlight Cleaner8-4	Turn Signal and Hazard Warning Light
Horn	Wiper and Washer
Illumination6-1	


SYSTEM INDEX (RHD)


LOCATION	SYSTEMS LOCATION
37–1	LEXUS Navigation System
50–2	Moon Roof 40–1
34–1	Multiplex Communication System
29–4	Power Seat
	Power Source
26–4	Radiator Fan and Condenser Fan
44-2	Radio and Player (6 Speaker) 46-2
44-4	Radio and Player (8 Speaker) 47-1
48-2	Rear Fog Light 32-2
36-2	Rear Window Defogger and Mirror Heater
51-2	Remote Control Mirror
35–2	Seat Heater
27–2	Shift Lock
28–4	SRS 38–1
43–1	Starting and Ignition
28–1	Taillight and Stop Light
	Theft Deterrent
	Turn Signal and Hazard Warning Light
İ	Wiper and Washer
	39–1
	LOCATION         37-1         50-2         34-1         29-4         42-1         26-4         44-2         44-4         36-2         51-2         35-2         27-2         28-4         32-3         32-4         30-1


### 1 IS 200 (LHD) ELECTRICAL WIRING DIAGRAM Starting and Ignition Charging Power Source 3 2 W-L B-L IG1 IG2 Ф B-W 9 EA1 ₹ I15 □ IGNITION SW 10A GAUGE 7.6A STARTER To Engine ECU(M/T) or Engine and ECT ECU(A/T) <2-11> (TK) To Engine ECU(M/T) or Engine and ECT ECU(A/T) <2-10><2-11> 2 EA1 B-W I 1 1 IG1 IGNITION COIL . IGNITER NO. 1 IGNITION COI I 2 T = I = I GNITION COIL / IGNITER NO. 2 $\bigcirc$ 1 N 1 NEUTRAL START SW E 2(A), E 6(E) ENGINE ECU(M/T) OR ENGINE AND ECT ECU(A/T) N COIL NO. 3 N COIL IG5 IGT5 IGT6 IGT4 IG3 IGT3 IGT IG2 IGT2 GND GND GND IGF3 GND GND 8 EA1 JUNCTION CONNECTOR N 2 NOISE FILTER (Ignition) S4A, S5B STARTER $\mathbb{H}$ W-B BATTERY A12(A), A13(B) W-B W-B ALTERNATOR Cowl side panel LH Rear side of cylinder head















### 5 IS 200 (LHD) Taillight and Stop Light Power Source Back-Up Light 2 3 G-R G-W \* 1 : w/ Daytime Running Light \* 2 : w/o Daytime Running Light \* 3 : M/T w/ LEXUS Navigation System **IGNITION SW** STOP LIGHT SW \* 4 : M/T w/o LEXUS Navigation System R-L To ABS and R-L G-W Traction ECU <12-3> J 2 A, J 3 JUNCTION E B CONNECTOR J2A, J3B 2(E) ◍ ♨ 6(11) (1K) 12(11) **Ф**В A (A/T) 3 (A) (A/T) 3 (A) (M/T) 3 (A) (M/T) 8 (M/T) 8 (M/T) 8 (M/T) 9 (M/T) 1 (M/T) 1 (M/T) 1 (M/T) 1 (M/T) MBINATION METER $\bigcirc$ RELAY 10A TAIL 6**B** 1(10) 12**(1K)** 13**(**1H) 9(11) 2(IF) J15 JUNCTION CONNECTOR TAIL J 2 A, J JUNCTION CONNECTOR DAYTIME J2A, J3B RUNNING LIGHT LIGHT FAILURE SENSOR RELAY IL2 ST+ GND EL 2 BD1 2 BD2 OFF JUNCTION CONNECTOR L 2 LICENSE PLATE LIGHT RH G-B W-B F 2 FRONT CLEARANCE LIGHT RH F1 FRONT CLEARANCE LIGHT LH TAIL (്) HEAD J11 JUNCTION (4) (1) (1) $^{\scriptsize{\textcircled{3}}}$ CONNECTOR H16 HIGH MOUNTED STOP LIGHT 1 BD1 BD2 + **A** A A (3) (4) (9) ( ) To Combination Meter<23-2> To Navigation ECU<20-2> To Combinati Meter<23-2> To Navigatior ECU<20-2> REAR COMBINATION LIGHT RH REAR COMBINATION ≶ LIGHT LH J17 W-B W-B JUNCTION CONNECTOR JUNCTION JUNCTION CONNECTOR CONNECTOR Cowl side Left quarter panel LH **7**Left quarter panel LH IG \ ID BK BK panel RH panel LH ÷













9 IS 200 (LHD) (Cont' d) (Cont. next page)





Z


































## 19 IS 200 (LHD) Cigarette Lighter Power Source Clock 2 3 В IG1 I15 IGNITION SW 10A RADIO NO. 2 10A MPX-B GR J 6 JUNCTION CONNECTOR ACC A14 CLOCK [A/C CONTROL ASSEMBLY] C 8 CIGARETTE LIGHTER OUTSIDE TEMP. GAUGE 10:00 GND 20A ECU-B1 J 7 JUNCTION CONNECTOR BATTERY W-B A J 5 JUNCTION CONNECTOR Left fender apron Cowl side panel RH Cowl side panel LH



### 21 IS 200 (LHD) Radio and Player (6 Speaker) Power Source 2 3 \* 1 : w/ LEXUS Navigation System \* 2 : w/o LEXUS Navigation System I15 IGNITION SW 10A RADIO NO: 2 A29 ANTENNA AMPLIFIER JUNCTION CONNECTOR R 2 (A), R 3 (B), R 4 (C), R 5 (D) RADIO AND PLAYER FR+ RR+ TMUT GND 1**①** 5**D** 1**(**) 3**(**C) 2**A** 2**©** 7**D** 20A RADIO NO. 1 120A ALT 13 IB2 12 IB1 (\*2) 4 IB2 T 8(A), T 9(B) TELEPHONE TRANSCEIV SPEAKER RELAY To Navigation ECU <20-3><20-4> F13 FRONT DOOR TWEETER SPEAKER LH F14 FRONT DOOR TWEETER SPEAKER RH BATTERY F12 FRONT DOOR SPEAKER RH F11 FRONT DOOR SPEAKER LH R15 REAR SPEAKER R14 REAR SPEAKER LH Front floor panel center RH



23 IS 200 (LHD)

Combination Meter

Combination Meter

