# **ENGINE CONTROL SYSTEM**

# SECTION EC

EW

LC

EC

FE

GL

MT

#### **MODIFICATION NOTICE:**

DDECALITIONS AND DDEDADATION

- TB45S engine has been newly adopted.
- For the TB45S engine specifications other than those described here, refer to TB42S engine of Service Manual (SM7E-1Y61G0, SM7E-2Y61G0) and Supplement-I (SM8E-Y61AG0).
- The Wiring Diagrams on models with the TB45E and TD42 engines have been changed.
- The ZD30DDTi engine has been replaced by the RD28ETi engine.

# **CONTENTS**

Charles Carrier Tool (TD45C)
Special Service Tool (TB45S)5
Special Service Tool (ZD30DDTi)5
Supplemental Restraint System (SRS) "AIR
BAG" and "SEAT BELT PRE-TENSIONER"5
TB45E
ENGINE AND EMISSION CONTROL OVERALL
<b>SYSTEM</b> 6
Circuit Diagram6
TROUBLE DIAGNOSIS FOR "OVER HEAT" (DTC
<b>28)</b>
Cooling Fan Control (Overheat)7
TROUBLE DIAGNOSIS FOR NON-DETECTABLE
ITEMS8
Fuel Pump8
IACV-FICD Solenoid Valve9
MIL & Data Link Connectors10
TB45S
15433
ENGINE AND EMISSION CONTROL OVERALL
<b>SYSTEM</b> 12
Component Parts Location12
Circuit Diagram14
CARBURETOR15
Construction15
Fuel Level
Automatic Choke20
Fast Idle21
Fuel Cut Control System22
ISC-FI Pot
ELECTRIC FUEL PUMP
Description24

Operation24 Wiring Diagram - FPCM25	AT
Inspection	TF
Wiring Diagram - IGN	PD
Boost Controlled Deceleration Device (BCDD)31	FA
TD	RA
QUICK-GLOW SYSTEM       32         Circuit Diagram       32         FAST IDLE CONTROL CIRCUIT       33         Wiring Diagram       33	BR
ENGINE ROOM FAN MOTOR ELECTRICAL CIRCUIT	ST
Wiring Diagram         34           FUEL CUT SYSTEM         35           Wiring Diagram         35	RS
ZD30DDTi	BT
TROUBLE DIAGNOSIS - INDEX	HA
Precautions39 ENGINE AND EMISSION CONTROL OVERALL	EL
ECCS-D Component Parts Location	SE
System Diagram	IDX

# CONTENTS (Cont'd)

ENGINE AND EMISSION BASIC CONTROL		Diagnostic Procedure	
SYSTEM DESCRIPTION	50	DTC 0104 VEHICLE SPEED SEN	
Fuel Injection Control System	50	Description	127
Fuel Injection Timing Control System	52	ECM Terminals and Reference Value	127
Air Conditioning Cut Control	52	On Board Diagnosis Logic	127
Fuel Cut Control (at no load & high engine		Overall Function Check	128
speed)	52	Wiring Diagram	129
Crankcase Ventilation System	53	Diagnostic Procedure	130
BASIC SERVICE PROCEDURE	54	DTC 0203 ACCEL POS SW (F/C)	131
Injection Tube and Injection Nozzle	54	Description	131
Electronic Control Fuel Injection Pump	57	CONSULT-II Reference Value in Data Monitor	
Air Bleeding	62	Mode	131
ON BOARD DIAGNOSTIC SYSTEM		ECM Terminals and Reference Value	131
DESCRIPTION	63	On Board Diagnosis Logic	131
DTC and MI (MIL) Detection Logic	63	DTC Confirmation Procedure	132
Diagnostic Trouble Code (DTC)	63	Wiring Diagram	133
Malfunction Indicator (MI), Malfunction Indicator		Diagnostic Procedure	
Lamp (MIL)	64	DTC 0208 OVER HEAT	
CONSULT-II	69	Description	136
TROUBLE DIAGNOSIS - INTRODUCTION	76	CONSULT-II Reference Value in Data Monitor	
Introduction	76	Mode	136
Work Flow	78	ECM Terminals and Reference Value	137
TROUBLE DIAGNOSIS - BASIC INSPECTION	80	On Board Diagnosis Logic	137
Basic Inspection	80	Overall Function Check	
TROUBLE DIAGNOSIS - GENERAL		Wiring Diagram	
DESCRIPTION	86	Diagnostic Procedure	
Symptom Matrix Chart	86	Main 12 Causes of Overheating	
CONSULT-II Reference Value in Data Monitor		DTC 0301 ECM 2, DTC 0901 ECM 12	
Mode	96	Description	
Major Sensor Reference Graph in Data Monitor		On Board Diagnosis Logic	
Mode		DTC Confirmation Procedure	
ECM Terminals and Reference Value		Diagnostic Procedure	149
TROUBLE DIAGNOSIS FOR INTERMITTENT		DTC 0402 P9 FUEL TEMP SEN	
INCIDENT	107	Description	150
Description	107	CONSULT-II Reference Value in Data Monitor	
Diagnostic Procedure		Mode	151
TROUBLE DIAGNOSIS FOR POWER SUPPLY	108	ECM Terminals and Reference Value	151
Main Power Supply and Ground Circuit	108	On Board Diagnosis Logic	151
DTC 0102 MASS AIR FLOW SEN	117	DTC Confirmation Procedure	152
Component Description	117	Wiring Diagram	153
CONSULT-II Reference Value in Data Monitor		Diagnostic Procedure	154
Mode	117	DTC 0403 ACCEL POS SENSOR	156
ECM Terminals and Reference Value	117	Description	156
On Board Diagnosis Logic	117	CONSULT-II Reference Value in Data Monitor	
DTC Confirmation Procedure	118	Mode	156
Wiring Diagram	119	ECM Terminals and Reference Value	157
Diagnostic Procedure		On Board Diagnosis Logic	157
DTC 0103 COOLANT TEMP SEN		DTC Confirmation Procedure	158
Description		Wiring Diagram	159
On Board Diagnosis Logic	123	Diagnostic Procedure	161
DTC Confirmation Procedure		DTC 0406 INT AIR VOL	
Wiring Diagram	124	On Board Diagnosis Logic	169

# CONTENTS (Cont'd)

G[

DTC Confirmation Procedure	169	Description	202	
Diagnostic Procedure	170	CONSULT-II Reference Value in Data Monitor		MA
DTC 0407 CRANK POS SEN (TDC)	171	Mode	203	
Description		ECM Terminals and Reference Value	203	ED A
CONSULT-II Reference Value in Data Monitor		On Board Diagnosis Logic	203	EM
Mode	171	DTC Confirmation Procedure		
ECM Terminals and Reference Value	171	Wiring Diagram		LC
On Board Diagnosis Logic		Diagnostic Procedure		
DTC Confirmation Procedure		DTC 0705 P5-PUMP C/MODULE		
Wiring Diagram		Description		EC
Diagnostic Procedure		CONSULT-II Reference Value in Data Monitor	200	
DTC 0502 BATTERY VOLTAGE		Mode	200	
On Board Diagnosis Logic		ECM Terminals and Reference Value		FE
DTC Confirmation Procedure		On Board Diagnosis Logic		
		DTC Confirmation Procedure		
Diagnostic Procedure				GL
DTC 0504 A/T COMM LINE		Diagnostic Procedure		
System Description		DTC 0707 P7 F/INJ TIMG FB		0.052
ECM Terminals and Reference Value		Description	211	MT
On Board Diagnosis Logic		CONSULT-II Reference Value in Data Monitor	0.40	
DTC Confirmation Procedure		Mode		AT
Overall Function Check		ECM Terminals and Reference Value		/=\_U
Wiring Diagram		On Board Diagnosis Logic		
Diagnostic Procedure		DTC Confirmation Procedure		TF
DTC 0701 P1 CAM POS SEN		Wiring Diagram		0 0
Description	184	Diagnostic Procedure		
CONSULT-II Reference Value in Data Monitor		DTC 0802 ECM 10	218	PD
Mode	185	Description	218	
ECM Terminals and Reference Value	185	On Board Diagnosis Logic	218	
On Board Diagnosis Logic	185	DTC Confirmation Procedure	218	FA
DTC Confirmation Procedure	186	Diagnostic Procedure	219	
Wiring Diagram	187	DTC 0804 ECM 11	220	
Diagnostic Procedure	188	Description	220	RA
DTC 0702 P2-TDC PULSE SIG	190	On Board Diagnosis Logic	220	
Description	190	DTC Confirmation Procedure	220	BR
CONSULT-II Reference Value in Data Monitor		Diagnostic Procedure	221	
Mode	191	DTC 0807 ECM 14	222	
ECM Terminals and Reference Value	191	Description		ST
On Board Diagnosis Logic		ECM Terminals and Reference Value		-
DTC Confirmation Procedure		On Board Diagnosis Logic		
Wiring Diagram		DTC Confirmation Procedure		RS
Diagnostic Procedure		Wiring Diagram		
DTC 0703 P3-PUMP COMM LINE		Diagnostic Procedure		
Description		DTC 0902 ECM RLY		BT
CONSULT-II Reference Value in Data Monitor		ECM Terminals and Reference Value		
Mode	197	On Board Diagnosis Logic		HA
ECM Terminals and Reference Value		DTC Confirmation Procedure		II II/=/
On Board Diagnosis Logic		Wiring Diagram		
DTC Confirmation Procedure				EL
Wiring Diagram		Diagnostic Procedure  DTC 0903 ECM 15		
Diagnostic Procedure		Description		SE
DTC 0704 P4 SPILL/V CIRC, DTC 0706 P6 SPIL		On Board Diagnosis Logic		
VALVE	202	DTC Confirmation Procedure	∠3 I	11500

# CONTENTS (Cont'd)

Diagnostic Procedure	232	
DTC 0905 TURBO PRESSURE	233	
Component Description	233	
ECM Terminals and Reference Value	233	
On Board Diagnosis Logic		
DTC Confirmation Procedure		IN
Wiring Diagram		S
Diagnostic Procedure		
DTC 1003 EGR VOLUME CONT/V		
Description		
CONSULT-II Reference Value in Data Monitor	200	
	220	V
Mode ECM Terminals and Reference Value		C
		C
DTC Confirmation Procedure		
Wiring Diagram		
Diagnostic Procedure		
DTC 1004 FUEL CUT SYSTEM1		
Description	246	
CONSULT-II Reference Value in Data Monitor		
Mode		E
ECM Terminals and Reference Value		S
On Board Diagnosis Logic		
DTC Confirmation Procedure	248	
Wiring Diagram	249	
Diagnostic Procedure	250	
GLOW CONTROL SYSTEM	252	
Description	252	
ECM Terminals and Reference Value		ΑI
Wiring Diagram	254	
Diagnostic Procedure	255	M
START SIGNAL	261	
Wiring Diagram	261	
Diagnostic Procedure	262	
PARK/NEUTRAL POSITION (PNP) SWITCH	264	_
Description	264	SI
CONSULT-II Reference Value in Data Monitor		
Mode	264	
ECM Terminals and Reference Value	264	
Wiring Diagram	265	
Diagnostic Procedure		SI
HEAT UP SWITCH	272	O.
Component Description	272	
CONSULT-II Reference Value in Data Monitor		
Mode	272	
ECM Terminals and Reference Value	272	
Wiring Diagram		
Diagnostic Procedure		
SWIRL CONTROL VALVE CONTROL SOLENOID		
VALVE	277	
Description		

CONSULT-II Reference value in Data Monitor	
Mode	
ECM Terminals and Reference Value	278
Wiring Diagram	279
Diagnostic Procedure	
INTAKE AIR CONTROL VALVE CONTROL	
SOLENOID VALVE	285
Description	
ECM Terminals and Reference Value	
Wiring Diagram	
Diagnostic Procedure	
VARIABLE NOZZLE TURBOCHARGER	01
CONTROL SOLENOID VALVE	202
Description	
CONSULT-II Reference Value in Data Monitor	232
	202
Mode	
ECM Terminals and Reference Value	
Wiring Diagram	
Diagnostic Procedure	295
EXHAUST GAS CONTROL VALVE CONTROL	
SOLENOID VALVE	
Description	300
CONSULT-II Reference Value in Data Monitor	
Mode	
ECM Terminals and Reference Value	
Wiring Diagram	301
Diagnostic Procedure	
AIR CONDITIONER CONTROL	306
Wiring Diagram	306
MI (MIL) & DATA LINK CONNECTORS	307
Wiring Diagram	307
TB45S	
SERVICE DATA AND SPECIFICATIONS (SDS)	
General Specifications	
Inspection and Adjustment	309
ZD30DDTi	
OFFICION AND OFFICIATIONS (OFFI	040
SERVICE DATA AND SPECIFICATIONS (SDS)	
General Specifications	
Injection Pump Numbers	
Injection Nozzle	
Engine Coolant Temperature Sensor	
Crankshaft Position Sensor (TDC)	
Glow Plug	
Accelerator Position Sensor	310
FGR Volume Control Valve	310

#### PRECAUTIONS AND PREPARATION

Tool number Tool name	Description
KV10108300 Idle adjusting screwdriver	NT270

## Special Service Tool (ZD30DDTi)

Tool number Tool name	Description	
KV10109300 Puller holder	a lo	0
	NT628	a = 68 mm (2.68 in) b = 8 mm (0.31 in) dia.

# Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER" used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS system composition which is available to NISSAN MODEL Y61 is as follows (The composition varies according to the destination and optional equipment.):

- For a frontal collision
  - The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.
- For a side collision
  - The Supplemental Restraint System consists of front side air bag module (located in the outer side of front seat), satellite sensor, diagnosis sensor unit (one of components of air bags for a frontal collision), wiring harness, warning lamp (one of components of air bags for a frontal collision).

Information necessary to service the system safely is included in the RS section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral cable and wiring harnesses covered with yellow insulation tape either just before the harness connectors or for the complete harness are related to the SRS.

MA

EM

LC

EC

FE

<u>@</u>[

MT

AT

P

<u></u>

PD)

FA

20

BR

200

ם ע

RS

BT


HA


EL

SE


 $\mathbb{D}\mathbb{X}$ 


#### **Circuit Diagram**






### **Fuel Pump**






#### **MIL & Data Link Connectors**



#### MIL & Data Link Connectors (Cont'd) GI EC-MIL/DL-02 IGNITION SWITCH ON or START BATTERY MA FUSE BLOCK 10A Refer to EL-POWER. (J/B) 28 24 (M3) , (M6) EM 6F 6A W/R W/B : Detectable line for DTC LC : Non-detectable line for DTC L : LHD models W/B W/B EC R: RHD models 9 COMBINATION 16 8 METER (MALFUNCTION INDICATOR LAMP) DATA LINK CONNECTOR FE M32), M34) (M10) Y/G GL 4 13 12 14 5 Y/R Y/G Y/B В MT 2 $\lceil 4 \rceil$ JOINT CONNEC-TOR-1 AT (M79) 4 2 Y/G Y/R Y/G TF M52 F7 1 7 8 23 22 24 Y/R Y/B Y/G Y/G PD 32 21 22 31 47 JOINT CONNECTOR-5 CSC MIL CSR CST CHECK FA **ECM** (F25) (F8) RA BR ST (M30) (F24) (F23) (M19) (M98): (R) Refer to last page (Foldout page). (M3)



TEC090M


BT

HA

EL

SE


## **Component Parts Location**




#### TB45S

# **ENGINE AND EMISSION CONTROL OVERALL SYSTEM**

# **Component Parts Location (Cont'd)**





G[

MA

EM

LC

EC

FE

GL

MT

AT

TF

PD

FA

RA

BR

ST

RS


BT


HA

EL


SE

# **Circuit Diagram**






# Construction (Cont'd)



# Construction (Cont'd)



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS


BT


HA


EL

SE

SEF963X







# Fuel Level INSPECTION

Disconnect ignition wire between distributor and ignition coil. Disconnect fuel cut solenoid valve connector of carburetor. Α NG Check primary main nozzle to ensure that Check needle valve for no fuel is discharging while cranking looseness or sticking. If engine for approximately 3 seconds. necessary, repair or replace. OK Adjust fuel level. В NG Check that acceleration pump nozzle injects fuel when throttle valve is opened. OK

If necessary, use Tool to visually check fuel level as follows:

- 1. Disconnect inlet fuel hose from carburetor, and plug opening.
- 2. Start engine and wait for it to stop.

**END** 

3. Install Tool on carburetor, as shown.

#### Be careful not to spill fuel.

- 4. Connect inlet hose to carburetor.
- 5. Start engine. Visually check fuel level.

If out of specification, adjust by bending float seat and float stopper.

#### **CARBURETOR**

# Fuel Level (Cont'd)






- 1. Remove carburetor from engine.
- Remove float chamber cover from float chamber.



Turn carburetor upside down, and fix it horizontally. Raise float fully, then lower it slowly until float seat contacts



EM

LC

7.0 - 8.0 mm (0.276 - 0.315 in)

If out of specification, adjust by bending float seat. Make sure needle valve slides smoothly on float seat.


EC

FE

GL

MT

AT



Height "H<sub>2</sub>":

44.5 - 45.5 mm (1.752 - 1.791 in)

If out of specification, adjust by bending float stopper.

6. Install choke chamber and then place carburetor on engine.

7. Perform "FUEL LEVEL INSPECTION".

TF

PD


FA


RA

BR


HA


EL






#### **Automatic Choke**







#### Fast Idle

1. Warm up engine.

2. Set fast idle arm on 2nd step of fast idle cam.

3. Check fast idle speed.

Fast idle speed (at 2nd cam step): 1,600±200 rpm

Make sure that engine is completely adjusted (idle speed, ignition timing, etc.) before checking or adjusting fast idle speed.

GI

MA

EM

LC

4. If out of specification, remove carburetor and make fast idle adjustments as follows:

1) Place fast idle arm on 2nd step of fast idle cam, in the same manner as in step 2. above.

2) Adjust clearance "A" between primary throttle valve and inner carburetor wall by turning fast idle adjusting screw.

Clearance "A":

1.37±0.14 mm (0.0539±0.0055 in)

5. After adjusting clearance "A", install carburetor on engine and check engine speed.

Following installation, do not attempt further adjustment of clearance "A" even if fast idle speed is incorrect.

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

0<u>5</u>

P2


HA

EL

\_\_\_

# **Fuel Cut Control System**


EC-FCUT-01








Refer to last page (Foldout page).




## **Description**

Electric fuel pump is controlled by fuel pump control module. This module drives electric fuel pump in response to the signals from alternator "L" terminal, ignition switch and oil pressure switch.





# Operation

Ignition switch position	Engine	Alternator	Oil pressure	Fuel pump	
OFF					
ACC	Stopped	Not generating	No pressure	Not operating	
ON		Trot goneraming			
START	Cranking		Low pressure		
		Generating	2011 procedio		
	Granking	Not generating			
		Generating Normal		Operating	
	Running	Failure			
	_	Generating	Failure	1	



# Wiring Diagram — FPCM — (Cont'd)





#### Inspection

Fuel pump control module is located under the left side of dash panel.

Check input signals in each terminal of fuel pump control module, following the table shown below.

#### GI

MA

EM

LC

EC

MT

AT

TF

PD

FA

RA

BR

#### INPUT SIGNAL CHECK

Check terminals		O a madistica a	Circuit tester			
	+	_	Condition	Range	Reading	_
Ground	(5)		_	Ω	0Ω	_
Dottom: (ON or CTADT)			Ignition switch "ON"		Battery voltage	_
Battery (ON or START)	2		Ignition switch "START*"			
Pottory (ACC or ON)			Ignition switch "ON"			
Battery (ACC or ON)	1	Body earth	Ignition switch "START*"	V	0V	_
Alternator "L" terminal		Journ	Engine running	V	Battery voltage	_
Alternator L terminal	4	4	Engine stopped		0V	_
Oil progues quitab			Engine running		Battery voltage	_
Oil pressure switch	3		Engine stopped		0V	_

<sup>\*:</sup> Disconnect starter motor "S" terminal before turning ignition switch "START".


If NG, check harness continuity between fuel pump control module and each component, or check each component individually. If OK, perform fuel pump control module check.

#### FUEL PUMP CONTROL MODULE CHECK

- First, disconnect starter motor "S" terminal.
- This check should be performed without starting engine.

Cton		Condition		Output valtage of terminal (6)	\$1
Step	Alternator "L" terminal	Oil pressure switch terminal	Ignition switch	Output voltage of terminal 6	
1			OFF		- R:
2	Commonted		ACC	0V	
3	Connected	Connected	ON		_ B'
4		Connected –	START		
5			ON		H
6	Diagramatad		START		U U <i>l</i>
7			ON	Battery voltage	
8		Diagonalist	START		
9		Connected –	ON		0.5
10	Connected		START		\$[

If NG, replace fuel pump control module.



# Inspection (Cont'd)

#### **FUEL PUMP**

- 1) Make sure that ignition switch is "OFF".
- 2) Disconnect fuel pump harness connector.
- 3) Check resistance between fuel pump connector terminals 4 and 6.

Resistance: Approximately 0.2 -  $5\Omega$ 

#### **FUEL PRESSURE CHECK**

#### **WARNING:**

- Keep flammables away during the test.
- For safety, the test must be completed in as short a time as possible.
- 1. Connect a suitable fuel pressure gauge.
- 2. Check fuel pressure.

Fuel pressure (Approximately):

14.7 kPa (0.147 bar, 0.15 kg/cm<sup>2</sup>, 2.1 psi)


If out of specification, check for fuel filter clogging or improper fuel pump operation.


## GI Wiring Diagram — IGN — **PICKUP MODELS** MA EC-IGN-01 BATTERY EM Refer to EL-POWER. LC L : LHD models R: RHD models \*1 GY: \(\) EC SB: R IGNITION SWITCH OFF ( (E114) FE GL MT To EL-METER CONDENSER AT TF PD FA RA DISTRIBUTOR (E31) ത്ത BR IGNITION COIL (E23) ST RS SPARK PLUG (E40) BT HA EL

TEC091M

SE

## Wiring Diagram — COOL/F —







**EC-31** 

#### **Circuit Diagram**


#### **EXCEPT FOR COLD AREAS**








## **Wiring Diagram**





Refer to last page (Foldout page).


# GI **Wiring Diagram** EC-FCUT-01 MA IGNITION SWITCH ON or START FUSE BLOCK (J/B) Refer to EL-POWER. 10A 25 (M2) LC EC FE CO: For cold areas GL XC : Except for cold areas (M21) \*1 12K: CO MT 8K : XC AT TF \_E68 PD FA RA BR INJECTION PUMP (FUEL CUT SOLENOID VALVE) ST RS Refer to last page (Foldout page). BT M21), E127) (M2) HA EL SE

TEC741

#### TD


# Wiring Diagram (Cont'd)

# EC-FCUT-02











# **Alphabetical & Numerical Index for DTC**

# ALPHABETICAL INDEX FOR DTC

X: Applicable	—: Not applicable

Items (CONSULT-II screen terms)	DTC	MI (MIL) illumination	Reference page	
ACCEL POS SENSOR	0403	X	EC-156	
ACCEL POS SW (F/C)	0203	X	EC-131	– LC
A/T COMM LINE	0504	_	EC-179	
BATTERY VOLTAGE	0502	_	EC-177	EC
COOLANT TEMP SEN	0103	X	EC-123	_ EG
CRANK POS SEN (TDC)	0407	X	EC-171	
ECM 2	0301	X	EC-148	- FE
ECM 10	0802	X	EC-218	_
ECM 11	0804	_	EC-220	- GL
ECM 12	0901	X	EC-148	_
ECM 14	0807	X	EC-222	_ MT
ECM 15	0903	_	EC-231	_
ECM RLY	0902	X	EC-227	_ AT
EGR VOLUME CONT/V	1003	X	EC-238	_
FUEL CUT SYSTEM1	1004	X	EC-246	— TF
INT/AIR VOLUME	0406	_	EC-169	
MASS AIR FLOW SEN	0102	X	EC-117	_ _ PD
NATS MALFUNCTION	1401 - 1408	_	EL section	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	0505	_	_	FA
OVER HEAT	0208	X	EC-136	_ RA
P1-CAM POS SEN	0701	X	EC-184	
P2-TDC PULSE SIG	0702	X	EC-190	_ _ BR
P3-PUMP COMM LINE	0703	X	EC-196	
P4-SPILL/V CIRC	0704	X	EC-202	– – ST
P5-PUMP C/MODULE	0705	X	EC-208	_ 01
P6-SPILL VALVE	0706	X	EC-202	
P7·F/INJ TIMG FB	0707	X	EC-211	– RS
P9-FUEL TEMP SEN	0402	X	EC-150	_
TURBO PRESSURE	0905	X	EC-233	BT
VEHICLE SPEED SEN	0104	Х	EC-127	<u> </u>

G[

 $\mathbb{M}\mathbb{A}$ 

PD

HA

EL

SE


# TROUBLE DIAGNOSIS — INDEX


# Alphabetical & Numerical Index for DTC (Cont'd)


# **NUMERICAL INDEX FOR DTC**


X: Applicable —: Not applicable


			X: Applicable —: Not applicable
DTC	Items (CONSULT-II screen terms)	MI (MIL) illumination	Reference page
0102	MASS AIR FLOW SEN	X	EC-117
0103	COOLANT TEMP SEN	Х	EC-123
0104	VEHICLE SPEED SEN	Х	EC-127
0203	ACCEL POS SW (F/C)	Х	EC-131
0208	OVER HEAT	X	EC-136
0301	ECM 2	X	EC-148
0402	P9-FUEL TEMP SEN	Х	EC-150
0403	ACCEL POS SENSOR	Х	EC-156
0406	INT/AIR VOLUME	<del>_</del>	EC-169
0407	CRANK POS SEN (TDC)	X	EC-171
0502	BATTERY VOLTAGE	_	EC-177
0504	A/T COMM LINE	_	EC-179
0505	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	-	_
0701	P1-CAM POS SEN	X	EC-184
0702	P2·TDC PULSE SIG	X	EC-190
0703	P3-PUMP COMM LINE	X	EC-196
0704	P4·SPILL/V CIRC	X	EC-202
0705	P5-PUMP C/MODULE	X	EC-208
0706	P6-SPILL VALVE	X	EC-202
0707	P7·F/INJ TIMG FB	X	EC-211
0802	ECM 10	X	EC-218
0804	ECM 11	<del>-</del>	EC-220
0807	ECM 14	X	EC-222
0901	ECM 12	X	EC-148
0902	ECM RLY	X	EC-227
0903	ECM 15		EC-231
0905	TURBO PRESSURE	X	EC-233
1003	EGR VOLUME CONT/V	X	EC-238
1004	FUEL CUT SYSTEM1	X	EC-246
1401 - 1408	NATS MALFUNCTION	_	EL section












## **Precautions**



Do not attempt to disconnect battery cable while engine is

Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery terminal. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.

Before removing parts, turn off ignition switch and then disconnect battery ground cable.

Do not disassemble ECM.

If a battery terminal is disconnected, the memory will return to the ECM value.

The ECM will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.

When ECM is removed for inspection, make sure to ground the ECM mainframe.

When connecting ECM harness connector, tighten securing bolt until the gap between the orange indicators disap-

: 3.0 - 5.0 N·m (0.3 - 0.5 kg-m, 26 - 43 in-lb)

When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break).

Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.

Securely connect ECM harness connectors. A poor connection can cause an extremely high (surge) voltage to develop in the circuit, thus resulting in damage

Keep ECM harness at least 10 cm (3.9 in) away from adjacent harnesses, to prevent an ECM system malfunction DX

MA

LC

EC

MT

AT

FA

RA

BR


HA

EL


# **Precautions (Cont'd)**


due to receiving external noise, degraded operation of ICs, etc.


Keep ECM parts and harnesses dry.



Before replacing ECM, perform Terminals and Reference Value inspection and make sure ECM functions properly. Refer to EC-99.








- If MI (MIL) illuminates or blinks irregularly when engine is running, water may have accumulated in fuel filter. Drain water from fuel filter. If this does not correct the problem, perform specified trouble diagnostic procedures.
- After performing each TROUBLE DIAGNOSIS, perform "DTC Confirmation Procedure" or "Overall Function Check".


The DTC should not be displayed in the "DTC Confirmation Procedure" if the repair is completed. The "Overall Function Check" should be a good result if the repair is completed.

- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact.
  - Accidental contact of probes will cause a short circuit and damage the ECM power transistor.
- Do not use ECM ground terminals when measuring input/ output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

## **PRECAUTIONS**

# **Precautions (Cont'd)**





Do not disassemble electronic fuel injection pump. If NG, take proper action.

Do not disassemble injection nozzle. If NG, replace injection nozzle.

Even a slight leak in the air intake system can cause serious problems.


Do not shock or jar the crankshaft position sensor (TDC).

EC

MA

EM

LC



Do not depress accelerator pedal when starting.

Immediately after starting, do not rev up engine unnecessarily.


Do not rev up engine just prior to shutdown.

GL

FE

MT

AT



Keep the antenna as far as possible away from the ECM.

2) Keep the antenna feeder line more than 20 cm (7.9 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.

3) Adjust the antenna and feeder line so that the standingwave ratio can be kept smaller.

Be sure to ground the radio to vehicle body.

RA

BR


ST

BT


HA

EL

SE




# **ECCS-D Component Parts Location**





<sup>\*:</sup> Only models for cold areas


# **ECCS-D Component Parts Location (Cont'd)**


## Electronic control fuel injection pump











GI

MA

EM

LC

EC

FE

GL

MT

AT

TF

PD

FA

RA

BR

ST

RS


BT

HA

EL

SE

# **ECCS-D Component Parts Location (Cont'd)**



Intake air control valve control actuator

GI

MA

EM

LC

EC

FE

GL

MT

AT

TF

PD

FA

RA

BR

ST

RS


BT

HA


EL


SE


# ECCS-D Component Parts Location (Cont'd)




View from under the vehicle









# **Circuit Diagram**





# **Vacuum Hose Drawing**



- Swirl control valve control solenoid valve to 3-way connector
- Swirl control valve control solenoid valve to swirl control valve actua-
- 3. Vacuum gallery to 3-way connec-
- Intake air control valve control solenoid valve to intake air control valve actuator
- Intake air control valve control solenoid valve to 3-way connector
- Variable nozzle turbocharger control solenoid valve to vacuum tank
- Vacuum tank to vacuum gallery
- Variable nozzle turbocharger control actuator to vacuum damper
- Variable nozzle turbocharger control solenoid valve to vacuum damper
- 10. Variable nozzle turbocharger control solenoid valve to resonator
- 11. Vacuum pump to vacuum gallery
- 12. Exhaust gas control valve control solenoid valve to 3-way connector
- 13. Exhaust gas control valve control solenoid valve to exhaust gas control valve actuator

Refer to "System Diagram", EC-47 for vacuum control system.

# **System Chart**

Input (Sensor)	ECM Function	Output (Actuator)
Electronic control fuel injection pump	Fuel injection control	Electronic control fuel injection pump
<ul><li>Crankshaft position sensor (TDC)</li><li>Engine coolant temperature sensor</li></ul>	Fuel injection timing control	Electronic control fuel injection pump
<ul> <li>Accelerator position sensor</li> <li>Accelerator position switch</li> <li>Accelerator switch (F/C)</li> <li>Park/Neutral position (PNP) switch</li> <li>Ignition switch</li> </ul>	Fuel cut control	Electronic control fuel injection pump
	Glow control system	Glow relay & glow lamp
	On board diagnostic system	MIL (On the instrument panel)
	EGR volume control	EGR volume control valve
Battery voltage	Cooling fan control	Cooling fan relay
<ul> <li>Vehicle speed sensor</li> <li>Air conditioner switch</li> <li>Mass air flow sensor</li> <li>Stop lamp switch</li> <li>Heat up switch</li> <li>Charge air pressure sensor*1</li> </ul>	Air conditioning cut control	Air conditioner relay
	Variable nozzle turbocharger control	Variable nozzle turbocharger control sole- noid valve
	Swirl control valve control	Swirl control valve control solenoid valve
	Intake air control valve control	Intake air control valve control solenoid valve
	Exhaust gas control valve control*2	Exhaust gas control valve control solenoid valve*2

<sup>\*1:</sup> This sensor is not used to control the engine system under normal conditions.



MA

EM

LC

EC

FE

GL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

SE

<sup>\*2:</sup> For models for cold areas

ZD30DDTi

# **Fuel Injection Control System**

#### DESCRIPTION

## System description


Three types of fuel injection control are provided to accommodate engine operating conditions; normal control, idle control and start control. The ECM determines the appropriate fuel injection control. Under each control, the amount of fuel injected is compensated to improve engine performance.

Pulse signals are exchanged between ECM and electronic control fuel injection pump (control unit is built-in). The fuel injection pump control unit performs duty control on the spill valve (built into the fuel injection pump) according to the input signals to compensate the amount of fuel injected to the preset value.

#### Start control

#### Input/output signal chart

Sensor	Input Signal to ECM	ECM Function	Actuator
Engine coolant temperature sensor	Engine coolant temperature		
Crankshaft position sensor (TDC)	l Engine speed		Electronic control fuel injection pump
Ignition switch	Start signal	tror (diarr dominor)	tion pamp



When the ECM receives a start signal from the ignition switch, the ECM adapts the fuel injection system for the start control. The amount of fuel injected at engine starting is a preset program value in the ECM. The program is determined by the engine speed and engine coolant temperature.

For better startability under cool engine conditions, the lower the coolant temperature becomes, the greater the amount of fuel injected. The ECM ends the start control when the engine speed reaches the specific value, and shifts the control to the normal or idle control.

#### Idle control

#### Input/output signal chart

Sensor	Input Signal to ECM	ECM Function	Actuator
Engine coolant temperature sensor	Engine coolant temperature		
Crankshaft position sensor (TDC)	Engine speed		
Park/Neutral position (PNP) switch	Gear position		
Battery	Battery voltage	Fuel injection con-	Electronic control fuel injec-
Accelerator position switch	Idle position	trol (Idle control)	tion pump
Vehicle speed sensor	Vehicle speed		
Air conditioner switch	Air conditioner signal		
Heat up switch	Heat up switch signal		

When the ECM determines that the engine speed is at idle, the fuel injection system is adapted for the idle control. The ECM regulates the amount of fuel injected corresponding to changes in load applied to the engine to keep engine speed constant. The ECM also provides the system with a fast idle control in response to the engine coolant temperature and heat up switch signal.

# **ENGINE AND EMISSION BASIC CONTROL SYSTEM** DESCRIPTION

**ZD30DDTi** 

# **Fuel Injection Control System (Cont'd)**

# Normal control


Input/output signal chart

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor (TDC)	Engine speed	Fuel injection con-	
Accelerator position sensor		trol (Normal con-	Electronic control fuel injection pump
Vehicle speed sensor	Vehicle speed	trol)	aon pamp



LC

MA




FE

The fuel injection data, predetermined by correlation between various engine speeds and accelerator positions, are stored in the ECM memory, forming a map. The ECM determines the optimal amount of fuel to be injected using the sensor signals in comparison with the map.

MT

AT



Accelerator

opening larger

**ECM Function** Input Signal to ECM Sensor Actuator Mass air flow sensor Amount of intake air Fuel injection con-Engine coolant temperature sensor Engine coolant temperature Electronic control fuel injectrol (Maximum tion pump Crankshaft position sensor (TDC) Engine speed amount control) Accelerator position sensor Accelerator position

FA

RA

The maximum injection amount is controlled to an optimum by the engine speed, intake air amount, engine coolant temperature, and accelerator opening in accordance with the driving conditions.

BR

This prevents the oversupply of the injection amount caused by decreased air density at a high altitude or during a system failure.

# Deceleration control Input/output signal chart

Sensor Input Signal to ECM **ECM Function** Actuator Fuel injection con-Accelerator switch (F/C) Accelerator position Electronic control fuel injectrol (Deceleration tion pump Crankshaft position sensor (TDC) Engine speed control)

The ECM sends a fuel cut signal to the electronic control fuel injection pump during deceleration for better fuel efficiency. The ECM determines the time of deceleration according to signals from the accelerator switch (F/C) and crankshaft position sensor (TDC).

HA

EL

# ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

ZD30DDTi

# **Fuel Injection Timing Control System**

#### **DESCRIPTION**

The target fuel injection timing in accordance with the engine speed and the fuel injection amount are recorded as a map in the ECM beforehand. The ECM and the injection pump control unit exchange signals and perform feedback control for optimum injection timing in accordance with the map.

# **Air Conditioning Cut Control**

#### DESCRIPTION

#### Input/output signal chart

Sensor	Input Signal to ECM	ECM Function	Actuator
Air conditioner switch	Air conditioner "ON" signal		
Accelerator position sensor	Accelerator valve opening angle  Air conditioner cut Air conditioner cut	Air conditioner relay	
Vehicle speed sensor	Vehicle speed	control	
Engine coolant temperature sensor	Engine coolant temperature		

## System description

This system improves acceleration when the air conditioner is used.

When the accelerator pedal is fully depressed, the air conditioner is turned off for a few seconds.

When engine coolant temperature becomes excessively high, the air conditioner is turned off. This continues until the engine coolant temperature returns to normal.

# Fuel Cut Control (at no load & high engine speed)

#### **DESCRIPTION**

#### Input/output signal chart

Sensor	Input Signal to ECM	ECM Function	Actuator
Vehicle speed sensor	Vehicle speed		
Park/Neutral position (PNP) switch	Neutral position		
Accelerator position switch or Accelerator switch (F/C)	Accelerator position	Fuel cut control	Electronic control fuel injection pump
Engine coolant temperature sensor	Engine coolant temperature		
Crankshaft position sensor (TDC)	Engine speed		

If the engine speed is above 2,700 rpm with no load (for example, in neutral and engine speed over 2,700 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed. Fuel cut will operate until the engine speed reaches 1,500 rpm, then fuel cut is cancelled.

#### NOTE:


This function is different from deceleration control listed under "Fuel Injection Control System", EC-50.


ZD30DDTi

# **Crankcase Ventilation System**

#### **DESCRIPTION**

In this system, blow-by gas is sucked into the air inlet pipe after oil separation by oil separator in the rocker cover.





## **INSPECTION**

# **Ventilation hose**

- 1. Check hoses and hose connections for leaks.
- 2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.

EM

MA

LC

EC

FE

GL

MT

AT

PD

TF

RA

FA

BR

ST

38

9T

1 11 /2

HA

EL


SE


# Injection Tube and Injection Nozzle

#### REMOVAL AND INSTALLATION

#### **CAUTION:**

- Do not disassemble injection nozzle assembly. If NG, replace injection nozzle assembly.
- Plug flare nut with a cap or rag so that no dust enters the nozzle. Cover nozzle tip for protection of needle.





#### Injection tube

#### Removal

- Mark the cylinder Nos. to the injection tubes, then disconnect them.
- Marking should be made at proper locations and by the proper method, so that they are not erased by fuel, etc.
- 2. Remove the clamps, then disconnect the tubes one by one.
- Avoid letting leaked fuel get on the interior walls of the engine compartment.

Take special care to prevent fuel from getting on the engine mount insulator.

# Injection Tube and Injection Nozzle (Cont'd)

#### Installation


Install the injection tubes, referring to the markings made during removal.

Install the injection tubes in the order of No. 3, No. 4, No. 1, and No. 2.



LC

EC



Injection nozzle assembly

O-ring

Nozzle gasket

#### Injection nozzle oil seal

#### Removal

Using a tool such as a flat-bladed screwdriver, pry the flange of the seal, then remove it.

# Installation

After the injection nozzle assembly is installed, push the seal from the cylinder head side until it contacts the flange.

 Replace the oil seal with new one when the injection nozzle assembly is removed. (It is not necessary to replace the oil seal when only injection tubes are removed.)

# AT

MT

#### Spill tube

#### Installation

- After the spill tube is installed, check the airtightness of the spill tube.
- After the bolts are tightened, the joint of the spill tube gasket might be broken. However, this will not affect function.





PD


# RA

# Injection nozzle assembly

#### Removal

Nozzle support

JEF249Z



Using a tool such as a flat-head screwdriver, remove the copper washer inside the cylinder head.



#### **CAUTION:**

# Do not disassemble the injection nozzle.

# Installation

1. Insert the nozzle gasket to the cylinder head hole.

2. Attach the O-ring to the mounting groove of the nozzle side, then insert it in the cylinder head.



#### **TEST AND ADJUSTMENT**

#### **WARNING:**


When using nozzle tester, be careful not to allow diesel fuel sprayed from nozzle to contact your hands or body, and make sure your eyes are properly protected with goggles.





HA


SE











# Injection Tube and Injection Nozzle (Cont'd)

## Inspection for spill tube airtightness

Before the rocker cover is installed, perform the inspection as fol-

- 1. Connect the handy vacuum pump to the spill hose.
- 2. Check that the airtightness is maintained after the negative pressure shown below is applied.

#### Standard:

-53.3 to -66.7 kPa (-533 to -667 mbar, -400 to -500 mmHg, -15.75 to -19.69 inHg)

# Air bleeding of fuel piping

After the repair, bleed air in the piping by pumping the priming pump up and down until it becomes heavy.

# Injection pressure test

1. Install injection nozzle assembly to injection nozzle tester and bleed air from flare nut.

- 2. Pump the tester handle slowly (one time per second) and watch the pressure gauge.
- 3. Read the pressure gauge when the injection pressure just starts dropping.

```
Initial injection pressure:
```

Used


19,026 kPa (190.3 bar, 194 kg/cm<sup>2</sup>, 2,759 psi)

19,516 - 20,497 kPa (195.2 - 205.0 bar, 199 - 209 kg/cm<sup>2</sup>, 2,830 - 2,972 psi)

Limit

16,182 kPa (161.8 bar, 165 kg/cm<sup>2</sup>, 2,346 psi)

The injection nozzle assembly has a 2-stage pressure injection function. However, the judgement should be made at the first stage of the valve opening pressure.



# Injection Tube and Injection Nozzle (Cont'd)

Spray pattern test

 Check spray pattern by pumping tester handle one full stroke per second.

NG spray pattern:

Does not inject straight and strong (B in the figure).

Fuel drips (C in the figure).

Does not inject evenly (D in the figure).

2. If the spray pattern is not correct, replace injection nozzle assembly.

GI

EM

MA


LC

# **Electronic Control Fuel Injection Pump**

#### REMOVAL AND INSTALLATION

#### **CAUTION:**

When removing or installing the timing chain as incidental work of the fuel injection pump removal/installation, always secure the internal mechanism of the idler gear with bolts before removing or installing the fuel injection pump sprocket. Do not refer to the procedure for "TIMING CHAIN" in EM section based on No. 1 cylinder compression top dead center. (Unless otherwise specified.)



EC

U

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL


SE

# Electronic Control Fuel Injection Pump (Cont'd) REMOVAL

- 1. Remove the following:
- Engine coolant draining
- Charge air cooler
- Air inlet pipe
- Throttle body
- Rocker cover
- Oil level gauge guide
- EGR guide tube
- EGR volume control solenoid valve
- Fuel hose
- Injection tube
- Radiator upper hose
- Radiator shroud
- Cooling fan
- Drive belt
- Vacuum pipe
- Vacuum pump
- 2. Move the power steering pump.




- 3. Remove the harness connector from the fuel injection pump.
- After pulling the connector stopper all the way back, remove the connector.
- When the stopper is pulled all the way back, the interlockedconnector will come off.
  - As for installation, when the connector is pushed all the way forward until the stopper locks, the interlocked-connector is inserted.
- 4. Remove the fuel injection pump rear bracket.



- Remove the chain cover.
- Remove the installation bolts A, B, and C shown in the figure (left).


# **CAUTION:**


During chain cover removal, seal the opening to prevent foreign objects from getting into the engine.





- 6. Fix the internal mechanism of the idler gear (scissors gear structure).
- a. Remove the plug on the front side of the gear case.
- b. While turning the crankshaft pulley clockwise, check the tightening bolt hole of the idler gear internal mechanism through the plug hole.
- Conduct the visual check using a mirror.
- When checking, note that there are 2 other holes (with no thread) beside the tightening bolt hole on the idler gear.

#### View with gear case / Fuel injection pump removed > ldler gear∕ gear and & stopper bolt Plug hole hole Stopper bolt Fan coupling ldler gear (A) JEF263Z









c. Install the tightening bolt [Part No.: 81-20620-28, thread diameter: M6, under head: 20 mm (0.79 in), pitch: 1.0 mm (0.039 in)] to the idler gear tightening bolt hole, and tighten to the specified torque:

**②** : 2.5 - 3.4 N⋅m (0.25 - 0.35 kg-m, 22 - 30 in-lb)

CAUTIO

- To protect the idler gear from damage, do not use the substitute part for the tightening bolt.
- Hereafter, do not turn the crankshaft to avoid hitting tightening bolt head against the gear case.
- Do not remove the idler gear tightening bolt before installations of the timing chain and related parts are completed.
- 7. Make mating marks on the cam sprocket, fuel injection pump sprocket, and timing chain with paint.
- Make mating marks on the fuel injection pump gear and idler gear with paint.

- Remove the chain tensioner.
- Loosen the upper and lower installation bolts.
- (2) While holding the chain tensioner by hand, remove the upper installation bolt to release the spring tension.
- (3) Remove the lower installation bolt first, and then the chain ten-
- Since the chain tensioner does not have a mechanism to prevent the plunger pop-out, watch out for the fall of the plunger and spring. (Return prevention mechanism is available.)
- 10. Remove the timing chain slack guide.
- 11. Remove the cam sprocket and timing chain at the same time.
- Make mating marks on each sprocket and timing chain.
- Hold the hexagon head of the camshaft on the exhaust manifold side, and loosen the cam sprocket installation bolt.

#### **CAUTION:**

Do not loosen the installation bolt using a chain tension.

- 12. Remove the fuel injection pump sprocket and gear as an assembly.
- Fix the fuel injection pump gear with the pulley holder (SST), and loosen the installation bolt for removal.
- Try not to move the pump shaft when removing.
- Connect the sprocket and gear with a dowel pin, and tighten them together with the installation bolt.

MA

EM

LC

EC

FE

GL

MT

AT

PD


FA

RA

BR

ST

BT




# Electronic Control Fuel Injection Pump (Cont'd)

- 13. Make the mating marks on the fuel injection pump flange and front plate with paint.
- 14. Remove installation bolts first, and then fuel injection pump toward the rear side of the engine.
- When the fuel injection pump is stationary, it can still be retained by the dowel without all bolts.


#### **CAUTION:**

Do not disassemble or adjust the fuel injection pump.




#### **INSTALLATION**


- The injection timing adjustment to correct the installation angle deviation is not necessary. Install the pump in the proper position according to the dowel and installation bolts.
- 1. Install the fuel injection pump from the rear side of the engine.
- Match the dowel of the spacer to the dowel hole of the pump side for installation.
- Replace the seal washer of the installation bolt with a new one.



- 2. Align the mating marks of the fuel injection pump flange and front plate, and then adjust the approximate flange position.
- Each hole [6 mm (0.24 in) dia.] is used as a reference point for the fuel injection pump flange, fuel injection pump gear, and fuel injection pump sprocket.
- Only during removal/installation at No. 1 cylinder compression top dead center, can the hole [6 mm (0.24 in) dia.] of the pump body be aligned.



- Install the fuel injection pump sprocket and gear as an assembly.
- Align the mating marks of the idler gear and fuel injection pump gear properly.




- 4. Tighten the installation bolt of the fuel injection pump sprocket.
- Fix the fuel injection pump gear with the pulley holder (SST), and tighten the installation bolt.


#### **CAUTION:**

Before tightening the installation bolt, check again that the mating marks of the idler gear and fuel injection pump gear are aligned.

# Timing chain Camshaft Fuel injection pump gear Fuel injection pump lidler gear sprocket JEF264Z

# Gear case Plug Apply liquid gasket. JEF272Z





# **Electronic Control Fuel Injection Pump (Cont'd)**

- 5. Install the cam sprocket and timing chain at the same time.
- Align the mating marks of the fuel injection pump sprocket and cam sprocket, and install the timing chain.
- Holding the hexagon head of the camshaft with a wrench, tighten the cam sprocket installation bolt.

## **CAUTION:**

Do not tighten the installation bolt using a chain tension.

- 6. Install the timing chain, related parts, and the chain cover. Refer to EM section, "TIMING CHAIN".
- 7. Remove the tightening bolt of the idler gear internal mechanism.
- 8. Apply the liquid gasket to the screw of the plug, and tighten the plug.
- 9: 7.9 9.8 N·m (0.8 1.0 kg-m, 70 86 in-lb)
- Use Genuine Liquid Gasket or equivalent.
- Install the fuel injection pump rear bracket.
- Tighten all the installation bolts temporarily, and then tighten them firmly with both surfaces of the fuel injection pump and cylinder block attached to the installation surface.

- 10. Connect the harness connector of the fuel injection pump.
- Insert the harness connector until the stopper is completely locked.
- When the connector is pushed fully to lock the stopper, the interlocked-connector is inserted.

11. Installation is in the reverse order of removal.

GI

MA

EM

LC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS


BT

HA

EL

SE


 $\mathbb{Z}$ 



# Air Bleeding

Pump the priming pump to bleed air.

- When air is bled completely, the pumping of the priming pump suddenly becomes heavy. Stop operation at that time.
- If it is difficult to bleed air by the pumping of the priming pump (the pumping of the priming pump does not become heavy), disconnect the fuel supply hose between the fuel filter and the injection pump. Then, perform the operation described above, and make sure that fuel comes out. (Use a pan, etc. so as not to spill fuel. Do not let fuel get on engine and other parts.) After that, connect the hose, and then bleed air again.



When a malfunction is detected, the malfunction (DTC) is stored in the ECM memory.

The MI (MIL) will light up each time the ECM detects malfunction. For diagnostic items causing the MI (MIL) to light up, refer to "TROUBLE DIAGNOSIS — INDEX", EC-37.

# MA EM

LC

GI

# **Diagnostic Trouble Code (DTC)**

#### **HOW TO READ DTC**

The DTC can be read by the following methods.



## Without CONSULT-II

ECM displays the DTC by a set of four digit numbers with MI (MIL) illumination in the diagnostic test mode II (Self-diagnostic results). Example: 0102, 0407, 1004, etc.



#### With CONSULT-II

CONSULT-II displays the DTC in "SELF-DIAG RESULTS" mode. Examples: "CRANK POS SEN (TDC)", etc.

 Output of the trouble code means that the indicated circuit has a malfunction. However, in the Mode II it does not indicate whether the malfunction is still occurring or occurred in the past and returned to normal.

CONSULT-II can identify them. Therefore, using CONSULT-II (if available) is recommended.


#### **HOW TO ERASE DTC**

# How to erase DTC (( With CONSULT-II)


- 1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.
- 2. Touch "ENGINE".
- 3. Touch "SELF-DIAG RESULTS".
- Touch "ERASE". (The DTC in the ECM will be erased.)


# How to erase DTC (With CONSULT-II)


If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once.
 Wait at least 5 seconds and then turn it "ON" again.



urn CONSULT-II "ON" and touch	3. Touch "SELF-
NGINE".	







ECM will be erased.)

SEF371Y

The emission related diagnostic information in the ECM can be erased by selecting "ERASE" in the "SELF-DIAG RESULTS" mode with CONSULT-II.

# How to erase DTC (Without CONSULT-II)

- 1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.
- 2. Change the diagnostic test mode from Mode II to Mode I by using the data link connector. (See EC-66.) The emission related diagnostic information in the ECM can be erased by changing the diagnostic test mode.

EC

FE

MT

AT

PD

TF

FA

RA

BR

**⊘** I

KS


HA

EL

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

# Diagnostic Trouble Code (DTC) (Cont'd)


- If the battery is disconnected, the emission-related diagnostic information will be lost after approx.
   24 hours.
- Erasing the emission-related diagnostic information using CONSULT-II is easier and quicker than switching the diagnostic test mode using the data link connector.



# NATS (Nissan Anti-Theft System)

- If the security indicator lights up with the ignition switch in the "ON" position or "NATS MALFUNCTION" is displayed on "SELF-DIAG RESULTS" screen, perform self-diagnostic results mode with CONSULT-II using NATS program card. Refer to "NATS (Nissan Anti-Theft System)" in EL section.
- Confirm no self-diagnostic results of NATS is displayed before touching "ERASE" in "SELF-DIAG RESULTS" mode with CONSULT-II.
- When replacing ECM, initialization of NATS system and registration of all NATS ignition key IDs must be carried out with CONSULT-II using NATS program card.

Therefore, be sure to receive all keys from vehicle owner. Regarding the procedures of NATS initialization and NATS ignition key ID registration, refer to CONSULT-II operation manual, NATS.



# Malfunction Indicator (MI), Malfunction Indicator Lamp (MIL)

#### **DESCRIPTION**

The MI (MIL) is located on the instrument panel.

- 1. The MI (MIL) will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
- If the MI (MIL) does not light up, refer to EL section ("WARN-ING LAMPS AND CHIME") or see EC-307.
- 2. When the engine is started, the MI (MIL) should go off. If the MI (MIL) remains on, the on board diagnostic system has detected an engine system malfunction.

If MI (MIL) illuminates or blinks irregularly after starting engine, water may have accumulated in fuel filter. Drain water from fuel filter. Refer to MA section.

## ZD30DDTi

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

# Malfunction Indicator (MI), Malfunction Indicator Lamp (MIL) (Cont'd)

# G[

# On board diagnostic system function

The on board diagnostic system has the following three functions.

INVA	/ <sub>A</sub> \
TIAL	

Diagnostic Test Mode	KEY and ENG. Status	Function	Explanation of Function	
Mode I	Ignition switch in ON position	BULB CHECK	This function checks the MI (MIL) bulb for damage (blown, open circuit, etc.). If the MI (MIL) does not come on, check MI (MIL) circuit. (See EC-307.)	EN LC
	Engine stopped			EC
	Engine running	MALFUNCTION WARNING	This is a usual driving condition. When ECM detects a malfunction, the MI (MIL) will light up to inform the driver that a malfunction has been detected.	FE . GL
Mode II	Ignition switch in ON position	SELF-DIAGNOSTIC RESULTS	This function allows DTCs to be read.	Mi
	Engine stopped			AT
			-	TF



PD FA

RA

BR

ST

RS

BT


HA

EL

SE

# Malfunction Indicator (MI), Malfunction Indicator Lamp (MIL) (Cont'd)

# How to switch diagnostic test modes



SEF372YA

# Malfunction Indicator (MI), Malfunction Indicator Lamp (MIL) (Cont'd)

# Diagnostic test mode I — Bulb check

In this mode, the MI (MIL) on the instrument panel should stay ON. If it remains OFF, check the bulb. Refer to EL section, "WARNING LAMPS AND CHIME" or see EC-307.

# er MA

GI


## Diagnostic test mode I — Malfunction warning


MI (MIL) Condition		Condition
ON		When the malfunction is detected or the ECM's CPU is malfunctioning.
OFF		No malfunction.

LC

# Diagnostic test mode II — Self-diagnostic results

In this mode, DTC is indicated by the number of blinks of the MI (MIL) as shown below.





Long (0.6 second) blinking indicates the two LH digits of number and short (0.3 second) blinking indicates the two RH digits of number. For example, the MI (MIL) blinks 10 times for 6 seconds (0.6 sec x 10 times) and then it blinks three times for about 1 second (0.3 sec x 3 times). This indicates the DTC "1003".

In this way, all the detected malfunctions are classified by their DTC numbers. The DTC "0505" refers to no malfunction. (See TROUBLE DIAGNOSIS — INDEX, EC-37.)

#### How to erase diagnostic test mode II (Self-diagnostic results)

The DTC can be erased from the backup memory in the ECM when the diagnostic test mode is changed from Diagnostic Test Mode II to Diagnostic Test Mode I. (Refer to "How to Switch Diagnostic Test Modes", EC-66.)

- If the battery terminal is disconnected, the DTC will be lost from the backup memory within 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL


SE

# Malfunction Indicator (MI), Malfunction Indicator Lamp (MIL) (Cont'd)

Relationship between MI (MIL), DTC, CONSULT-II and driving patterns



- \*1: When a malfunction is detected, MI (MIL) will light up.
- \*2: When the same malfunction is detected in two consecutive driving patterns, MI (MIL) will stay lit up.
- \*3: MI (MIL) will go off after vehicle is driven three times without any malfunctions.
- \*4: When a malfunction is detected for the first time, the DTC will be stored in ECM.
- \*5: The DTC will not be displayed any longer after vehicle is driven 40 times without the same malfunction. (The DTC still remain in ECM.)
- \*6: Other screens except SELF-DIAG-NOSTIC RESULTS & DATA MONITOR (AUTO TRIG) cannot display the malfunction. DATA MONITOR (AUTO TRIG) can display the malfunction at the moment it is detected.



SELECT SYSTEM	
ENGINE	
	SEF995X

SELECT DIAG MODE	
SELF-DIAG RESULTS	
DATA MONITOR	
ACTIVE TEST	
ECM PART NUMBER	
	SEF320Y

# **CONSULT-II**

## **CONSULT-II INSPECTION PROCEDURE**

1. Turn ignition switch OFF.

2. Connect CONSULT-II to data link connector, which is located under the driver side dash panel.

GI

MA

LC

3. Turn ignition switch ON.

- 4. Touch "START".
- 5. Touch "ENGINE".
- 6. Perform each diagnostic test mode according to each service procedure.

## For further information, see the CONSULT-II Operation Manual.

EC

·Ľ

GL

MT

AT

TF

PD

FA

RA

BR

ST

BT

HA

EL

SE

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

# CONSULT-II (Cont'd) ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

		DIAGNOSTIC TEST MODE			
n		SELF-DIAG RESULTS	DATA MONI- TOR	ACTIVE TEST	
	Engine coolant temperature sensor	X	Х		
	Vehicle speed sensor	X	Х		
	Accelerator position sensor	X	Х	Х	
	Accelerator position switch	Х	Х		
	Accelerator switch (F/C)	X	Х		
!	Crankshaft position sensor (TDC)	X	Х		
INPUT	Ignition switch (start signal)		Х		
INPUT	Park/Neutral position (PNP) switch		Х		
	Battery voltage		Х		
	Air conditioner switch		Х		
INPUT	Mass air flow sensor	X	Х		
	Stop lamp switch	X	Х		
	Heat up switch		Х		
	Charge air pressure sensor	X			
	Glow relay		X	Х	
	EGR volume control valve	X	Х	Х	
	Cooling fan relay	X	Х	Х	
OUTPUT	Air conditioner relay		Х		
	Variable nozzle turbocharger control solenoid valve		Х		
	Swirl control valve control solenoid valve		Х	Х	
	Exhaust gas control valve control solenoid valve		Х		

X: Applicable

## **SELF-DIAGNOSTIC MODE**

Regarding items detected in "SELF-DIAG RESULTS" mode, refer to "TROUBLE DIAGNOSIS — INDEX", EC-37.

## **DATA MONITOR MODE**

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
CKPS-RPM (TDC) [rpm]	0	0	The engine speed computed from the crankshaft position sensor (TDC) signal is displayed.	
CMPS-RPM-PUMP [rpm]	0	0	The engine speed computed from the pulse signal sent from electronic control fuel injection pump is displayed.	
COOLAN TEMP/S [°C] or [°F]	0	0	The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed.	When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine cool- ant temperature determined by the ECM is displayed.

ZD30DDTi

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

# CONSULT-II (Cont'd)

		l	, ,		- G
Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks	_ M
VHCL SPEED SE [km/h] or [mph]	0	0	The vehicle speed computed from the vehicle speed sensor signal is displayed.		
FUEL TEMP SEN [°C] or [°F]	0	0	The fuel temperature (sent from electronic control fuel injection pump) is displayed.		– E1 _ L(
ACCEL POS SEN [V]	0	0	The accelerator position sensor signal voltage is displayed.		
FULL ACCEL SW [ON/OFF]	0	0	Indicates [ON/OFF] condition from the accelerator position switch signal.		E
ACCEL SW (FC) [OPEN/CLOSE]	0	0	Indicates [OPEN/CLOSE] condition from the accelerator switch (FC) signal.		- FE
OFF ACCEL SW [ON/OFF]	0	0	Indicates [ON/OFF] condition from the accelerator position switch signal.		- G
SPILL/V [°CA]		0	The control position of spill valve (sent from electronic control fuel injection pump) is displayed.		_ M
BATTERY VOLT [V]	0	0	The power supply voltage of ECM is displayed.		_ A1
P/N POSI SW [ON/OFF]	0	0	Indicates [ON/OFF] condition from the park/neutral position switch signal.		– – TI
START SIGNAL [ON/OFF]	0	0	Indicates [ON/OFF] condition from the starter signal.	After starting the engine, [OFF] is displayed regardless of the starter signal.	— 11
AIR COND SIG [ON/OFF]	0	0	<ul> <li>Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal.</li> </ul>		– P(
BRAKE SW [ON/OFF]	0	0	Indicates [ON/OFF] condition from the stop lamp switch signal.		— F/
IGN SW [ON/OFF]	0	0	Indicates [ON/OFF] condition from ignition switch signal.		R
WARM UP SW [ON/OFF]	0		Indicates [ON/OFF] condition from the heat up switch signal.		_ B[
MAS AIR/FL SE [V]	0	0	The signal voltage of the mass air flow sensor is displayed.	When the engine is stopped, a certain value is indicated.	– Si
DECELER F/CUT [ON/OFF]		0	The [ON/OFF] condition from deceleration fuel cut signal (sent from electronic control fuel injection pump) is displayed.		_ R(
INJ TIMG C/V [%]		0	The duty ratio of fuel injection timing control valve (sent from electronic control fuel injection pump) is displayed.		- B
AIR COND RLY [ON/OFF]		0	Indicates the control condition of the air conditioner relay (determined by ECM according to the input signals).		
GLOW RLY [ON/OFF]		0	The glow relay control condition (determined by ECM according to the input signal) is displayed.		_ [3]

ZD30DDTi

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

# CONSULT-II (Cont'd)

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
COOLING FAN [ON/OFF]		0	<ul> <li>Indicates the control condition of the cooling fans (determined by ECM according to the input signal).</li> <li>ON Operates.</li> <li>OFF Stopped.</li> </ul>	
EGR VOL CON/V [step]		0	<ul> <li>Indicates the EGR volume control value computed by the ECM according to the input signals.</li> <li>The opening becomes larger as the value increases.</li> </ul>	
VNT S/V 1 [%]			Indicates the variable nozzle turbo- charger control solenoid valve control value computed by the ECM according to the input signals.	
BARO SEN [kPa]	0		The barometric pressure (determined by the signal voltage from the barometric pressure sensor built into the ECM) is displayed.	
SWRL CON S/V 1 [ON/OFF]		0	<ul> <li>The control condition of the swirl control valve control solenoid valve (determined by ECM according to the input signals) is indicated.</li> <li>ON Swirl control valve is closed.</li> <li>OFF Swirl control valve is opened.</li> </ul>	
EXH/GAS REG V [ON/OFF]			<ul> <li>The control condition of the exhaust gas control valve control solenoid valve (computed by ECM according to the input signals) is indicated.</li> <li>ON Exhaust gas control valve is closed.</li> <li>OFF Exhaust gas control valve is opened.</li> </ul>	This item is applicable for cold area models.     On other models, "OFF" is always displayed.

#### NOTE:

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

#### ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

# CONSULT-II (Cont'd)

#### **ACTIVE TEST MODE**

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)	
COOLING FAN	<ul> <li>Ignition switch: ON</li> <li>Operate the cooling fan at "LOW", "HI" speed and turn "OFF" using CONSULT-II.</li> </ul>	Cooling fan moves at "LOW", "HI" speed and stops.	<ul><li>Harness and connector</li><li>Cooling fan motor</li><li>Cooling fan relay</li></ul>	MA EM
OFF ACCEL PO SIG	Clears the self-learning fully closed ECM.	d accelerator position, detected by acc	celerator position sensor, from the	LC
GLOW RLY	<ul> <li>Ignition switch: ON (Engine stopped)</li> <li>Turn the glow relay "ON" and "OFF" using CONSULT-II and listen to operating sound.</li> </ul>	Glow relay makes the operating sound.	<ul><li>Harness and connector</li><li>Glow relay</li></ul>	EC
INJ TIMING*	<ul> <li>Engine: Return to the original trouble condition</li> <li>Retard the injection timing using CONSULT-II.</li> </ul>	If trouble symptom disappears, see CHECK ITEM.	Electronic control fuel injection pump	FE
SWIRL CONT S/V1	<ul> <li>Ignition switch: ON</li> <li>Turn solenoid valve "ON" and "OFF" with the CONSULT-II and listen to operating sound.</li> </ul>	Solenoid valve makes an operating sound.	Harness and connector     Solenoid valve	MT
EGR VOL CONT/V	<ul> <li>Ignition switch: ON</li> <li>Change EGR volume control valve opening step using CON- SULT-II.</li> </ul>	EGR volume control valve makes an operating sound.	Harness and connector     EGR volume control valve	AT TF

<sup>\*:</sup> When using this item, DTC 0707 "P7-F/INJ TIMG FB" may be detected. If so, erase it because it is not a malfunction.



PD

FA

RA

BR

ST

RS


BT

HA

EL

SE

# DATA MONITOR Recording Data...11% NO DTC CKPS-RPM(TDC) XXX rpm CMPS-RPM-PUMP XXX rpm COOLAN TEMP/S XXX °C VHCL SPEED SE XXX km/h FUEL TEMP SEN XXX °C SEF373Y



#### **CONSULT-II (Cont'd)**

#### **REAL TIME DIAGNOSIS IN DATA MONITOR MODE**

CONSULT-II has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.

- 1) "AUTO TRIG" (Automatic trigger):
- The malfunction will be identified on the CONSULT-II screen in real time.

In other words, DTC will be displayed if the malfunction is detected by ECM.

At the moment a malfunction is detected by ECM, "MONITOR" in "DATA MONITOR" screen is changed to "Recording Data ... xx%" as shown at left, and the data after the malfunction detection is recorded. Then when the percentage reached 100%, "REAL-TIME DIAG" screen is displayed. If "STOP" is touched on the screen during "Recording Data ... xx%", "REAL-TIME DIAG" screen is also displayed.

The recording time after the malfunction detection and the recording speed can be changed by "TRIGGER POINT" and "Recording Speed". Refer to CONSULT-II OPERATION MANUAL.

- 2) "MANU TRIG" (Manual trigger):
- DTC will not be displayed automatically on CONSULT-II screen even though a malfunction is detected by ECM.
   DATA MONITOR can be performed continuously even though

Use these triggers as follows:


a malfunction is detected.

- 1) "AUTO TRIG"
- While trying to detect the DTC by performing the "DTC Confirmation Procedure", be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.
- While narrowing down the possible causes, CONSULT-II should be set in "DATA MONITOR (AUTO TRIG)" mode, especially in case the incident is intermittent.
  - When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the "DTC Confirmation Procedure", the moment a malfunction is found the DTC will be displayed. (Refer to GI section, "Incident Simulation Tests" in "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".)
- "MANU TRIG"
- If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT-II to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.

#### ZD30DDTi

#### ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

# CONSULT-II (Cont'd)



G[

MA

EM

LC

EC

FE

\_\_\_

GL

MT

AT

TF

PD

FA

RA

BR

ST

200


BT

HA


UU U

EL

SE







#### Introduction

The engine has an ECM to control major systems such as fuel injection control, fuel injection timing control, glow control system, etc. The ECM accepts input signals from sensors and instantly drives electronic control fuel injection pump. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no problems such as vacuum leaks, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems. A road test with CONSULT-II or a circuit tester connected should be performed. Follow the "Work Flow", EC-78.

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example on next page should be used.

Start your diagnosis by looking for "conventional" problems first. This will help troubleshoot driveability problems on an electronically controlled engine vehicle.

#### **KEY POINTS**

WHAT ..... Vehicle & engine model WHEN ..... Date, Frequencies WHERE ..... Road conditions ..... Operating conditions,

Weather conditions, Symptoms

SEF907L

#### DIAGNOSTIC WORKSHEET

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make troubleshooting faster and more accurate.

In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the one shown below in order to organize all the information for troubleshooting.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

# TROUBLE DIAGNOSIS — INTRODUCTION

# Introduction (Cont'd) Worksheet sample

Customer nai	me MR/MS	Model & Year	VIN							
Engine #		Trans.	Mileage							
Incident Date		Manuf. Date	In Service Date							
	☐ Startability	artability  □ Impossible to start □ No combustion □ Partial combustion □ Partial combustion affected by throttle position □ Partial combustion when engine is cool □ Possible but hard to start □ Others [								
Symptoms	□ Idling	☐ No fast idle ☐ Unstable ☐ H☐ Others [	High idle							
, '	☐ Driveability	☐ Stumble ☐ Surge ☐ Knock ☐ Others [	☐ Lack of power ]							
	☐ Engine stall	☐ At the time of start ☐ While idling ☐ While accelerating ☐ While decelerating ☐ Just after stopping ☐ While loading								
Incident occurrence		☐ Just after delivery ☐ Recently ☐ In the morning ☐ At night ☐ In the daytime								
Frequency		☐ All the time ☐ Under certain conditions ☐ Sometimes								
Weather conditions		☐ Not affected								
	Weather	☐ Fine ☐ Raining ☐ Snowing ☐ Others [ ]								
	Temperature	☐ Hot ☐ Warm ☐ Cool ☐	Cold ☐ Humid °F							
		☐ Cold ☐ During warm-up ☐ After warm-up								
Engine condi	tions	Engine speed  0 2,000	4,000 6,000 8,000 rpm							
Road condition	ons	☐ In town ☐ In suburbs ☐ Hig	jhway ☐ Off road (up/down)							
Driving conditions		<ul> <li>Not affected</li> <li>At starting</li> <li>While idling</li> <li>At racing</li> <li>While accelerating</li> <li>While cruising</li> <li>While decelerating</li> <li>While turning (RH/LH)</li> </ul>								
Malfunction in	ndicator lamp	Vehicle speed  0 10 20  Turned on Not turned on	30 40 50 60 MPH							

RS

MTBL0397


BT

HA

EL

SE

#### **Work Flow**



- \*1 Refer to MA section ("Checking and Replacing Fuel Filter and Draining Water", "ENGINE MAIN-TENANCE").
- \*2 If time data of "SELF-DIAG RESULTS" is other than "0", perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.
- \*3 If the incident cannot be verified, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.
- \*4 If the on board diagnostic system cannot be performed, check main
- power supply and ground circuit. Refer to "TROUBLE DIAGNOSIS FOR POWER SUPPLY", EC-108.
- \*5 If malfunctioning part cannot be detected, perform "TROUBLE DIAGNOSIS FOR INTERMIT-TENT INCIDENT", EC-107.

ZD30DDTi

# TROUBLE DIAGNOSIS — INTRODUCTION Work Flow (Cont'd) DESCRIPTION FOR WORK FLOW

(A)	П
U	U

STEP	DESCRIPTION
STEP I	Get detailed information about the conditions and the environment when the incident/symptom occurred using the "DIAGNOSTIC WORKSHEET", EC-76.
STEP II	Before confirming the concern, check and write down (print out using CONSULT-II) the DTC, then erase the DTC. Refer to EC-63.  If the incident cannot be verified, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107. Study the relationship between the cause, specified by DTC, and the symptom described by the customer. (The "Symptom Matrix Chart" will be useful. Refer to EC-86.) Also check related service bulletins for information.
STEP III	Try to confirm the symptom and under what conditions the incident occurs.  The "DIAGNOSTIC WORK SHEET" is useful to verify the incident. Connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results.  If the incident cannot be verified, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107. If the malfunction code is detected, skip STEP IV and perform STEP V.
STEP IV	Try to detect the DTC by driving in (or performing) the "DTC Confirmation Procedure". Check and read the DTC by using CONSULT-II.  During the DTC verification, be sure to connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results.
SILF IV	If the incident cannot be verified, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107. In case the "DTC Confirmation Procedure" is not available, perform the "Overall Function Check" instead. The DTC cannot be displayed by this check, however, this simplified "check" is an effective alternative. The "NG" result of the "Overall Function Check" is the same as the DTC detection.
STEP V	Take the appropriate action based on the results of STEP I through IV.  If the malfunction code is indicated, proceed to TROUBLE DIAGNOSIS FOR DTC XXXX.  If the normal code is indicated, proceed to the Basic Inspection, EC-80. Then perform inspections according to the Symptom Matrix Chart. Refer to EC-86.
	Identify where to begin diagnosis based on the relationship study between symptom and possible causes.  Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) "Harness Layouts".  Gently shake the related connectors, components or wiring harness with CONSULT-II set in "DATA MONITOR (AUTO TRIG)" mode.  Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CON-
STEP VI	SULT-II. Refer to EC-99 or EC-96.  The "Diagnostic Procedure" in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure. For details, refer to GI section ("Circuit Inspection", "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT").  Repair or replace the malfunction parts.
	If the malfunctioning part cannot be detected, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.
STEP VII	Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint.  Perform the "DTC Confirmation Procedure" and confirm the normal code (DTC No. 0505) is detected. If the inci-
	dent is still detected in the final check, perform STEP VI by using a different method from the previous one.  Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) DTC in ECM.  (Refer to EC-63.)





SE

#### **Basic Inspection**


#### **Precaution:**

Perform Basic Inspection without electrical or mechanical loads applied;

- Shift lever is in neutral position,
- Heat up switch is OFF,
- Headlamp switch is OFF,
- Air conditioner switch is OFF,
- Rear defogger switch is OFF,
- Steering wheel is in the straight-ahead position, etc.

#### 1 INSPECTION START

- 1. Check service records for any recent repairs that may indicate a related problem.
- 2. Check the current need for scheduled maintenance, especially for fuel filter and air cleaner filter. Refer to MA section.
- 3. Open engine hood and check the following:
- Harness connectors for improper connections
- Vacuum hoses for splits, kinks, or improper connections
- Wiring for improper connections, pinches, or cuts



SEF142I

4. Start engine and warm it up to the normal operating temperature.

▶ GO TO 2.

#### 2 PREPARATION FOR CHECKING IDLE SPEED

(P) With CONSULT-II

Connect CONSULT-II to the data link connector.

Without CONSULT-II

Install diesel tacho tester to the vehicle.

▶ GO TO 3.

BT


HA

EL

SE

#### TROUBLE DIAGNOSIS — BASIC INSPECTION

### **Basic Inspection (Cont'd)**




### **Basic Inspection (Cont'd)**

#### 6 **CHECK IDLE SPEED AGAIN** With CONSULT-II 1. Start engine and let it idle. 2. Select "CKPS-RPM (TDC)" in "DATA MONITOR" mode with CONSULT-II. 3. Read idle speed. DATA MONITOR MONITOR NO DTC CKPS-RPM (TDC) XXX rpm SEF817Y Without CONSULT-II 1. Start engine and let it idle. 2. Check idle speed. 750±25 rpm OK or NG OK **INSPECTION END** NG GO TO 7.

7	DRIN WATER FROM FUEL FILTER										
1	Drain water from fuel filter. Refer to MA section ("Checking and Replacing Fuel Filter and Draining Water", "ENGINE MAINTENANCE").										
	<b>•</b>	GO TO 8.									

ZD30DDTi

### **Basic Inspection (Cont'd)**



EL SE

PD

FA

RA

BR

ST

RS

BT

HA

# Basic Inspection (Cont'd)

9	CHECK AIR CLEANER FILTER								
Check air cleaner filter for clogging or breaks.									
	OK or NG								
OK ▶ GO TO 10.									
NG	<b>&gt;</b>	Replace air cleaner filter.							

10	CHECK FUEL INJECTION NOZZLE								
Check fuel injection nozzle opening pressure. Refer to "Injection pressure test", EC-56.									
	OK or NG								
ОК	OK ▶ GO TO 11.								
NG	NG Replace fuel injection nozzle assembly.								

#### 11 CHECK IDLE SPEED AGAIN

#### (I) With CONSULT-II

- 1. Start engine and let it idle.
- 2. Select "CKPS-RPM (TDC)" in "DATA MONITOR" mode with CONSULT-II.
- 3. Read idle speed.

DATA MONITOR									
NO DTC									
XX rpm									
•									

SEF817Y

#### Without CONSULT-II

- 1. Start engine and let it idle.
- 2. Check idle speed.

750±25 rpm


OK or NG

OK ▶	INSPECTION END
NG ▶	GO TO 12.

12	CHECK COMPRESSION F	CHECK COMPRESSION PRESSURE								
Check compression pressure. Refer to EM section, "MEASUREMENT OF COMPRESSION PRESSURE".										
	OK or NG									
ОК	OK ► GO TO 13.									
NG	<b>•</b>	Follow the instruction of "MEASUREMENT OF COMPRESSION PRESSURE".								

ZD30DDTi

### **Basic Inspection (Cont'd)**



FA

 $\mathbb{R}\mathbb{A}$ 

BR

ST

RS

BT

HA

EL

SE

### **Symptom Matrix Chart**

	SYMPTOM														
	HARD/NO START/RESTART (EXCP. HA)			ENGINE STALL											
SYSTEM — Basic engine control system	NO START (with first firing)	NO START (without first firing)	HARD TO START WHEN ENGINE IS COLD	HARD TO START WHEN ENGINE IS HOT	AT IDLE	DURING DRIVING	WHEN DECELERATING	HESITATION/SURGING/FLAT SPOT	KNOCK/DETONATION	LACK OF POWER	POOR ACCELERATION	HI IDLE	LOW IDLE	Reference page	Feature of symptom, Check point
Warranty symptom code		Α	ιA			AB		AC	AD	А	Ε	А	νF	Ref	Fea
Electronic control fuel injection pump mainframe	4	4	4	4	4	4	4	4	4	5	5	3	4	_	*1
Injection nozzle	3	3	3	3	3	3	3	3	3	4	4		3	EC-54	*2
Glow system	1	1	1	1										EC-252	
Engine body	3	3	3	3	3	3	3		3	4	4		3	EM section	*3
EGR system										3	3			EC-238	
Air cleaner and ducts										3	3			MA section	*4

<sup>1 - 5:</sup> The numbers refer to the order of inspection. (continued on next page)

<sup>\*1:</sup> Fuel injection system malfunction or fuel injection timing control system malfunction may be the cause.
\*2: Depends on open-valve pressure and spray pattern.

<sup>\*3:</sup> Caused mainly by insufficient compression pressure.
\*4: Symptom varies depending on off-position of air duct, etc.

# Symptom Matrix Chart (Cont'd)

		SYMPTOM												
SYSTEM — Basic engine control system	NG	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEAT/HIGH ENGINE COOLANT TEMPERATURE	MPTION	CONSUMPTION	ABNORMAL SMOKE COLOR		CHARGE)		CONSULT-II?			ck point
	ROUGH IDLE/HUNTING					EXCESSIVE OIL COI	BLACK SMOKE	WHITE SMOKE	DEAD BATTERY (UNDER	Malfunction indicator lamp illuminates.	be detected by	Fuel cut	Reference page	Feature of symptom, Check point
Warranty symptom code	AG	АН	AJ	AK	AL	AM	А	·P	НА	Ma	Can	Fue	R e	Fe
Electronic control fuel injection pump mainframe	4	4	3		4		5	4		3	3	3	_	*1
Injection nozzle	3	3					4						EC-54	*2
Glow system								1					EC-252	
Engine body	3	3		3	3	3		3					EM section	*3
EGR system							3						EC-238	
Air cleaner and ducts							3				3		MA section	*4

<sup>1 - 5:</sup> The numbers refer to the order of inspection. (continued on next page)

EC EC

GI

MA

EM

FE

GL

MT

AT

TF

PD

\_ \_

FA

RA

BR

ST

RS

BT

HA

EL

SE

<sup>\*1:</sup> Fuel injection system malfunction or fuel injection timing control system malfunction may be the cause.

<sup>\*2:</sup> Depends on open-valve pressure and spray pattern.

<sup>\*3:</sup> Caused mainly by insufficient compression pressure.

<sup>\*4:</sup> Symptom varies depending on off-position of air duct, etc.

# Symptom Matrix Chart (Cont'd)

								SY	MPT	ОМ							
				HARD/NO START/RESTART	(EXCP. HA)			ENGINE STALL									
SYS	TEM — ENGINE CONTROL system	Malfunction	NO START (with first firing)	NO START (without first firing)	HARD TO START WHEN ENGINE IS COLD	HARD TO START WHEN ENGINE IS HOT	AT IDLE	DURING DRIVING	WHEN DECELERATING	HESITATION/SURGING/FLAT SPOT	KNOCK/DETONATION	LACK OF POWER	POOR ACCELERATION	HI IDLE	LOW IDLE	Reference page	Feature of symptom, Check point
Warra	nty symptom code	•		Α	A			АВ		AC	AD	Α	E	А	F	Ref	Fe
	Electronic control fuel injection pump	*a, *b		1		1	1	1	1	1	1	1	1	1	1		
ROL	circuit	*c, *d					'	'		<u>'</u>						_	
TNC	Mass air flow sensor circuit	*a, *c								1		1	1			EC-117	
Ю	mass an new sensor should	*b								Ľ						20 117	
ENGINE CONTROL	Engine coolant temperature sensor circuit	*a, *b			1		1		1						1	EC-123	*1
	Vehicle speed sensor circuit	*a, *b											1			EC-127	

<sup>1 - 5:</sup> The numbers refer to the order of inspection.

(continued on next page)

<sup>\*</sup>a: Open \*b: Short

<sup>\*</sup>c: Ground short

<sup>\*</sup>d: Noise

<sup>\*1:</sup> Compensation according to engine coolant temperature does not function.

# Symptom Matrix Chart (Cont'd)

								SYMF	PTO	M							
SYS	STEM — ENGINE CONTROL system	Malfunction	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEAT/HIGH ENGINE COOLANT TEMPERATURE	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	SMOKE	SMOKE ABNORWAL SMOKE COLOR	BATTERY (UNDER CHARGE)	Malfunction indicator lamp illuminates.	Can be detected by CONSULT-II?		page	Feature of symptom, Check point	
						_			BLACK	WHITE	DEAD	alfunctio	an be de	Fuel cut	Reference	ature of	
Warra	nty symptom code		AG	АН	AJ	AK	AL	AM	А	P	НА	Ĕ	ပိ	F.	Re	Fe	
	Electronic control fuel injection pump	*a, *b								1		1	1	1	_		
ROL	circuit	*c, *d							1			'	'				
CONTROL	Mass air flow sensor circuit	*a, *c											1		EC-117		
	Iviass all now sensor circuit	*b							1				'		EC-117		
ENGINE	Engine coolant temperature sensor circuit	*a, *b	1	1								1	1		EC-123	*1	
	Vehicle speed sensor circuit	*a, *b											1		EC-127		

<sup>1 - 5:</sup> The numbers refer to the order of inspection. (continued on next page)
\*a: Open

MA

GI

EM

LC

EC

FE

GL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

SE

<sup>\*</sup>b: Short

<sup>\*</sup>c: Ground short

<sup>\*</sup>d: Noise

<sup>\*1:</sup> Compensation according to engine coolant temperature does not function.

# Symptom Matrix Chart (Cont'd)

								SY	MPT	OM							
				HARD/NO START/RESTART	(EXCP. HA)			ENGINE STALL									
SYS	TEM — ENGINE CONTROL system	Malfunction	NO START (with first firing)	NO START (without first firing)	HARD TO START WHEN ENGINE IS COLD	HARD TO START WHEN ENGINE IS HOT	AT IDLE	DURING DRIVING	WHEN DECELERATING	HESITATION/SURGING/FLAT SPOT	KNOCK/DETONATION	LACK OF POWER	POOR ACCELERATION	HI IDLE	LOW IDLE	Reference page	Feature of symptom, Check point
Warra	nty symptom code			А	A			AB		AC	AD	А	Æ	Д	F	Re	Fe
	Accelerator switch (FC) circuit	*a, *b								1						EC-131	_
		*c															_
	Fuel cut system line	*a, *c *b	1				1	1	1							EC-246	*2
	Accelerator position sensor circuit	*a, *b	<u>'</u>				<u> </u>	i i	Ė	1		1	1			EC-156	_
	Crankshaft position sensor (TDC)	*a, *b															
TROL	circuit	*d										1	1			EC-171	
ENGINE CONT	Charge air pressure sensor circuit	*a, *b, *c										1	1			EC-233	
BUS	Swirl control valve control solenoid	*a, *b														EC-277	
Ш	valve circuit	*c								1	1	1	1				
	Variable nozzle turbocharger control solenoid valve circuit	*a, *b										1	1			EC-292	_
	Intake air control valve control sole- noid valve circuit	*c	1	1	1	1	1	1	1	1						EC-285	
	Exhaust gas control valve control solenoid valve circuit	*c						1	1	1		1	1			EC-300	

<sup>1 - 5:</sup> The numbers refer to the order of inspection. (continued on next page)

<sup>\*</sup>a: Open \*b: Short

<sup>\*</sup>c: Ground short

<sup>\*</sup>d: Noise

<sup>\*2:</sup> Engine runs on after turning ignition switch OFF.

G[

MA

EM

LC

EC

FE

GL

MT

AT

TF

PD

FA

RA

BR

ST

### TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

# Symptom Matrix Chart (Cont'd)

								SYMF	PTON	Л						
SYS	STEM — ENGINE CONTROL system		NG		TO IDLE	NGINE COOLANT TEMPERATURE	ONSUMPTION	CONSUMPTION		ABNORIVIAL SIMONE COLOR	NDER CHARGE)	p illuminates.	CONSULT-II?			sck point
		Malfunction	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEAT/HIGH ENGINE COOLANT	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CO	BLACK SMOKE	WHITE SMOKE	DEAD BATTERY (UNDER CHARGE)	Malfunction indicator lamp illuminates.	Can be detected by CON	el cut	Reference page	Feature of symptom, Check point
Warra	nty symptom code		AG	АН	AJ	AK	AL	AM	А	P	НА	Ma	Ca	Fuel	Re	L L
	Accelerator switch (FC) circuit	*a, *b										1	1		EC-131	
		*c														_
	Fuel cut system line	*a, *c										1	1	1	EC-246	*2
	Accelerator position sensor circuit	*a, *b										1	1		EC-156	
٦	Crankshaft position sensor (TDC) cir-	*a, *b	1	1												
ENGINE CONTROL	cuit	*d										1	1		EC-171	
SON	Charge air pressure sensor circuit	*a, *b, *c										1	1		EC-233	
빌	Swirl control valve control solenoid	*a, *b							1						E0 077	
IS NG	valve circuit	*c					1		1	1					EC-277	
ш	Variable nozzle turbocharger control	*a, *b					1		1						EC-292	
	solenoid valve circuit	*c					1						1		EG-292	
	Intake air control valve control sole- noid valve circuit	*c													EC-285	
	Exhaust gas control valve control solenoid valve circuit	*c	1	1		1	1	1	1						EC-300	

<sup>1 - 5:</sup> The numbers refer to the order of inspection. (continued on next page)
\*a: Open

RS

BT

HA

EL

SE

<sup>\*</sup>b: Short

<sup>\*</sup>c: Ground short

<sup>\*</sup>d: Noise

<sup>\*2:</sup> Engine runs on after turning ignition switch OFF.

# Symptom Matrix Chart (Cont'd)

								SY	MPT	ОМ							
				HARD/NO START/RESTART	(EXCP. HA)			ENGINE STALL									
SYS	TEM — ENGINE CONTROL system	Malfunction	NO START (with first firing)	NO START (without first firing)	HARD TO START WHEN ENGINE IS COLD	HARD TO START WHEN ENGINE IS HOT	AT IDLE	DURING DRIVING	WHEN DECELERATING	HESITATION/SURGING/FLAT SPOT	KNOCK/DETONATION	LACK OF POWER	POOR ACCELERATION	HIIDLE	LOW IDLE	Reference page	Feature of symptom, Check point
	Warranty symptom code			Д	A			AB		AC	AD	Д	Æ	А	F	Z.	Fe
	Start signal circuit	*a, *b			1	1										EC-261	*3
	PNP switch circuit	*a, *b							1							EC-264	
	FINE SWILCH CITCUIT	*c														EC-204	
3OL	Accelerator position switch (Idle) cir-	*a, *c					1		1						1	FO 450	
Ĭ	cuit	*b								1		1	1			EC-156	*4
ENGINE CONTROL	Accelerator position switch (Full) circuit	*a, *b								1		1	1			EC-156	
ENG	Ignition switch circuit	*a *b		1			1	1	1							EC-108	*5
	Power supply for ECM circuit	*a *b														EC-108	

<sup>1 - 5:</sup> The numbers refer to the order of inspection.

(continued on next page)

<sup>\*</sup>a: Open \*b: Short

<sup>\*</sup>c: Ground short

<sup>\*</sup>d: Noise

<sup>\*3:</sup> Start control does not function.

<sup>\*4:</sup> Accelerator position sensor NG signal is output.

<sup>\*5:</sup> Engine does not stop.

# Symptom Matrix Chart (Cont'd)

								SYMI	PTOI	VI							GI
SYS	STEM — ENGINE CONTROL system		NG		TO IDLE	IGINE COOLANT TEMPERATURE	ONSUMPTION	CONSUMPTION		ABNORMAL SMOKE COLOR	DER CHARGE)	illuminates.	CONSULT-II?			ck point	MA EM LG
		Malfunction	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEAT/HIGH ENGINE	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CON	BLACK SMOKE	WHITE SMOKE	DEAD BATTERY (UNDER CHARGE)	Malfunction indicator lamp illuminates.	Can be detected by CONS	Fuel cut	Reference page	Feature of symptom, Check point	FE CL MT
Warra	nty symptom code		AG	АН	AJ	AK	AL	AM	А	P	НА	Mal	Car	Fue	Ref	Fea	UVU U
	Start signal circuit	*a, *b													EC-261	*3	AT
	PNP switch circuit	*a, *b	1	1											EC-264		
ROL	Accelerator position switch (Idle) cir-	*a, *c													EC-156		TF
LNC	cuit	*b										1	1		EC-100	*4	
ENGINE CONTROL	Accelerator position switch (Full) circuit	*a, *b										1	1		EC-156		PD
ENG	Ignition switch circuit	*a *b													EC-108	*5	FA
	Power supply for ECM circuit	*a										1	1	1	EC-108		RA

<sup>1 - 5:</sup> The numbers refer to the order of inspection. (continued on next page)

BR

ST

RS

BT

HA

EL

SE

<sup>\*</sup>a: Open

<sup>\*</sup>b: Short \*c: Ground short

<sup>\*</sup>d: Noise

<sup>\*3:</sup> Start control does not function.

<sup>\*4:</sup> Accelerator position sensor NG signal is output.

<sup>\*5:</sup> Engine does not stop.

# Symptom Matrix Chart (Cont'd)

								SY	MPT	ОМ							Π
				HARD/NO	(EXCP. HA)			ENGINE STALL									
SYS	TEM — ENGINE CONTROL system	Malfunction	NO START (with first firing)	NO START (without first firing)	HARD TO START WHEN ENGINE IS COLD	HARD TO START WHEN ENGINE IS HOT	AT IDLE	DURING DRIVING	WHEN DECELERATING	HESITATION/SURGING/FLAT SPOT	KNOCK/DETONATION	LACK OF POWER	POOR ACCELERATION	HI IDLE	LOW IDLE	Reference page	Feature of symptom, Check point
	Warranty symptom code			Α	Α			AB		AC	AD	А	Æ	А	F	Re	Fe
	EGR volume control valve circuit	*a, *b														EC-238	
		*c															*8
	Glow relay circuit	*a	1	1	1	1										EC-252	*9
OL	Cien reie, eneun	*b															*10
Ä	ECM relay (Self-shutoff) circuit	*a					1	1	1							EC-108	
Ö	Low roley (Gen Shaton) should	*b														20 100	*11
ENGINE CONTROL	ECM, Connector circuit	*a, *b	2	2	2	2	2	2	2	2	2	2	2	2	2	EC-148, 218, 231	
Ш	Air and dising a relevative site.	*a														FC 200	*12
	Air conditioner relay circuit	*b														EC-306	*13
	Air conditioner switch circuit	*a, *c														EC-306	*13
	All conditioner switch circuit	*b														LO-300	*14

<sup>1 - 5:</sup> The numbers refer to the order of inspection. (continued on next page)

<sup>\*</sup>a: Open

<sup>\*</sup>b: Short

<sup>\*</sup>c: Ground short

<sup>\*</sup>d: Noise

<sup>\*8:</sup> Does not stop operating.

<sup>\*9:</sup> Glow lamp does not turn on.

<sup>\*10:</sup> Glow lamp does not turn off. \*11: Ground short makes engine unable to stop.

<sup>\*12:</sup> Air conditioner does not operate.

<sup>\*13:</sup> Air conditioner does not stop operating.

<sup>\*14:</sup> Air conditioner does not work.

# Symptom Matrix Chart (Cont'd)

		<u> </u>	<u> </u>						PTON							Т	GI
SY	STEM — ENGINE CONTROL system		NG		TO IDLE	OVERHEAT/HIGH ENGINE COOLANT TEMPERATURE		CONSUMPTION		ABINORINIAL SIMIONE COLOR	DER CHARGE)	illuminates.	SULT-II?			ck point	MA EM LG
		Malfunction	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEAT/HIGH EN	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CON	BLACK SMOKE	WHITE SMOKE	DEAD BATTERY (UNDER CHARGE)	Malfunction indicator lamp illuminates.	Can be detected by CONSULT-II?	cut	Reference page	Feature of symptom, Check point	FE
Warra	nty symptom code	_	AG		AJ	AK	AL			.P	HA	Malf	Can	Fuel cut	Refe	Feat	MT
	EGR volume control valve circuit	*a, *b							1						EC-238	*8	AT
پ	Glow relay circuit	*a *b								1					EC-252	*9 *10	TF
ENGINE CONTROL	ECM relay (Self-shutoff) circuit	*a *b	1	1										1	EC-108	*11	PD
IGINE C	ECM, Connector circuit	*a, *b	2	2	2	2	2	2	2	2	2	2	2	2	EC-148, 218, 231		FA
Ш	Air conditioner relay circuit	*a *b													EC-306	*12	RA
	Air conditioner switch circuit	*a, *c *b													EC-306	*13	na BR

<sup>1 - 5:</sup> The numbers refer to the order of inspection.

EC

FE

GL

MT

AT

TF

FA

RA

BR

ST

RS

BT

HA

EL

SE

<sup>\*</sup>a: Open

<sup>\*</sup>b: Short

<sup>\*</sup>c: Ground short

<sup>\*</sup>d: Noise

<sup>\*8:</sup> Does not stop operating.

<sup>\*9:</sup> Glow lamp does not turn on.

<sup>\*10:</sup> Glow lamp does not turn off.

<sup>\*11:</sup> Ground short makes engine unable to stop.

<sup>\*12:</sup> Air conditioner does not operate.

<sup>\*13:</sup> Air conditioner does not stop operating.

<sup>\*14:</sup> Air conditioner does not work.

#### **CONSULT-II Reference Value in Data Monitor** Mode

#### Remarks:

- Specification data are reference values.
- Specification data are output/input values which are detected or supplied by the ECM at the connector.
   \* Specification data may not be directly related to their components signals/values/operations.

MONITOR ITEM	CON	IDITION	SPECIFICATION
CKPS-RPM (TDC)	Tachometer: Connect		Almost the same speed as the
CMPS-RPM-PUMP	Run engine and compare tachometer in	dication with the CONSULT-II value.	CONSULT-II value.
COOLAN TEMP/S	Engine: After warming up		More than 70°C (158°F)
VHCL SPEED SE	Turn drive wheels and compare speedo	meter indication with the CONSULT-II value	Almost the same speed as the CONSULT-II value
FUEL TEMP SEN	Engine: After warming up		More than 40°C (104°F)
ACCEL POS SEN	Ignition switch: ON	Accelerator pedal: fully released	0.40 - 0.60V
ACCEL POS SEN	(Engine stopped)	Accelerator pedal: fully depressed	Approx. 4.5V
ELILL ACCEL SW	Ignition switch: ON	Accelerator pedal: fully depressed	ON
FULL ACCEL SW	(Engine stopped)	Except above	OFF
ACCEL SIM (FC)	Ignition switch: ON	Accelerator pedal: fully released	CLOSE
ACCEL SW (FC)	(Engine stopped)	Accelerator pedal: slightly open	OPEN
OFF ACCEL 2144	Ignition switch: ON	Accelerator pedal: fully released	ON
OFF ACCEL SW	(Engine stopped)	Accelerator pedal: slightly open	OFF
SPILL/V	Engine: After warming up		Approx. 13°CA
BATTERY VOLT	Ignition switch: ON (Engine stopped)		11 - 14V
D/N DOOL OW	Inviting positions ON	Shift lever: Park/Neutral	ON
P/N POSI SW	Ignition switch: ON	Except above	OFF
START SIGNAL	ullet Ignition switch: ON $ o$ START $ o$ ON		$OFF \to ON \to OFF$
	Coninc. After warming up idle the	Air conditioner switch: OFF	OFF
AIR COND SIG	Engine: After warming up, idle the engine	Air conditioner switch: ON (Compressor operates.)	ON
DDAKE CW	Impition assistable ON	Brake pedal: depressed	ON
BRAKE SW	Ignition switch: ON	Brake pedal: released	OFF
IGN SW	• Ignition switch: ON → OFF		$ON \rightarrow OFF$
\\\\ \D\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	Leading auditaba ON	Heat up switch: ON	ON
WARM UP SW	Ignition switch: ON	Heat up switch: OFF	OFF
MAS AIR/FL SE	<ul> <li>Engine: After warming up</li> <li>Air conditioner switch: OFF</li> <li>Shift lever: Neutral position</li> <li>No-load</li> </ul>	Idle	1.6 - 2.0V
DECELER F/CUT	Engine: After warming up	Idle	OFF
INJ TIMG C/V	Engine: After warming up, idle the enging	ne.	Approx. 50 - 70%
	- Engine After were in a sub-th-	Air conditioner switch: OFF	OFF
AIR COND RLY	Engine: After warming up, idle the engine	Air conditioner switch: ON (Compressor operates.)	ON
GLOW RLY	Refer to EC-252.		
COOLING FAN	When cooling fan is stopped.		OFF
COOLING FAN	When cooling fan operates.		ON

#### **CONSULT-II Reference Value in Data Monitor** Mode (Cont'd)

MONITOR ITEM	CONI	DITION	SPECIFICATION	
EGR VOL CON/V	<ul> <li>Engine: After warming up</li> <li>Air conditioner switch: "OFF"</li> </ul>	After 1 minute of idling	More than 10 steps	M
EGR VOL CON/V	<ul><li>Shift lever: Neutral position</li><li>No-load</li></ul>	Revving engine from idle to 3,200 rpm	0 step	E
VNT S/V 1	<ul><li>Engine: After warming up</li><li>Air conditioner switch: "OFF"</li></ul>	Idle	Approx. 56%	
VIVI 3/V I	<ul><li>Shift lever: Neutral position</li><li>No-load</li></ul>	2,000 rpm	Approx. 20%	L
			Altitude Approx. 0 m (0 ft): Approx. 100.62 kPa (1.0062 bar, 1.026 kg/cm², 14.59 psi)	Е
BARO SEN	• Ignition switch: ON		Approx. 1,000 m (3,281 ft): Approx. 88.95 kPa (0.8895 bar, 0.907 kg/cm², 12.90 psi)	F
			Approx. 1,500 m (4,922 ft): Approx. 83.16 kPa (0.8316 bar, 0.848 kg/cm², 12.06 psi) Approx. 2,000 m (6,562 ft): Approx.	0
			78.36 kPa (0.7836 bar, 0.799 kg/cm², 11.36 psi)	N
SWRL CON S/V 1	<ul> <li>Lift up the vehicle</li> <li>Engine: After warming up let it idle for more than 1 second.</li> </ul>	Shift lever: Except "P" and "Neutral" positions	ON	A
	<ul><li>Air conditioner switch: "OFF"</li><li>No-load</li></ul>	Shift lever: Neutral position	OFF	
EXH/GAS REG V*	Vehicle: Stopped     Engine speed: Below 1,200 rpm     Engine coolant temperature: Below 87°C     Heat up switch: ON	; (189°F)	ON	T
	Except above		OFF	. G

<sup>\*:</sup> This item is applicable for cold area models. On other models, "OFF" is always displayed.

G[

FA

RA

BR

ST

RS

BT

HA

EL


SE


# Major Sensor Reference Graph in Data Monitor Mode

The following are the major sensor reference graphs in "DATA MONITOR" mode.

#### ACCEL POS SEN, "CKPS:RPM (TDC)", "MAS AIR/FL SE"

Below is the data for "ACCEL POS SEN", "CKPS-RPM (TDC)" and "MAS AIR/FL SE" when revving engine quickly up to 3,000 rpm under no load after warming up engine to the normal operating temperature. Each value is for reference, the exact value may vary.







# lower cover removed SEF519VA

ECM harness protector

AEC913





# **ECM Terminals and Reference Value**

#### **PREPARATION**

1. ECM is located behind the instrument lower panel. For this inspection, remove the driver's side instrument lower cover.

MA

GI

LC

2. Remove ECM harness protector.

EC

FE

GL

MT

AT

- Perform all voltage measurements with the connector connected. Extend tester probe as shown to perform tests easily.
  - Open harness securing clip to make testing easier.
  - Use extreme care not to touch 2 pins at one time.
  - Data is for comparison and may not be exact.

PD

TF

FA

RA

BR

ST

RS

BT

Be sure ECM unit is properly grounded before checking.


HA

EL

SE

#### **ECM Terminals and Reference Value (Cont'd)**

#### **ECM HARNESS CONNECTOR TERMINAL LAYOUT**



#### **ECM INSPECTION TABLE**

Remarks: Specification data are reference values and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
			Engine is running.	BATTERY VOLTAGE (11 - 14V)
2	R/W	Intake air control valve control solenoid valve	Ignition switch "OFF"  For a few seconds after turning ignition switch "OFF"	Approximately 0.1V
4	B/Y	ECM relay (Self-shutoff)	Ignition switch "ON"  Ignition switch "OFF"  For a few seconds after turning ignition switch "OFF"	Approximately 0.25V
			Ignition switch "OFF"  A few seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)

ZD30DDTi

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
			Engine is running.  Warm-up condition Idle speed	Approximately 5.7V  (V) 10 5 0 20ms SEF255Z
5	Y/B	Tachometer	Engine is running.  Warm-up condition Engine speed is 2,000 rpm	Approximately 6V  (V) 10 20ms 20ms SEF256Z
11	BR/Y	Exhaust gas control valve control solenoid valve	Engine is running.  Engine speed is below 1,200 rpm Engine coolant temperature is below 87°C (189°F) Stop the vehicle Heat up switch is "ON"	Approximately 0.1V
			Engine is running.  Except the above condition	BATTERY VOLTAGE (11 - 14V)
14	L	Cooling fan relay	Engine is running.  Cooling fan is not operating	BATTERY VOLTAGE (11 - 14V)
			Engine is running.  Cooling fan is operating	Approximately 0.1V
			Engine is running.  Air conditioner switch is "OFF"	BATTERY VOLTAGE (11 - 14V)
15	Y/L	Air conditioner relay	Engine is running.  Both air conditioner switch and blower fan switch are "ON" (Compressor is operating)	Approximately 0.1V
16	1.00/	Clay lamp	Ignition switch "ON"  Glow lamp is "ON"	Approximately 1V
16	L/W	Glow lamp	Ignition switch "ON"  Glow lamp is "OFF"	BATTERY VOLTAGE (11 - 14V)

ZD30DDTi

# TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

			LCW Terminals and Reference	e value (Sont a)
TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
17	G/Y	Stop lamp switch	Ignition switch "ON"  Brake pedal fully released	Approximately 0V
			Ignition switch "ON"  Brake pedal depressed	BATTERY VOLTAGE (11 - 14V)
			Ignition switch "ON"	Approximately 1V
18	G	Malfunction indicator lamp	Engine is running.  Idle speed	BATTERY VOLTAGE (11 - 14V)
19	LG/R	Engine coolant tempera- ture sensor	Engine is running.	Approximately 0 - 4.8V Output voltage varies with engine coolant temperature
			Ignition switch "ON"	Approximately 0V
20	R/W	Start signal	Ignition switch "START"	BATTERY VOLTAGE (11 - 14V)
			Engine is running.  Air conditioner switch is "OFF"	BATTERY VOLTAGE (11 - 14V)
21	LG/B	Air conditioner switch	Engine is running.  Both air conditioner switch and blower fan switch are "ON"  (Compressor is operating)	Approximately 0.1V
22	P/B	Park/Neutral position switch	Gear position is "Neutral" (M/T models) Gear position is "P" or "N" (A/T models)	Approximately 0V
		- CWNOT	Ignition switch "ON"  Except the above gear position	BATTERY VOLTAGE (11 - 14V)
		Accelerator position sen-	Ignition switch "ON"  Accelerator pedal fully released	0.4 - 0.6V
23	W	sor	Ignition switch "ON"  Accelerator pedal fully depressed	Approximately 4.5V
				Voltage goes high up once in a few seconds
24	PU/W	A/T signal No. 1	Engine is running.  Warm-up condition Idle speed	(V) 10 5 0
				SEF448Z

ZD30DDTi

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
			Engine is running.  Lift up the vehicle In 1st gear position Vehicle speed is 10 km/h (6 MPH)	0 - Approximately 4.8V
26	L/OR	Vehicle speed sensor	Engine is running.  Lift up the vehicle In 2nd gear position Vehicle speed is 30 km/h (19 MPH)	Approximately 2.2V  (V) 10 5 0 100ms SEF258Z
29	R/L	Accelerator switch (F/C)	Ignition switch "ON"  Accelerator pedal fully released  Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)  Approximately 0V
			Engine is running.  Warm-up condition Idle speed	Approximately 0V
30	P	A/T signal No. 3	Engine is running.  Warm-up condition Engine speed is 2,000 rpm	Approximately 7.7V
31	R/L	Accelerator position	Ignition switch "ON"  Accelerator pedal fully released	BATTERY VOLTAGE (11 - 14V)
01	TVL	switch (Idle)	Ignition switch "ON"  Accelerator pedal depressed	Approximately 0V
32	W/G	Accelerator position	Ignition switch "ON"  Accelerator pedal released	Approximately 0V
32	W/G	switch (Full)	Ignition switch "ON"  Accelerator pedal fully depressed	BATTERY VOLTAGE (11 - 14V)
33	G/Y	Electronic control fuel injection pump	Engine is running.  Warm-up condition Idle speed	Approximately 2.5V

ZD30DDTi

# TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

			LOW Tellilliais and Neiereill	o varao (oont a)
TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
35	R	Mass air flow sensor	Engine is running.  Warm-up condition Idle speed	1.6 - 2.0V
37	P/B	A/T signal No. 2	Engine is running.  Warm-up condition Idle speed	Voltage goes high up once in a few seconds  (V) 10 5 0 SEF448Z
			Ignition switch "OFF"	0V
38	В/Ү	Ignition switch	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
39 43	B B	ECM ground	Engine is running.  Idle speed	Approximately 0V
40	R/B	Electronic control fuel injection pump	Engine is running.  Warm-up condition Idle speed	Approximately 2.5V
42	L/G		Engine is running.	Approximately 0V
64	Y/G	Data link connector	Idle speed (CONSULT-II is connected and	Approximately 0V
65	Y/R		turned on)	Less than 9V
			Engine is running.  Warm-up condition Idle speed	Approximately 0V  (V) 20 10 0 5 ms
44	L	Crankshaft position sensor (TDC)		Approximately 0V
			Engine is running.  Warm-up condition Engine speed is 2,000 rpm	(V) 20 10 0 5 ms
				SEF334Y

ZD30DDTi

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
46	L	Charge air pressure sensor	Engine is running.  Warm-up condition Idle speed	Approximately 2.0V
47	B/W	Crankshaft position sensor (TDC) ground	Engine is running.  Warm-up condition Idle speed	Approximately 0V
48	G/R	Accelerator position sensor power supply	Ignition switch "ON"	Approximately 5V
49	W	Sensor's power supply	Ignition switch "ON"	Approximately 5V
50	В	Sensors' ground	Engine is running.  Warm-up condition Idle speed	Approximately 0V
51	L/W	Accelerator position sensor ground	Engine is running.  Warm-up condition Idle speed	Approximately 0V
52	L/B	Electronic control fuel injection pump	Engine is running.  Idle speed	Approximately 0.1V
53	L/R	Electronic control fuel injection pump	Engine is running.  Idle speed	Approximately 1.0V
54	L/B	Swirl control valve control solenoid valve	Engine is running.  Warm-up condition At idle speed for more than 1 second Lift up the vehicle Gear position is in positions other than "P" and "Neutral"	Approximately 0.1V
			Engine is running.  Idle speed Lift up the vehicle Gear position is in "P" or "Neutral"	BATTERY VOLTAGE (11 - 14V)
56 61 116	W W W	Power supply for ECM	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
58	L/OR	A/T signal No. 4	Engine is running.  Warm-up condition Idle speed	Voltage goes high up once in a few seconds  (V) 10 5 0

ZD30DDTi

# TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

			Low reminals and reference	to value (Solit a)
TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
59	BR/W	Heat up switch	Ignition switch "ON"  Heat up switch is "ON"	Approximately 0V
00	BIOVV	riout up ownor	Ignition switch "ON"  Heat up switch is "OFF"	BATTERY VOLTAGE (11 - 14V)
<u></u>	DAM	Accelerator position sen-	Ignition switch "ON"  Accelerator pedal fully released	0.4 - 0.6V
68	B/W	sor signal output	Ignition switch "ON"  Accelerator pedal fully depressed	Approximately 4.5V
				Approximately 6.8V
			Engine is running.  Warm-up condition Idle speed	(V) 20 10 0
		Variable nozzle turbo-		SEF253Z
101	R/B	charger control solenoid valve		Approximately 11V
			Engine is running.  Warm-up condition Engine speed is 2,000 rpm	(V) 20 10 0
				SEF254Z
102	G/R	Current return	Engine is running.  Idle speed	BATTERY VOLTAGE (11 - 14V)
103 105 109 115	L/Y L/W L R/L	EGR volume control valve	Engine is running.  Warm-up condition Idle speed	0.1 - 14V
106 112 118	B B B	ECM ground	Engine is running.  Idle speed	Approximately 0V
111	LG/B	Glow relay	Refer to "GLOW CONTROL SYSTEM", EC-252.	

#### **Description**

Intermittent incidents (I/I) may occur. In many cases, the problem resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on DTC visits. Realize also that the most frequent cause of I/I occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnostic procedure may not indicate the specific problem area.

# MA

GI

#### **COMMON I/I REPORT SITUATIONS**

STEP in Work Flow	Situation
II	The CONSULT-II is used. The SELF-DIAG RESULTS screen shows time data other than "0".
III	The symptom described by the customer does not recur.
IV	DTC does not appear during the DTC Confirmation Procedure.
VI	The Diagnostic Procedure for XXXX does not indicate the problem area.

# LC

EC

#### GL

MIT

#### **Diagnostic Procedure**

1	INSPECTION START		
Erase D	TCs. Refer to "HOW TO ER	ASE DTC", EC-63.	
	<b>•</b>	GO TO 2.	1

AT	
TF	

2	CHECK GROUND TERMI	NALS	
	ground terminals for corroding GI section ("GROUND INS	g or loose connection. PECTION", "Circuit Inspection").	
	·	OK or NG	
OK	<b>•</b>	GO TO 3.	
NG	<b>•</b>	Repair or replace.	

FA

FA
----

RA

3	SEARCH FOR ELECTRICAL INCIDENT					
Perform GI section, "Incident Simulation Tests".						
OK or NG						
ОК	•	INSPECTION END				
NG	•	Repair or replace.				

BR









#### **Main Power Supply and Ground Circuit**

#### **ECM TERMINALS AND REFERENCE VALUE**

Remarks: Specification data are reference values and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
4	B/Y	ECM relay (Self-shutoff)	Ignition switch "ON"  Ignition switch "OFF"  For a few seconds after turning ignition switch "OFF"	Approximately 0.25V
			Ignition switch "OFF"  A few seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
38	B/Y	Ignition switch	Ignition switch "OFF"	OV
			Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
39 43	ВВ	ECM ground	Engine is running.  Idle speed	Approximately 0V
56 61 116	W W W	Power supply for ECM	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
102	G/R	Current return	Engine is running.  Idle speed	BATTERY VOLTAGE (11 - 14V)
106 112 118	В В В	ECM ground	Engine is running.  Idle speed	Approximately 0V

ZD30DDTi

GI

MA

EM

LC

EC

FE

GL

MT

AT

TF

PD

FA

RA

BR

ST

BT

HA


EL


SE

[DX

## Main Power Supply and Ground Circuit (Cont'd)


#### **WIRING DIAGRAM**







## Main Power Supply and Ground Circuit (Cont'd)

EC-MAIN-02









GI

EC

FE

GL

MT

AT

TF

PD

RA

BR

ST


BT


HA

EL

#### **Main Power Supply and Ground Circuit** (Cont'd)

#### DIAGNOSTIC PROCEDURE





3	DETECT MALFUNCTIONING PART
---	----------------------------

Check the following.

- Harness connectors M51, F6
- Fuse block (J/B) connector M2
- 10A fuse
- Harness for open or short between ECM and fuse
  - Repair open circuit or short to ground or short to power in harness or connectors.

#### 4 CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch "OFF".
- 2. Disconnect ECM harness connector.
- 3. Check harness continuity between ECM terminals 39, 43, 106, 112, 118 and engine ground. Refer to Wiring Diagram. Continuity should exist.
- 4. Also check harness for short to ground and short to power.

OK or NG		
OK ▶	GO TO 6.	
NG ▶	GO TO 5.	

SE

#### TROUBLE DIAGNOSIS FOR POWER SUPPLY

## Main Power Supply and Ground Circuit (Cont'd)

#### 5 DETECT MALFUNCTIONING PART

Check the following.


• Joint connector-3

6

- Harness for open or short between ECM and engine ground
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

#### CHECK ECM POWER SUPPLY CIRCUIT-II

- 1. Reconnect ECM harness connector.
- 2. Turn ignition switch "ON" and then "OFF".
- 3. Check voltage between ECM terminals 56, 61, 116 and ground with CONSULT-II or tester.



#### Voltage:

After turning ignition switch "OFF", battery voltage will exist for a few seconds, then drop to approximately 0V.


SEF288Z

#### OK or NG

ОК	•	Check electronic control fuel injection pump power supply circuit. Refer to "Diagnostic Procedure", EC-200.
NG (Battery voltage does not exist.)	<b>&gt;</b>	GO TO 7.
NG (Battery voltage exists for more than a few seconds.)	<b>•</b>	GO TO 13.

GI

## Main Power Supply and Ground Circuit (Cont'd)



#### TROUBLE DIAGNOSIS FOR POWER SUPPLY

## Main Power Supply and Ground Circuit (Cont'd)

#### 10 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M52, F7
- Harness for open or short between ECM and ECM relay
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

#### 11 CHECK ECM POWER SUPPLY CIRCUIT-IV

- 1. Check harness continuity between ECM terminals 56, 61, 116 and ECM relay terminal 5. Refer to Wiring Diagram. Continuity should exist.
- 2. Also check harness for short to ground and short to power.

#### OK or NG

OK	•	GO TO 13.
NG	•	GO TO 12.


#### 12 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M50, F5
- Harness for open or short between ECM and ECM relay
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

#### 13 CHECK ECM RELAY

- 1. Apply 12V direct current between ECM relay terminals 1 and 2.
- 2. Check continuity between ECM relay terminals 3 and 5, 7 and 6.



Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
OFF	No

SEF296X

OK or NG

OK ▶	GO TO 14.
NG ▶	Replace ECM relay.


OK or NG

#### **Main Power Supply and Ground Circuit** (Cont'd)

#### **CHECK ECM POWER SUPPLY CIRCUIT-V**

- 1. Reconnect all harness connectors disconnected.
- 2. Turn ignition switch "ON".
- 3. Check voltage between ECM terminal 102 and ground with CONSULT-II or tester.

GO TO 15.



Voltage: Battery voltage

SEF290Z

OK GO TO 16.

#### 15 **DETECT MALFUNCTIONING PART**

Check the following.


- Harness connectors M52, F7
- Fuse block (J/B) connector M2
- 10A fuse

NG

- Harness for open or short between ECM and fuse
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

#### 16 **CHECK ECM POWER SUPPLY CIRCUIT-VI**

- 1. Turn ignition switch "OFF".
- 2. Disconnect ECM relay.



SEF225Z

- 3. Disconnect ECM harness connector.
- 4. Check harness continuity between ECM terminals 56, 61, 116 and ECM relay terminal 5. Refer to Wiring Diagram. Continuity should exist.
- 5. Also check harness for short to ground and short to power.

OK or NG

ок	•	GO TO 18.
NG	<b></b>	GO TO 17.

**EC-115** 

GI

MA

EM

LC

EC

FE

GL

MT

AT

TF

PD

FA

BR

RA

HA

EL

SE

ZD30DDTi

#### TROUBLE DIAGNOSIS FOR POWER SUPPLY


## Main Power Supply and Ground Circuit (Cont'd)

## 17 DETECT MALFUNCTIONING PART Check the following. • Harness connectors M50, F5 • Harness for open or short between ECM and ECM relay Repair open circuit or short to ground or short to power in harness or connectors.

18	8 CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT			
<ol> <li>Check harness continuity between ECM terminals 39, 43, 106, 112, 118 and engine ground. Refer to Wiring Diagram.         Continuity should exist.     </li> <li>Also check harness for short to ground and short to power.</li> </ol>				
OK or NG				
ОК	<b>•</b>	GO TO 20.		
NG	<b>•</b>	GO TO 19.		

19	DETECT MALFUNCTIONING PART		
• Joint	Check the following.  Joint connector-3  Harness for open or short between ECM and engine ground		
Traine	'	Repair open circuit or short to ground or short to power in harness or connectors.	

20	CHECK INTERMITTENT INCIDENT		
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.			
	<b>&gt;</b>	INSPECTION END	



#### **Component Description**

The mass air flow sensor (MAFS) is placed in the stream of intake air. It measures the intake air flow rate by measuring a part of the entire intake air flow. It consists of a hot wire that is supplied with electric current from the ECM. The temperature of the hot wire is controlled by the ECM a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss.

Therefore, the ECM must supply more electric current to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.

#### GI

MA

EC

#### **CONSULT-II** Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAS AIR/FL SE	<ul> <li>Engine: After warming up</li> <li>Air conditioner switch: "OFF"</li> <li>Shift lever: Neutral position</li> <li>No-load</li> </ul>	Idle	1.6 - 2.0V

#### **ECM Terminals and Reference Value**

Specification data are reference values, and are measured between each terminal and ground.

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	PD FA
35	R	Mass air flow sensor	Engine is running.  Warm-up condition Idle speed	1.6 - 2.0V	RA
49	W	Sensor's power supply	Ignition switch "ON"	Approximately 5V	BR
50	В	Sensor's ground	Engine is running.  Warm-up condition Idle speed	Approximately 0V	ST

#### On Board Diagnosis Logic

Malfunction is detected when	Check Items (Possible Cause)	 B'
An excessively high or low voltage from the sensor is sent to ECM.	Harness or connectors     (The sensor circuit is open or shorted.)     Mass air flow sensor	

FE

GL

MT

AT

PD


TF

BR

1/4

EL

SE




#### **DTC Confirmation Procedure**



- 1) Turn ignition switch "ON", and wait at least 6 seconds.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and wait at least 3 seconds.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-120.




- 1) Turn ignition switch "ON", and wait at least 6 seconds.
- 2) Start engine and wait at least 3 seconds.
- 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 5) If DTC is detected, go to "Diagnostic Procedure", EC-120.



#### **Diagnostic Procedure**


#### **CHECK MAFS POWER SUPPLY CIRCUIT**

- 1. Turn ignition switch "OFF".
- 2. Disconnect mass air flow sensor harness connector.



SEF226Z

- 3. Turn ignition switch "ON".
- 4. Check voltage between mass air flow sensor terminals 2, 4 and gund with CONSULT-II or tester.



Terminal Voltage	
2 Approximately 5	
4	Battery voltage

SEF297X


OK ▶	GO TO 3.
NG •	GO TO 2.

#### 2 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E230, F12
- Harness connectors M50, F5
- Harness for open or short between mass air flow sensor and ECM
- Harness for open or short between mass air flow sensor and ECM relay
  - ► Repair open circuit or short to ground or short to power in harness or connector.

#### **Diagnostic Procedure (Cont'd)**




#### DTC 0102 MASS AIR FLOW SEN

#### Diagnostic Procedure (Cont'd)

#### CHECK MASS AIR FLOW SENSOR

- 1. Reconnect harness connectors disconnected.
- 2. Start engine and warm it up to normal operating temperature.
- 3. Check voltage between ECM terminal 35 (Mass air flow sensor signal) and ground.



Condition	Voltage V	
Ignition switch "ON" (Engine stopped.)	Approx. 1.0	
Idle (Engine is warmed-up to normal operating temperature.)	1.6 - 2.0	
Idle to about 4,000 rpm*	1.6 - 2.0 to Approx. 4.0	

<sup>\*:</sup> Check for linear voltage rise in response to engine being increased to about 4,000 rpm.


SEF400Y


4. If the voltage is out of specification, disconnect MAFS harness connector and connect it again. Then repeat above check.

#### OK or NG

OK ▶	GO TO 8.
NG •	Replace mass air flow sensor.

8	CHECK INTERMITTENT INCIDENT	
Refer to	Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.	
	•	INSPECTION END





#### Description

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.

#### GI

MA

EM

LC

#### <Reference data>

Engine coolant temperature °C (°F)	Voltage* (V)	Resistance (kΩ)
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.3	0.68 - 1.00
90 (194)	1.0	0.236 - 0.260


These data are reference values and measured between ECM terminal 19 (Engine coolant temperature sensor) and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/ output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

#### On Board Diagnosis Logic

Malfunction is detected when	Check Items (Possible Cause)	
• An excessively high or low voltage from the sensor is entered	Harness or connectors (The sensor circuit is open or shorted.)	FA
to ECM.	Engine coolant temperature sensor	



#### **DTC Confirmation Procedure**

#### WITH CONSULT-II

Turn ignition switch "ON". 1)

- Select "DATA MONITOR" mode with CONSULT-II.
- Wait at least 5 seconds.
- If DTC is detected, go to "Diagnostic Procedure", EC-125. 4)

#### WITHOUT CONSULT-II

- Turn ignition switch "ON" and wait at least 5 seconds.
- Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- Perform "Diagnostic Test Mode II (Self-diagnostic results)" with 3)
- If DTC is detected, go to "Diagnostic Procedure", EC-125.

EC

FE

MT

AT

TF

PD

RA

BR

ST

BT


HA

EL

SE


#### **Wiring Diagram**

#### EC-ECTS-01



GI

#### **Diagnostic Procedure**



#### **DTC 0103 COOLANT TEMP SEN**

#### Diagnostic Procedure (Cont'd)

#### 4 DETECT MALFUNCTIONING PART


Check the following.

5

- Harness connectors E230, F12
- Harness connectors F6, M51
- Harness connectors M88, E106
- Harness for open or short between engine coolant temperature sensor and ECM
- Harness for open or short between engine coolant temperature sensor and TCM (Transmission control module)
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.


#### CHECK ENGINE COOLANT TEMPERATURE SENSOR

- 1. Remove engine coolant temperature sensor from the engine.
- 2. Check resistance between ECTS terminals 1 and 2 as shown in the figure.



#### <Reference data>

Temperature °C (°F)	Resistance k $\Omega$
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260



SEF304X


OK	► GO TO 6.

NG Replace engine coolant temperature sensor.

#### 6 CHECK INTERMITTENT INCIDENT

Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.

► INSPECTION END



#### **Description**

The vehicle speed sensor is installed in the transaxle. It contains a pulse generator which provides a vehicle speed signal to the speedometer. The speedometer then sends a signal to the ECM.

GI

MA

EM

LC

#### **ECM Terminals and Reference Value**

Specification data are reference values and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

Engine is running.  Lift up the vehicle In 1st gear position Vehicle speed is 10 km/h (6 MPH)  SEF257Z  Approximately 4.8V  Vehicle speed sensor  Engine is running.  Lift up the vehicle In 2nd gear position Vehicle speed is 30 km/h (19 MPH)  RA  OFFICIAL REPORTMENT OF THE PROPERTY OF T	TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)	GL MT
Vehicle speed sensor    SEF257Z   Approximately 2.2V   FA		Lift up the vehicle In 1st gear position	(V) 10 5	TF		
	26	L/OR	Vehicle speed sensor	Lift up the vehicle In 2nd gear position	Approximately 2.2V	FA RA

#### On Board Diagnosis Logic

Malfunction is detected when	Check Items (Possible Cause)	RS
The almost 0 km/h (0 MPH) signal from vehicle speed sensor is sent to ECM even when vehicle is being driven.	Harness or connector     (The vehicle speed sensor circuit is open or shorted.)     Vehicle speed sensor	BT


EC


FE

GL

HA

EL





#### **Overall Function Check**

Use this procedure to check the overall function of the vehicle speed sensor circuit. During this check, a DTC might not be confirmed.



#### WITH CONSULT-II

- 1) Lift up the vehicle.
- 2) Start engine.
- 3) Read vehicle speed sensor signal in "DATA MONITOR" mode with CONSULT-II.

The vehicle speed on CONSULT-II should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.

4) If NG, go to "Diagnostic Procedure", EC-130.




#### WITHOUT CONSULT-II

- 1) Lift up the vehicle.
- 2) Start engine.
- 3) Rotate drive wheel by hand.
- 4) Check voltage between ECM terminal 26 and ground with tester.

Voltage should vary between 0 - 4.8V.

5) If NG, go to "Diagnostic Procedure", EC-130.



#### **Diagnostic Procedure**

# 1 CHECK VEHICLE SPEED SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT 1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector and combination meter harness connector. 3. Check harness continuity between ECM terminal 26 and combination meter terminal 26. Refer to Wiring Diagram. Continuity should exist. 4. Also check harness for short to ground and short to power. OK or NG OK

2	DETECT MALFUNCTIONING PART		
Check the following.  ● Harness connectors M52, F7			
	<ul> <li>Joint connector-1</li> <li>Harness for open or short between ECM and combination meter</li> </ul>		
▶ Repair open circuit or short to ground or short to power in harness or connectors.			


GO TO 2.

NG

3	CHECK SPEEDOMETER FUNCTION			
Make su	Make sure that speedometer functions properly.			
	OK or NG			
OK	<b>&gt;</b>	GO TO 5.		
NG	<b>•</b>	GO TO 4.		

4	CHECK SPEEDOMETER	CIRCUIT FOR OPEN AND SHORT	
Check the following.  • Harness connectors E70, E201  • Harness connectors M86, E104 or M21, E127  • Harness for open or short between combination meter and vehicle speed sensor			
	OK or NG		
OK			
NG	<b>•</b>	Repair open circuit or short to ground or short to power in harness or connectors.	

5	CHECK INTERMITTENT INCIDENT		
Refer to	Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.		
	<b>•</b>	INSPECTION END	



#### **Description**

The accelerator switch is installed to the accelerator pedal assembly. The switch senses accelerator position and sends an ON-OFF signal to the ECM. The ECM uses the signal to control the fuel cut operation at deceleration for better fuel efficiency.

GI

MA

EM

LC

## **CONSULT-II** Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL SW (FC)	Ignition switch: ON	Accelerator pedal: fully released	CLOSE
(Engine stopped)	Accelerator pedal: slightly open	OPEN	
DECELER F/CUT	Engine: After warming up	Idle	OFF

#### **ECM Terminals and Reference Value**

Specification data are reference values and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	[
	Ignition switch "ON"  Accelerator pedal fully released	BATTERY VOLTAGE (11 - 14V)	[		
29	R/L	Accelerator switch (F/C)	Ignition switch "ON"  Accelerator pedal depressed	Approximately 0V	[

#### On Board Diagnosis Logic

Malfunction is detected when	Check Items (Possible Cause)	
<ul> <li>The OFF signal (short) is sent to the ECM for a certain period of time even when the accelerator pedal is not being depressed.</li> </ul>	<ul> <li>Harness or connectors (The switch circuit is shorted.)</li> <li>Accelerator switch (F/C)</li> </ul>	

EC

FE

GL

MT

AT

TF

RA

FA

BR

ST


RS

BT

HA

EL

SE



#### **DTC Confirmation Procedure**


#### WITH CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Fully depress and fully release accelerator pedal, and wait 15 seconds.
- 4) Repeat step 3 at least 29 times.
- 5) If DTC is detected, go to "Diagnostic Procedure", EC-134.



#### WITHOUT CONSULT-II


- 1) Turn ignition switch "ON".
- 2) Fully depress and fully release accelerator pedal, and then wait 15 seconds.
- 3) Repeat step 2 at least 29 times.
- 4) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 5) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 6) If DTC is detected, go to "Diagnostic Procedure", EC-134.



#### **Diagnostic Procedure**

#### CHECK ACCELERATOR SWITCH (F/C) GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch "OFF".
- 2. Loosen and retighten engine ground screws.
- 3. Disconnect accelerator switch (F/C) harness connector.



SEF688V

- Check harness continuity between accelerator switch (F/C) terminal 3 and engine ground. Refer to Wiring Diagram.
   Continuity should exist.
- 5. Also check harness for short to ground and short to power.

#### OK or NG

OK ▶	GO TO 3.
NG •	GO TO 2.

#### 2 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M51, F6 (RHD models)
- Joint connector-3
- Harness for open or short between accelerator switch (F/C) and engine ground
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

#### 3 CHECK ACCELERATOR SWITCH (F/C) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- 1. Disconnect ECM harness connector.
- 2. Check harness continuity between ECM terminal 29 and accelerator switch (F/C) terminal 1. Refer to Wiring Diagram.

#### Continuity should exist.

3. Also check harness for short to ground and short to power.

#### OK or NG

OK ▶	GO TO 5.
NG ►	GO TO 4.

#### 4 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M51, F6 (RHD models)
- Harness for open or short between ECM and accelerator switch (F/C)
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

PD

FA

RA

BR

ST


BT

HA

EL

SE

#### **Diagnostic Procedure (Cont'd)**




#### **Description**

#### SYSTEM DESCRIPTION

Sensor Input signal to ECM		ECM function	Actuator	
Vehicle speed sensor Vehicle speed				
Engine coolant temperature sensor	Engine coolant temperature	Cooling fan con-	Cooling fan relay	
Air conditioner switch Air conditioner "ON" signal		1.01		

The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, air conditioner ON signal. The control system has 2-step control [ON/OFF].

#### **OPERATION**



### **CONSULT-II** Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
	Engine: After warming up, idle the	Air conditioner switch: OFF	OFF
AIR COND SIG	engine	Air conditioner switch: ON (Compressor operates.)	ON
COOLING FAN	When cooling fan is stopped.		OFF
When cooling fan operates.		ON	

#### **ECM Terminals and Reference Value**

Specification data are reference values and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	
14		Cooling fan relay	Engine is running.  Cooling fan is not operating	BATTERY VOLTAGE (11 - 14V)	
		Cooming fair relay	Engine is running.  Cooling fan is operating		

#### On Board Diagnosis Logic

This diagnosis continuously monitors the engine coolant temperature.

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise

When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

		<del></del> A
Malfunction is detected when	Check Items (Possible Cause)	
<ul> <li>Cooling fan does not operate properly (Overheat).</li> </ul>	Harness or connectors	571
<ul> <li>Cooling fan system does not operate properly (Overheat).</li> </ul>	(The cooling fan circuit is open or shorted.)	T
<ul> <li>Engine coolant was not added to the system using the proper</li> </ul>	Cooling fan	
filling method.	Radiator hose	<u> </u>
	Radiator	P
	Radiator cap	
	Water pump	P
	Thermostat	F
	• Fan belt	
	Engine coolant temperature sensor	<u></u>
	For more information, refer to "MAIN 12 CAUSES OF	R
	OVERHEATING", EC-147.	

#### **CAUTION:**

When a malfunction is indicated, be sure to replace the coolant following the procedure in the MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE"). Also, replace the engine oil.

- 1) Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to MA section ("Anti-freeze Coolant Mixture Ratio", "RECOMMENDED LUBRICANTS AND FLUIDS").
- 2) After refilling coolant, run engine to ensure that no water-flow noise is emitted.

G[

MA

\_\_\_\_

LC

EC

GL

FE

MT

AT

TF

PD

r R

RA

BR

B.O.


25

. .


HA

EL

SE



_			i
	ACTIVE TES		
	COOLING FAN	OFF	
	MONITOR		
	COOLAN TEMP/S	xxx °c	
F			
⊢			
<u> </u>			
<del> </del>			
L			SEF111X



#### **Overall Function Check**

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.

#### WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around the cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.


#### (**[**]) \

#### WITH CONSULT-II

- 1) Check the coolant level in the reservoir tank and radiator.
  - Allow engine to cool before checking coolant level.
  - If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to "Diagnostic Procedure", EC-140.
- 2) Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to "Diagnostic Procedure", EC-140.
- 3) Turn ignition switch "ON".
- 4) Perform "COOLING FAN" in "ACTIVE TEST" mode with CON-SULT-II and make sure that cooling fans operate when touching "HIGH" or "LOW".
  - If NG, go to "Diagnostic Procedure", EC-140.

#### WITHOUT CONSULT-II

- 1) Check the coolant level in the reservoir tank and radiator.
  - Allow engine to cool before checking coolant level.
  - If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to "Diagnostic Procedure", EC-140.
- Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to "Diagnostic Procedure", EC-140.
- Disconnect engine coolant temperature sensor harness connector.
- 4) Connect  $150\Omega$  resistor to engine coolant temperature sensor harness connector.
- 5) Start engine and make sure that cooling fan operates. **Be careful not to overheat engine.**
- 6) If NG, go to "Diagnostic Procedure", EC-140.




#### **Diagnostic Procedure**

1	INSPECTION START		
Do you	Do you have CONSULT-II?		
	Yes or No		
Yes	<b>&gt;</b>	GO TO 2.	
No	<b>•</b>	GO TO 3.	

103		00 10 2.				
No	•	GO TO 3.				
2	CHECK COOLING FAN O	PERATION				
(F) Wit	th CONSULT-II					
1. Turn	ignition switch "ON".					
2. Perfo	orm "COOLING FAN" in "AC"	TIVE TEST" mod	e with CONSULT-	II.		
			ACTIVE TES	т	1	
			COOLING FAN	OFF		
			MONITOR			
			COOLAN TEMP/S	xxx °c		
3. Make	e sure that cooling fan-1 ope	rates.				
			OK or NO	3		
OK	<b>&gt;</b>	GO TO 12.				
NG	<b>•</b>	GO TO 4.				

#### **Diagnostic Procedure (Cont'd)**



**EC-141** 

MA

EM

LC

EC

FE

GL

MT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL

#### **Diagnostic Procedure (Cont'd)**


#### CHECK COOLING FAN POWER SUPPLY CIRCUIT

- 1. Turn ignition switch "OFF".
- 2. Disconnect cooling fan relay-1.



SEF690V

- 3. Turn ignition switch "ON".
- 4. Check voltage between cooling fan relay-1 terminals 2, 5 and ground with CONSULT-II or tester.



Voltage: Battery voltage

SEF291Z

OK or NG

OK ▶	GO TO 6.
NG •	GO TO 5.


#### 5 DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E112
- 10A fuse or 20A fuse
- 30A fusible links
- Harness for open or short between cooling fan relay-1 and fuse
- Harness for open or short between cooling fan relay-1 and battery
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

HA


#### **Diagnostic Procedure (Cont'd)**




#### **Diagnostic Procedure (Cont'd)**

#### CHECK COOLING FAN RELAY-1

Check continuity between cooling fan relay-1 terminals 3 and 5 under the following conditions.





Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No


SEF608X

#### OK or NG

OK ▶	GO TO 10.
NG ►	Replace cooling fan relay.

#### 10 CHECK COOLING FAN MOTOR-1

Supply battery voltage between the following terminals and check operation.



	Speed	Terminals			
	Speed	(+)	(-)		
Cooling fan	Low	1	4		
motor-1	High	1,3	2 , 4		

SEF292Z

#### OK or NG


OK ▶	GO TO 11.
NG ►	Replace cooling fan motor.

#### 11 CHECK INTERMITTENT INCIDENT

Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.

**▶** INSPECTION END

### **Diagnostic Procedure (Cont'd)**




### **Diagnostic Procedure (Cont'd)**

#### 15 CHECK THERMOSTAT

- 1. Remove thermostat.
- 2. Check valve seating condition at normal room temperatures.

#### It should seat tightly.

3. Check valve opening temperature and valve lift.



SLC343

Valve opening temperature:

82°C (180°F) [standard] (Models for cold areas)

76.5°C (170°F) [standard] (Models for except cold areas)

Valve lift:

More than 10 mm/95°C (0.394 in/203°F)


4. Check if valve is closed at 5°C (9°F) below valve opening temperature. For details, refer to LC section, "Thermostat".

#### OK or NG

OK ▶	GO TO 16.
NG ▶	Replace thermostat.


#### 16 CHECK ENGINE COOLANT TEMPERATURE SENSOR

- 1. Remove engine coolant temperature sensor.
- 2. Check resistance between engine coolant temperature sensor terminals 1 and 2 as shown in the figure.



#### <Reference data>

Temperature °C (°F)	Resistance k $\Omega$
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260



SEF304X

OK or NG

OK ▶	GO TO 17.
NG •	Replace engine coolant temperature sensor.

### DTC 0208 OVER HEAT

### Diagnostic Procedure (Cont'd)

17	CHECK MAIN 12 CAUSES			
If the cause cannot be isolated, go to "MAIN 12 CAUSES OF OVERHEATING", EC-147.				
► INSPECTION END				

### Main 12 Causes of Overheating

Engine	Step	Inspection item	Equipment	Standard	Reference page	
OFF	1	<ul><li>Blocked radiator</li><li>Blocked condenser</li><li>Blocked radiator grille</li><li>Blocked bumper</li></ul>	Visual	No blocking	_	
	2	Coolant mixture	Coolant tester	30 - 50% coolant mixture	See "RECOMMENDED FLUIDS AND LUBRI- CANTS" in MA section.	
	3	Coolant level	Visual	Coolant up to MAX level in reservoir tank and radiator filler neck	See "Changing Engine Coolant", "ENGINE MAIN- TENANCE" in MA section.	
	4	Radiator cap	Pressure tester	78 - 98 kPa (0.78 - 0.98 bar, 0.8 - 1.0 kg/cm <sup>2</sup> , 11 - 14 psi) 59 - 98 kPa (0.59 - 0.98 bar, 0.6 - 1.0 kg/cm <sup>2</sup> , 9 - 14 psi) (Limit)	See "System Check", "ENGINE COOLING SYS- TEM" in LC section.	
ON*2	5	Coolant leaks	Visual	No leaks	See "System Check", "ENGINE COOLING SYS- TEM" in LC section.	
ON*2	6	Thermostat	Touch the upper and lower radiator hoses	Both hoses should be hot.	See "Thermostat" and "Radiator", "ENGINE COOLING SYSTEM" in LC section.	
ON*1	7	Cooling fan	Visual	Operating	See "DTC 0208 OVER HEAT", EC-136.	
OFF	8	Combustion gas leak	Color checker chemical tester 4 gas analyzer	Negative	_	
ON*3	9	Coolant temperature gauge	Visual	Gauge less than 3/4 when driving	_	
		Coolant overflow to reservoir tank	Visual	No overflow during driving and idling	See "Changing Engine Coolant", "ENGINE MAIN- TENANCE" in MA section.	
OFF*4	10	Coolant return from reservoir tank to radiator	Visual	Should be initial level in reservoir tank	See "ENGINE MAINTE- NANCE" in MA section.	
OFF	11	Cylinder head	Straight gauge feeler gauge	0.1 mm (0.004 in) Maximum distortion (warping)	See "Inspection", "CYLIN- DER HEAD" in EM sec- tion.	
	12	Cylinder block and pistons	Visual	No scuffing on cylinder walls or piston	See "Inspection", "CYLIN- DER BLOCK" in EM sec- tion.	

<sup>\*1:</sup> Engine running at idle.

G[

MA

EM


SE

<sup>\*2:</sup> Engine running at 3,000 rpm for 10 minutes.

<sup>\*3:</sup> Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

<sup>\*4:</sup> After 60 minutes of cool down time.

For more information, refer to "OVERHEATING CAUSE ANALYSIS" in LC section.




### **Description**

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The unit controls the engine.

### On Board Diagnosis Logic

Malfunction is detected when	Check Items (Possible Cause)
ECM calculation function is malfunctioning.	ECM     (ECCS-D control module)



#### **DTC Confirmation Procedure**



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and wait at least 2 seconds.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-149.

### WITHOUT CONSULT-II


- 1) Turn ignition switch "ON" and wait at least 2 seconds.
- 2) Start engine and wait at least 2 seconds.
- 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with FCM
- 5) If DTC is detected, go to "Diagnostic Procedure", EC-149.

G[

## **Diagnostic Procedure**

1 INSPECT	ION START		MA
(H) With CONSUL	.T-II		UVU <i>U</i> -
Turn ignition switch "ON".     Select "SELF DIAG RESULTS" mode with CONSULT-II.			
3. Touch "ERASE".  4. Perform "DTC Confirmation Procedure", EC-148, again.  5. Let the great fine displayed a print?			
5. Is the malfunction displayed again?  Without CONSULT-II			LC
1. Turn ignition switch "ON".			
Erase the Diagnostic Test Mode II (Self-diagnostic results) memory.     Perform "DTC Confirmation Procedure", EC-148, again.			EC
4. Perform "Diagno	4. Perform "Diagnostic Test Mode II (Self-diagnostic results)".  1. Perform "Diagnostic Test Mode II (Self-diagnostic results)".		
5. Is the DTC 0301	5. Is the DTC 0301 or 0901 displayed again?		
		Yes or No	
Yes	•	Replace ECM.	
No	► INSPECTION END		

SE



#### **Description**

#### SYSTEM DESCRIPTION

The ECM and the electronic control fuel injection pump control unit (abbreviated as the injection pump control unit) perform the real time communication (signal exchange).

The ECM transmits the signals of the target fuel injection amount, target fuel injection timing, and engine speed, etc., and receives the signals of the pump speed and fuel temperature, etc. from the injection pump control unit.

By those signals, the injection pump controls the optimum fuel injection amount and injection timing of the spill valve and timing control valve.

Injection pump control unit has an on board diagnostic system, which detects malfunctions related to sensors or actuators built-into electronic control fuel injection pump. These malfunction information are transferred through the line (circuit) from injection pump control unit to ECM.

#### **FUEL INJECTION AMOUNT CONTROL**

In accordance with the target fuel injection amount signal from the ECM, the injection amount is controlled by controlling the spill valve in the injection pump and by changing the needle opening time.

#### **FUEL INJECTION TIMING CONTROL**

Based on the target fuel injection timing signal from the ECM, the injection timing is controlled in accordance with the timer spring by performing the duty control of the timing control valve in the injection pump and by adjusting the pressure of the timer piston high pressure chamber.

#### **FUEL TEMPERATURE SENSOR**

The sensor detects the fuel temperature in the injection pump and calibrates the injection amount change by the fuel temperature.

#### **CAM RING POSITION SENSOR**

The sensor detects the passing of the protrusion on the sensor wheel in the injection pump by the semiconductor magnetic resistance element sensor. The cam ring position sensor synchronizes with the cam ring, and detects the actual advance amount. The injection pump control unit measures the injection pump revolution by the signal of the cam ring position sensor.

# **CONSULT-II** Reference Value in Data Monitor Mode

GI

Remarks: Specification data are reference values.

$\Box A \Box$	Λ
INVAL	<b>/Δ\</b>
	$/ \cap \rangle$

LC

MONITOR ITEM	CONDITION		SPECIFICATION
FUEL TEMP SEN	Engine: After warming up		More than 40°C (104°F)
SPILL/V	Engine: After warmin	g up	Approx. 13°CA
INJ TIMG C/V	Engine: After warming up, idle the engine.		Approx. 50 - 70%
DECELER F/CUT	Engine: After warming up	Idle	OFF
BARO SEN	• Ignition switch: ON		Altitude Approx. 0 m (0 ft): Approx. 100.62 kPa (1.0062 bar, 1.026 kg/cm², 14.59 psi) Approx. 1,000 m (3,281 ft): Approx. 88.95 kPa (0.8895 bar, 0.907 kg/cm², 12.90 psi) Approx. 1,500 m (4,992 ft): Approx. 83.16 kPa (0.8316 bar, 0.848 kg/cm², 12.06 psi) Approx. 2,000 m (6,562 ft): Approx. 78.36 kPa (0.7836 bar, 0.799 kg/cm², 11.36 psi)

FE

EC

### **ECM Terminals and Reference Value**

AT

MT

Specification data are reference values and are measured between each terminal and ground.

TF

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

PD

FA

RA

BR

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	
33	G/Y	Electronic control fuel injection pump	Engine is running.  Warm-up condition Idle speed	Approximately 2.5V	
40	R/B	Electronic control fuel injection pump	Engine is running.  Warm-up condition Idle speed	Approximately 2.5V	
52	L/B	Electronic control fuel injection pump	Engine is running.  Idle speed	Approximately 0.1V	
53	L/R	Electronic control fuel injection pump	Engine is running.  Idle speed	Approximately 0.35V	

ST

RS

HA

BT


### On Board Diagnosis Logic

EL

Malfunction is detected when	Check Items (Possible cause)
<ul> <li>An improper voltage signal from fuel temperature sensor (Built-into electronic control fuel injection pump) is sent to injection pump control unit.</li> </ul>	<ul> <li>Harness or connectors (Electronic control fuel injection pump circuit is open or shorted.)</li> <li>Electronic control fuel injection pump</li> </ul>

SE

[DX




#### **DTC Confirmation Procedure**



- 1) Turn ignition switch "ON" and wait at least 2 seconds.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and run it for at least 2 seconds at idle speed. (If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-154.

## WITHOUT CONSULT-II


- 1) Turn ignition switch "ON" and wait at least 2 seconds.
- 2) Start engine and run it for at least 2 seconds at idle speed. (If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
- 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with FCM
- 5) If DTC is detected, go to "Diagnostic Procedure", EC-154.



### **Diagnostic Procedure**


#### CHECK ELECTRONIC CONTROL FUEL INJECTION PUMP POWER SUPPLY CIRCUIT

- 1. Turn ignition switch "OFF".
- 2. Disconnect electronic control fuel injection pump harness connector.



SEF229Z

- 3. Turn ignition switch "ON".
- 4. Check voltage between electronic control fuel injection pump terminal 7 and ground.



SEF438Y

#### OK or NG

OK	► GO TO 3.
NG	▶ GO TO 2.

#### 2 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M50, F5
- Harness connectors F4, EC4
- Harness for open or short between electronic control fuel injection pump and ECM
- Harness for open or short between electronic control fuel injection pump and ECM relay
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

#### 3 CHECK ELECTRONIC CONTROL FUEL INJECTION PUMP GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch "OFF".
- 2. Check harness continuity between electronic control fuel injection pump terminal 6 and ground. Refer to Wiring Diagram. Continuity should exist.
- 3. Also check harness for short to ground and short to power.

#### OK or NG

OK ▶	GO TO 5.
NG ▶	GO TO 4.

# DTC 0402 P9-FUEL TEMP SEN

		Diagnostic Prod	cedure (Cont'd)	
1	DETECT MALFUNCTIONI	NG PART		
Harr	the following. ness connectors F4, EC4 ness for open or short betwee	n electronic control fuel injection pump an	d engine ground	
	<b>&gt;</b>	Repair open circuit or short to ground or	short to power in harness or connectors.	
5	CHECK COMMUNICATIO	N LINE FOR OPEN AND SHORT		
1. Che	ck continuity between the foll	owing terminals. Refer to Wiring Diagram.		
		Electronic control fuel injection pump	ECM	
		1	33	
		2	40	
		5	52	
		8	53	
			MT	BL0444
ſ	Continuity should exist.			
	check harness for short to g	round and short to power.		
		OK or NG		
OK	<b>&gt;</b>	GO TO 7.	GO TO 7.	
NG	<b>•</b>	GO TO 6.		
6	DETECT MALFUNCTIONI	NG PART		
Check	the following.			$\overline{}$
<ul><li>Harr</li></ul>	ness connectors F4, EC4			
• Harr	less for open or short betwee	n electronic control fuel injection pump an		
	<b>•</b>	Repair open circuit or short to ground or	short to power in harness or connectors.	
7	CHECK INTERMITTENT I	NCIDENT		
Refer	to "TROUBLE DIAGNOSIS F	OR INTERMITTENT INCIDENT", EC-107.		
		OK or NG		
OK	•	Replace electronic control fuel injection p	ump.	
NG	<b>•</b>	Repair open circuit or short to ground or	short to power in harness or connectors.	

HA


EL

SE

### **Description**

The accelerator position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM. The ECM uses the signal to determine the amount of fuel to be injected.

The accelerator position switch detects Off-accelerator switch signal and Full-accelerator switch signal and send these signals to the ECM. The ECM will then determine engine idle conditions. These signals are also used for diagnosing the accelerator position sensor.



# **CONSULT-II** Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL POS SEN • Ignition switch: ON		Accelerator pedal: released	0.40 - 0.60V
ACCEL POS SEN	(Engine stopped)	Accelerator pedal: depressed	Approx. 4.5V
FULL ACCEL SW	Ignition switch: ON	Accelerator pedal: fully depressed	ON
FULL ACCEL SVV	(Engine stopped)	Except above	OFF
OFF ACCEL SW	Ignition switch: ON	Accelerator pedal: fully released	ON
OFF ACCEL SW	(Engine stopped)	Accelerator pedal: slightly open	OFF

### **ECM Terminals and Reference Value**

Specification data are reference values and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

					- 1211///
TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	· EM
22	)A/	Accelerator position sen-	Ignition switch "ON"  Accelerator pedal fully released	0.4 - 0.6V	EC
23	W	sor	Ignition switch "ON"  Accelerator pedal fully depressed	Approximately 4.5V	FE
31	R/L	Accelerator position switch	Ignition switch "ON"  Accelerator pedal fully released	BATTERY VOLTAGE (11 - 14V)	CL
31	R/L	(Idle)	Ignition switch "ON"  Accelerator pedal depressed	Approximately 0V	MT
	NVO.	Accelerator position switch	Ignition switch "ON"  Accelerator pedal released	Approximately 0V	AT
32	W/G	(Full)	Ignition switch "ON"  Accelerator pedal fully depressed	BATTERY VOLTAGE (11 - 14V)	TF
48	G/R	Accelerator position sensor power supply	Ignition switch "ON"	Approximately 5V	PD
51	L/W	Accelerator position sensor ground	Engine is running.  Warm-up condition Idle speed	Approximately 0V	FA
					. RA

### On Board Diagnosis Logic

Malfunction is detected when	Check Items (Possible Cause)	
The relation between sensor and switch signal is not in the normal range during the specified accelerator position.	<ul> <li>Harness or connectors (The sensor circuit is open or shorted.)</li> <li>Accelerator position sensor</li> <li>Accelerator position switch</li> <li>Accelerator switch (F/C)</li> </ul>	ST RS
		BT

MA

GI

FE


MT

BR

HA

EL

SE




#### **DTC Confirmation Procedure**




- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Depress and release fully accelerator pedal slowly.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-161.


### WITHOUT CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Depress and release fully accelerator pedal slowly.
- Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 5) If DTC is detected, go to "Diagnostic Procedure", EC-161.



### Wiring Diagram (Cont'd)





### **Diagnostic Procedure**

### c Procedure

### CHECK OVERALL FUNCTION-I

#### With CONSULT-II

- 1. Turn ignition switch "ON".
- 2. Select "ACCEL POS SEN" in "DATA MONITOR" mode with CONSULT-II.
- 3. Check "ACCEL POS SEN" signal under the following conditions.

DATA MONITOR		
MONITOR	NO DTC	
ACCEL POS SEN	xxxv	


Conditions	ACCEL POS SEN
Accelerator pedal fully depressed	Approx. 4.5V
Accelerator pedal fully released	0.40 - 0.60V

SEF278Z

#### Without CONSULT-II

1. Turn ignition switch "ON".

2. Check voltage between ECM terminal 23 and ground under the following conditions.



	Conditions	Voltage
,,,,,,,,,,,	Accelerator pedal fully depressed	Approx. 4.5V
	Accelerator pedal fully released	0.4 - 0.6V

SEF279Z

OK or NG

OK ▶	GO TO 2.
NG •	GO TO 3.

 $\mathbb{G}$ 

MA

EM

LC

EC

FE

GL

z mt

AT

TF

PD

FA

RA

BR

\_ \_

BT

HA

EL

SE

### **Diagnostic Procedure (Cont'd)**

#### CHECK OVERALL FUNCTION

### With CONSULT-II

- 1. Turn ignition switch "ON".
- 2. Select "FULL ACCEL SW" and "OFF ACCEL SW" in "DATA MONITOR" mode with CONSULT-II.
- 3. Check "FULL ACCEL SW" and "OFF ACCEL SW" signal under the following conditions.

DATA MONITOR		
MONITOR	NO DTC	
FULL ACCEL SW	OFF	
OFF ACCEL SW	ON	


Conditions	FULL ACCEL SW
Accelerator pedal fully depressed	ON
Except above	OFF

Conditions	OFF ACCEL SW
Accelerator pedal fully released	ON
Accelerator pedal depressed	OFF

SEF416Y

#### Without CONSULT-II

- 1. Turn ignition switch "ON".
- 2. Check voltage between ECM terminals 31, 32 and ground under the following conditions.



Conditions	Voltage (ECM terminal 32)
Accelerator pedal fully depressed	Battery voltage
Except above	Approx. 0V


Conditions	Voltage (ECM terminal 31)		
Accelerator pedal fully released	Battery voltage		
Accelerator pedal depressed	Approx. 0V		

SEF417Y

OK or NG

OK •	INSPECTION END
NG •	GO TO 14.

### **Diagnostic Procedure (Cont'd)**



HA


EL

SE

### **Diagnostic Procedure (Cont'd)**

#### CHECK ACCELERATOR POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch "OFF".
- 2. Loosen and retighten engine ground screw.



SEF227Z

- 3. Check harness continuity between accelerator position sensor terminal 3 and engine ground. Refer to Wiring Diagram. Continuity should exist.
- 4. Also check harness for short to ground and short to power.

#### OK or NG

OK ▶	GO TO 7.
NG <b>•</b>	GO TO 6.

#### **DETECT MALFUNCTIONING PART** 6

Check the following.

- Harness connectors F7, M52 (RHD models)
- Harness for open or short between ECM and accelerator position sensor
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

#### CHECK ACCELERATOR POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- 1. Disconnect ECM harness connector.
- 2. Check harness continuity between ECM terminal 23 and accelerator position sensor terminal 2. Refer to Wiring Diagram.

#### Continuity should exist.

3. Also check harness for short to ground and short to power.

#### OK or NG

ок	<b>•</b>	GO TO 9.
NG	<b>•</b>	GO TO 8.

#### **DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors F7, M52 (RHD models)
- Harness for open or short between ECM and accelerator position sensor
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

### **Diagnostic Procedure (Cont'd)**

#### GI CHECK ACCELERATOR POSITION SENSOR (II) With CONSULT-II 1. Reconnect all disconnected harness connectors. MA 2. Turn ignition switch "ON". 3. Select "DATA MONITOR" mode with CONSULT-II. 4. Check the indication of "ACCEL POS SEN" under the following conditions. EM DATA MONITOR MONITOR LC NO DTC CKPS-RPM (TDC) XXX rpm Throttle valve conditions ACCEL POS SEN ACCEL POS SEN XXX V EC Completely closed (a) 0.4 - 0.6V Partially open Between (a) and (b) FE Completely open (b) Approx. 4.5V GL SEF818Y OK or NG MT OK GO TO 11. $\triangleright$ NG Replace accelerator pedal assembly. AT 10 **CHECK ACCELERATOR POSITION SENSOR** TF Without CONSULT-II 1. Reconnect all disconnected harness connectors. 2. Turn ignition switch "ON". PD 3. Check voltage between ECM terminal 23 and ground under the following conditions. FA ECM CONNECTOR RA Throttle valve conditions Voltage Completely closed (a) 0.4 - 0.6V Partially open Between (a) and (b) BR Completely open (b) Approx. 4.5V SEF407Y OK or NG OK GO TO 12. BT NG Replace accelerator pedal assembly. 11 RESET ACCELERATOR POSITION SENSOR IDLE POSITION MEMORY HA (P) With CONSULT-II 1. Turn ignition switch "ON". 2. Select "OFF ACCEL PO SIG" in "ACTIVE TEST" mode with CONSULT-II. EL 3. Touch "CLEAR". GO TO 13.

### Diagnostic Procedure (Cont'd)

#### 12 RESET ACCELERATOR POSITION SENSOR IDLE POSITION MEMORY

#### Without CONSULT-II

- 1. Start engine and warm it up to normal operating temperature.
- 2. Let engine idle for 10 minutes.

► GO TO 13.


#### 13 CHECK INTERMITTENT INCIDENT

Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.

**▶** INSPECTION END


#### 14 CHECK ACCELERATOR POSITION SWITCH POWER SUPPLY CIRCUIT

- 1. Turn ignition switch "OFF".
- 2. Disconnect accelerator position switch harness connector.



SEF708V

- 3. Turn ignition switch "ON".
- 4. Check voltage between accelerator position switch terminal 5 and ground with CONSULT-II or tester.



Voltage: Battery voltage

SEF346X

OK or NG

OK ▶	•	GO TO 16.
NG	•	GO TO 15.

#### 15 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M50, F5 (LHD models)
- Harness for open or short between accelerator position switch and ECM relay
- Harness for open or short between accelerator position switch and ECM
  - ▶ Repair harness or connectors.

GI

MA

EM

LC

EC

MT

AT

TF

PD

FA

RA

BT

HA

### **DTC 0403 ACCEL POS SENSOR**

### Diagnostic Procedure (Cont'd)

16	6 CHECK ACCELERATOR POSITION SWITCH INPUT SIGNAL CIRCUIT-I FOR OPEN AND SHORT		
1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between accelerator position switch terminal 6 and ECM terminal 31. Refer to Wiring Diagram.  Continuity should exist. 4. Also check harness for short to ground and short to power.			
OK or NG			
OK	<b>&gt;</b>	GO TO 18.	
NG	<b>•</b>	GO TO 17.	


17	DETECT MALFUNCTIONING PART	
Check the following.  • Harness connectors M52, F7 (RHD models)  • Harness for open or short between ECM and accelerator position switch		
Repair open circuit or short to ground or short to power in harness or connectors.		

Check harness continuity between accelerator position switch terminal 4 and ECM terminal 32. Refer to Wiring Diagram.     Continuity should exist.      Also check harness for short to ground and short to power.		
OK or NG		
OK ▶	GO TO 20.	
NG ▶	GO TO 19.	

19	DETECT MALFUNCTIONING PART
Check the following.  • Harness connectors M52, F7 (RHD models)  • Harness for open or short between ECM and accelerator position switch	

Repair open circuit or short to ground or short to power in harness or connectors.			
	20 CHECK ACCELERATOR POSITION SWITCH		

Check continuity between accelerator position switch terminals 4 and 5, 5 and 6 under the following conditions.



Between terminals 4 and 5		
Conditions	Continuity	
Accelerator pedal fully depressed	Should exist.	
Except above	Should not exist.	

Between terminals 5 and 6	
Conditions	Continuity
Accelerator pedal fully released	Should exist.
Accelerator pedal depressed	Should not exist.

			SEF418Y
OK or NG			
OK (With CONSULT-II)	<b>&gt;</b>	GO TO 21.	
OK (Without CONSULT-II)	<b>&gt;</b>	GO TO 22.	
NG	<b>&gt;</b>	Replace accelerator pedal assembly.	

SE

ZD30DDTi

### DTC 0403 ACCEL POS SENSOR

### **Diagnostic Procedure (Cont'd)**

#### 21 RESET ACCELERATOR POSITION SENSOR IDLE POSITION MEMORY

#### (I) With CONSULT-II

- 1. Turn ignition switch "ON".
- 2. Select "OFF ACCEL PO SIG" in "ACTIVE TEST" mode with CONSULT-II.
- 3. Touch "CLEAR".

▶ GO TO 23.

#### 22 RESET ACCELERATOR POSITION SENSOR IDLE POSITION MEMORY

#### Without CONSULT-II

- 1. Start engine and warm it up to normal operating temperature.
- 2. Let engine idle for 10 minutes.

▶ GO TO 23.

#### 23 CHECK INTERMITTENT INCIDENT

Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.

**▶** INSPECTION END

### On Board Diagnosis Logic

		_
Malfunction is detected when	Check Items (Possible Cause)	_ MA
<ul> <li>An excessively high voltage from the mass air flow sensor is sent to ECM when engine is running.</li> </ul>	<ul> <li>Air duct</li> <li>Charge air cooler</li> <li>Variable nozzle turbocharger control system</li> <li>Variable nozzle turbocharger</li> </ul>	EM
	Mass air flow sensor     Harness or connectors     (The mass air flow sensor circuit is shorted.)	LC

#### **DTC Confirmation Procedure**

#### NOTE:

If DTC 0406 "INT AIR VOL" displayed with DTC 0102 "MASS AIR FLOW SEN", perform trouble diagnosis for DTC 0102 "MASS AIR FLOW SEN" first. (See EC-117.)

GL

EC

GI

MT

AT

TF

PD

FA

RA

BR

DATA MONITOR
MONITOR
NO DTC
CKPS-RPM (TDC) XXX rpm

SEF817Y

### WITH CONSULT-II

1) Turn ignition switch "ON".

Select "DATA MONITOR" mode with CONSULT-II.

3) Start engine and warm it up to normal operating temperature.

4) Drive vehicle.

Maintain the engine speed more than 4,000 rpm for at least 10 seconds.

6) If DTC is detected, go to "Diagnostic Procedure", EC-170.

WITHOUT CONSULT-II

1) Start engine and warm it up to normal operating temperature.

2) Drive vehicle.

3) Maintain the engine speed more than 4,000 rpm for at least 10 seconds.

4) Stop vehicle.

5) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON"

 Perform "Diagnostic Test Mode II (Self-diagnostic results)" with FCM

7) If DTC is detected, go to "Diagnostic Procedure", EC-170.

DS.

BT

HA

EL

SE


 $\mathbb{D}\mathbb{X}$ 

### **Diagnostic Procedure**

1	CHECK INTAKE AIR LEAK	
Listen for an intake air leak after the mass air flow sensor.		
OK or NG		
OK ▶ GO TO 2.		
NG	<b>•</b>	Repair or replace.

#### 2 CHECK VARIABLE NOZZLE TURBOCHARGER OVERALL FUNCTION

- 1. Start engine and let it idle.
- 2. Make sure that variable nozzle turbocharger control actuator rod moves when revving engine up to 3,000 rpm and returning to idle.




SEF320Z

OK or NO
----------

OK ► GO TO 3.	
NG ►	Go to "Diagnostic Procedure" in "VARIABLE NOZZLE TURBOCHARGER CONTROL SOLENOID VALVE", EC-295.

#### 3 CHECK MASS AIR FLOW SENSOR

- 1. Start engine and warm it up to normal operating temperature.
- 2. Check voltage between ECM terminal 35 (Mass air flow sensor signal) and ground.



Condition	Voltage V
Ignition switch "ON" (Engine stopped.)	Approx. 1.0
Idle (Engine is warmed-up to normal operating temperature.)	1.6 - 2.0
Idle to about 4,000 rpm*	1.6 - 2.0 to Approx. 4.0

\*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.


SEF400Y

3. If the voltage is out of specification, disconnect MAFS harness connector and connect it again. Then repeat above check.

#### OK or NG

OK ▶	GO TO 4.
NG •	Replace mass air flow sensor.

4	CHECK INTERMIT INCIDENT	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.		
► INSPECTION END		



### **Description**

The crankshaft position sensor (TDC) monitors engine speed by means of signals from the sensing plate (with three protrusions) installed to the crankshaft pulley. The data signal output is detected at ATDC 70° and sent to the ECM. The sensor signal is used for fuel injection control and fuel injection timing control.

GI

MA

EM

LC

EC

GL

MT

AT

### **CONSULT-II Reference Value in Data Monitor** Mode

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
CKPS-RPM (TDC)	■ Run engine and compare tachometer indication with the CONSULT-II	Almost the same speed as the CONSULT-II value.

**ECM Terminals and Reference Value** 


Specification data are reference values and are measured between each terminal and ground.

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)	PD
				Approximately 0V	FA
			Engine is running.	(V) 20 10	RA
				0 5 ms	BR
44	L	Crankshaft position sensor		SEF333Y	ST
• •	_	(TDC)		Approximately 0V	@@
		Crankshaft position sensor (TDC) ground	Engine is running.  Warm-up condition  Engine speed is 2,000 rpm	(V) 20 10	RS BT
				5 ms   SEF334Y	HA
47	B/W		Engine is running.  Warm-up condition Idle speed	Approximately 0V	
					SE

### On Board Diagnosis Logic

Malfunction is detected when	Check Items (Possible Cause)
<ul> <li>An improper signal from the sensor is sent to ECM during engine running and cranking.</li> </ul>	<ul> <li>Harness or connectors (The sensor circuit is open.)</li> <li>Crankshaft position sensor (TDC)</li> </ul>



#### **DTC Confirmation Procedure**


Before performing the following procedure, confirm that battery voltage is more than 10V.



- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
- 2) Crank engine for at least 1 second.
- 3) Start engine and run it for at least 2 seconds at idle speed.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-174.

## WITHOUT CONSULT-II


- 1) Crank engine for at least 1 second.
- 2) Start engine and run it for at least 2 seconds at idle speed.
- 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 5) If DTC is detected, go to "Diagnostic Procedure", EC-174.



### **Diagnostic Procedure**


#### 1 CHECK CRANKSHAFT POSITION SENSOR (TDC) GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch "OFF".
- 2. Loosen and retighten engine ground screws.



SEF227Z

3. Disconnect crankshaft position sensor (TDC) harness connector and ECM harness connector.



SEF230Z

- Check harness continuity between ECM terminal 47 and terminal 2. Refer to Wiring Diagram.
   Continuity should exist.
- 5. Also check harness for short to ground and short to power.

#### OK or NG

OK •	<b>&gt;</b>	GO TO 2.
NG	•	Repair open circuit or short to ground or short to power in harness or connectors.

#### 2 CHECK CRANKSHAFT POSITION SENSOR (TDC) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- Check harness continuity between terminal 1 and ECM terminal 44. Refer to Wiring Diagram.
   Continuity should exist.
- 2. Also check harness for short to ground and short to power.

#### OK or NG

OK •	GO TO 3.
NG <b>&gt;</b>	Repair open circuit or short to ground or short to power in harness or connectors.

#### 3 CHECK CRANKSHAFT POSITION SENSOR SHIELD CIRCUIT

- 1. Check harness continuity between crankshaft position sensor (TDC) terminal 3 and engine ground. Refer to Wiring Diagram. Continuity should exist.
- 2. Also check harness for short to ground and short to power.

#### OK or NG

OK ▶	GO TO 5.
NG •	GO TO 4.

### **DTC 0407 CRANK POS SEN (TDC)**

### Diagnostic Procedure (Cont'd)

# **DETECT MALFUNCTIONING PART**

Check the following.


Joint connector-4

• Harness for open or short between crankshaft position sensor (TDC) and engine ground

Repair open circuit or short to ground or short to power in harness or connectors.

# CHECK CRANKSHAFT POSITION SENSOR (TDC) INSTALLATION

Check the clearance between crankshaft position sensor (TDC) and protrusion on the crankshaft pulley.




OK or NG

ОК	<b>&gt;</b>	GO TO 6.
NG	<b>&gt;</b>	GO TO 7.

#### 6 **REINSTALL CRANKSHAFT POSITION SENSOR (TDC)**

1. Remove crankshaft position sensor (TDC).

2. Install crankshaft position sensor (TDC) properly.



**INSPECTION END** 

GI

MA

EM

LC

EC

FE

GL

MT

JEF293Z

AT

TF

PD

FA

RA

BR

ST

BT

HA

EL


SE

### DTC 0407 CRANK POS SEN (TDC)

### **Diagnostic Procedure (Cont'd)**

### CHECK CRANKSHAFT POSITION SENSOR (TDC)-I

- 1. Loosen the fixing bolt and remove the crankshaft position sensor (TDC).
- 2. Visually check the sensor for chipping.



SEF232Z

#### OK or NG

OK ►	GO TO 8.
NG •	Replace crankshaft position sensor (TDC).

#### 8 CHECK CRANKSHAFT POSITION SENSOR (TDC)-II

- 1. Disconnect crankshaft position sensor (TDC) harness connector.
- 2. Check resistance between crankshaft position sensor (TDC) terminals 1 and 2.





Resistance: 1,287 - 1,573 $\Omega$  [at 20°C (68°F)]

SEF295Z

#### OK or NG

OK •	GO TO 9.
NG •	Replace crankshaft position sensor (TDC).

#### 9 CHECK INTERMITTENT INCIDENT

Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.

► INSPECTION END

### On Board Diagnosis Logic

The ECM checks if battery voltage is within the tolerance range for the engine control system.

		D D D D
Malfunction is detected when	Check Items (Possible Cause)	• MA
• An abnormally high voltage from the battery is sent to ECM.	<ul><li>Incorrect jump starting</li><li>Battery</li><li>Alternator</li></ul>	EM
	• ECM	_ LC

#### **DTC Confirmation Procedure**

With CONSULT-II

1) Check the following.

- Jumper cables are connected for jump starting.
- Battery or alternator has been replaced. If the result is "Yes" for one item or more, skip the following steps and go to "Diagnostic Procedure", EC-177.
- 2) Check that the positive battery terminal is connected to battery properly. If NG, reconnect it properly.
- Check that the alternator functions properly. Refer to EL section ("CHARGING SYSTEM").
- 4) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
- Wait one minute.
- 6) If DTC is detected, go to "Diagnostic Procedure", EC-177. If DTC is not detected, go to next step.
- 7) Start engine and wait one minute at idle.
- 8) If DTC is detected, go to "Diagnostic Procedure", EC-177.

### Without CONSULT-II

- 1) Check the following.
- Jumper cables are connected for jump starting.
- Battery or alternator has been replaced. If the result is "Yes" for one item or more, skip the following steps and go to "Diagnostic Procedure".
- 2) Check that the positive battery terminal is connected to battery properly. If NG, reconnect it properly.
- Check that the alternator functions properly. Refer to EL section ("CHARGING SYSTEM").
- 4) Turn ignition switch "ON" and wait one minute.
- 5) Turn ignition switch "OFF", wait 5 seconds and then turn "ON".
- 6) Perform "Diagnostic Test Mode II (Self-diagnostic result)" with ECM.
- 7) If DTC is detected, go to "Diagnostic Procedure", EC-177. If DTC is not detected, go to next step.
- 8) Start engine and wait one minute at idle.
- 9) Turn ignition switch "OFF", wait 5 seconds and then turn "ON".
- 10) Perform "Diagnostic Test Mode II (Self-diagnostic result)" with ECM.
- 11) If DTC is detected, go to "Diagnostic Procedure", EC-177.

### **Diagnostic Procedure**

1	INSPECTION START		
Are jump	Are jumper cables connected for the jump starting?		
	Yes or No		
Yes	•	GO TO 3.	
No	<b>&gt;</b>	GO TO 2.	

EC-177

EC

MT

AT

RA


BR

HA

EL

## Diagnostic Procedure (Cont'd)

2	CHECK BATTERY AND A	LTERNATOR	
	Check that the proper type of battery and alternator is installed.  Refer to EL section ("BATTERY" and "CHARGING SYSTEM").		
	OK or NG		
ОК	<b>•</b>	GO TO 5.	
NG	•	Replace with a proper one.	



4	CHECK BATTERY FOR B	OOSTER	
Check tl	Check that the battery for the booster is a 12V battery.		
	OK or NG		
ОК	<b>&gt;</b>	GO TO 5.	
NG	<b>&gt;</b>	Change the vehicle for booster.	

5	5 PERFORM DTC CONFIRMATION PROCEDURE AGAIN		
Perform	Perform "DTC Confirmation Procedure", EC-177, again.		
	OK or NG		
ОК	<b>&gt;</b>	GO TO 6.	
NG	<b>•</b>	Replace ECM.	

6	CHECK ELECTRICAL PA	RTS DAMAGE
<ul><li>Wirir</li></ul>	Check the following for damage.  • Wiring harness and harness connectors for burn  • Fuses for short  OK or NG	
ок	<b>&gt;</b>	INSPECTION END
NG	<b>&gt;</b>	Repair or replace malfunctioning part.

### **System Description**

These circuit lines are used to control the smooth shifting up and down of A/T during the hard acceleration/deceleration.

Voltage signals are exchanged between ECM and TCM (Transmission control module).

## EM

LC

MA

GI

### **ECM Terminals and Reference Value**

Specification data are reference values and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24 37 58	PU/W P/B L/OR	A/T signal No. 1 A/T signal No. 2 A/T signal No. 4	Engine is running.  Warm-up condition Idle speed	Voltage goes high up once in a few seconds  (V) 10 5 0 SEF448Z
30	Р	A/T signal No. 3	Engine is running.  Warm-up condition Idle speed  Engine is running.  Warm-up condition Engine speed is 2,000 rpm	Approximately 0V  Approximately 7.7V

### On Board Diagnosis Logic

Malfunction is detected when	Check Items (Possible Cause)
ECM receives incorrect voltage from TCM (Transmission control module) continuously.	Harness or connectors [The circuit between ECM and TCM (Transmission control module) is open or shorted.]

EC

FE

CL

MT

TF

AT

PD

RA

FA

BR

ST


1 110

BT

HA

EL

SE



#### **DTC Confirmation Procedure**

#### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.




#### With CONSULT-II

- 1) Start engine.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Set selector lever to "D" position.
- 4) Accelerate up to 60 km/h (37 MPH) gradually on the accelerator pedal.


#### Do not accelerate with shift down.

- 5) Stop the vehicle with engine running.
- 6) If DTC is detected, go to "Diagnostic Procedure", EC-182.




#### **Overall Function Check**

Use this procedure to check the overall function of the A/T control circuit. During this check, a DTC might not be confirmed.




- 1) Start engine.
- 2) Read the voltage signal between ECM terminals 24, 30, 37, 58 and ground with an oscilloscope.
- 3) Verify that the oscilloscope screen shows the signal wave as shown under "ECM Terminals and Reference Value" on the previous page.
- 4) If NG, go to "Diagnostic Procedure", EC-182.



### **Diagnostic Procedure**


#### **CHECK INPUT SIGNAL CIRCUIT**

- 1. Turn ignition switch "OFF".
- 2. Disconnect ECM harness connector and TCM (Transmission control module) harness connector.



Driver's side instrument lower cover removed

SEF519VA



SEF792V

3. Check harness continuity between the following terminals. Refer to Wiring Diagram.

ECM	TCM
24	5
30	7
37	6
58	9

MTBL0532

#### Continuity should exist.

#### OK or NG

OK ▶	GO TO 3.
NG ▶	GO TO 2.

#### 2 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E106, M88
- Harness connectors M51, F6
- Harness connectors E104, M86 (RHD models)
- Harness for open or short between ECM and TCM (Transmission control module)
  - ► Repair harness or connectors.

ZD30DDTi

### DTC 0504 A/T COMM LINE

## Diagnostic Procedure (Cont'd)

3	CHECK INPUT SIGNAL C	IRCUIT	
ECM Co	k harness continuity betwee terminal 58 and ground. Re continuity should not exist. check harness for short to g		MA
		OK or NG	EM
ОК	•	GO TO 5.	
NG	<b>•</b>	GO TO 4.	LC
			1

5	CHECK INTERMITTENT I	NCIDENT	
	<u> </u>	Repair open circuit short to ground or short to power in harness.	
CHECK	ne narness for open or snor	t between ECM and TCM (Transmission control module).	

**DETECT MALFUNCTIONING PART** 

5	CHECK INTERMITTENT I	NCIDENT	
Refer to	er to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.		
	► INSPECTION END		

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS


BT

HA

EL

SE

 $\mathbb{D}\mathbb{X}$ 



#### **Description**

#### SYSTEM DESCRIPTION

The ECM and the electronic control fuel injection pump control unit (abbreviated as the injection pump control unit) perform the real time communication (signal exchange).

The ECM transmits the signals of the target fuel injection amount, target fuel injection timing, and engine speed, etc., and receives the signals of the pump speed and fuel temperature, etc. from the injection pump control unit.

By those signals, the injection pump controls the optimum fuel injection amount and injection timing of the spill valve and timing control valve.

Injection pump control unit has an on board diagnostic system, which detects malfunctions related to sensors or actuators built-into electronic control fuel injection pump. These malfunction information are transferred through the line (circuit) from injection pump control unit to ECM.

#### **FUEL INJECTION AMOUNT CONTROL**

In accordance with the target fuel injection amount signal from the ECM, the injection amount is controlled by controlling the spill valve in the injection pump and by changing the needle opening time.

#### **FUEL INJECTION TIMING CONTROL**

Based on the target fuel injection timing signal from the ECM, the injection timing is controlled in accordance with the timer spring by performing the duty control of the timing control valve in the injection pump and by adjusting the pressure of the timer piston high pressure chamber.

#### **FUEL TEMPERATURE SENSOR**

The sensor detects the fuel temperature in the injection pump and calibrates the injection amount change by the fuel temperature.

#### **CAM RING POSITION SENSOR**

The sensor detects the passing of the protrusion on the sensor wheel in the injection pump by the semiconductor magnetic resistance element sensor. The cam ring position sensor synchronizes with the cam ring, and detects the actual advance amount. The injection pump control unit measures the injection pump revolution by the signal of the cam ring position sensor.

GI

MA

EM

LC

EC

FE

GL

MT

AT

TF

# **CONSULT-II Reference Value in Data Monitor Mode**

Remarks: Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION	
FUEL TEMP SEN	Engine: After warmin	g up	More than 40°C (104°F)	
SPILL/V	Engine: After warming up		Approx. 13°CA	
INJ TIMG C/V	Engine: After warming up, idle the engine.		Approx. 50 - 70%	
DECELER F/CUT	Engine: After warming up	Idle	OFF	
BARO SEN	• Ignition switch: ON		Altitude Approx. 0 m (0 ft): Approx. 100.62 kPa (1.0062 bar, 1.026 kg/cm², 14.59 psi) Approx. 1,000 m (3,281 ft): Approx. 88.95 kPa (0.8895 bar, 0.907 kg/cm², 12.90 psi) Approx. 1,500 m (4,992 ft): Approx. 83.16 kPa (0.8316 bar, 0.848 kg/cm², 12.06 psi) Approx. 2,000 m (6,562 ft): Approx. 78.36 kPa (0.7836 bar, 0.799 kg/cm², 11.36 psi)	

#### **ECM Terminals and Reference Value**

Specification data are reference values and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


ECM's	transist	or. Use a ground othe	r than ECM terminals, such as the ground.		PD
TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	FA
33	G/Y	Electronic control fuel injection pump	Engine is running.  Warm-up condition Idle speed	Approximately 2.5V	RA
40	R/B	Electronic control fuel injection pump	Engine is running.  Warm-up condition Idle speed	Approximately 2.5V	BR ST
52	L/B	Electronic control fuel injection pump	Engine is running.  Idle speed	Approximately 0.1V	RS
53	L/R	Electronic control fuel injection pump	Engine is running.  Idle speed	Approximately 0.35V	BT

### On Board Diagnosis Logic

Malfunction is detected when	Check Items (Possible cause)	
<ul> <li>An improper voltage signal from cam position sensor (Built- into electronic control fuel injection pump) is sent to injection pump control unit.</li> </ul>	Harness or connectors     (Electronic control fuel injection pump circuit is open or shorted.)     Electronic control fuel injection pump	

HA

EL




#### **DTC Confirmation Procedure**



- 1) Turn ignition switch "ON" and wait at least 2 seconds.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and run it for at least 2 seconds at idle speed. (If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-188.

### WITHOUT CONSULT-II


- 1) Turn ignition switch "ON" and wait at least 2 seconds.
- 2) Start engine and run it for at least 2 seconds at idle speed. (If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
- 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with FCM
- 5) If DTC is detected, go to "Diagnostic Procedure", EC-188.



### **Diagnostic Procedure**


#### CHECK ELECTRONIC CONTROL FUEL INJECTION PUMP POWER SUPPLY CIRCUIT

- 1. Turn ignition switch "OFF".
- 2. Disconnect electronic control fuel injection pump harness connector.



SEF229Z

- 3. Turn ignition switch "ON".
- 4. Check voltage between electronic control fuel injection pump terminal 7 and ground.



SEF438Y

OK	► GO TO 3.	► GO TO 3.
NG	▶ GO TO 2.	▶ GO TO 2.

#### 2 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M50, F5
- Harness connectors F4, EC4
- Harness for open or short between electronic control fuel injection pump and ECM
- Harness for open or short between electronic control fuel injection pump and ECM relay
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

#### 3 CHECK ELECTRONIC CONTROL FUEL INJECTION PUMP GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch "OFF".
- 2. Check harness continuity between electronic control fuel injection pump terminal 6 and ground. Refer to Wiring Diagram. **Continuity should exist.**
- 3. Also check harness for short to ground and short to power.

OK	or	NG

OK or NG

OK ▶	GO TO 5.
NG •	GO TO 4.


### DTC 0701 P1-CAM POS SEN

		Diagnostic Proc	edure (Co	ont'd)
4	DETECT MALFUNCTION	NG PART		
<ul><li>Harr</li></ul>	the following. ness connectors F4, EC4 ness for open or short betwee	n electronic control fuel injection pump and	d engine ground	
	<b>•</b>	Repair open circuit or short to ground or s	short to power in	n harness or connectors.
5		N LINE FOR OPEN AND SHORT		
1. Che	eck continuity between the foll	owing terminals. Refer to Wiring Diagram.		
		Electronic control fuel injection pump	ECM	
		1	33	
		2	40	
		<u>5</u> 8	52 53	
		-		
				MTBL0444
	Continuity should exist.			
	check harness for short to g	round and short to power.		
		OK or NG		
OK	<b>•</b>	GO TO 7.		
NG	<b>•</b>	GO TO 6.		
6	DETECT MALFUNCTION	NG PART		
Check	the following.			
	ness connectors F4, EC4	a alactronia aportral final injection anno ana	LECM	
• Harr		n electronic control fuel injection pump and		
	<u> </u>	Repair open circuit or short to ground or s	short to power in	n harness or connectors.
_	T			
7	CHECK INTERMITTENT I			
Refer	to "TROUBLE DIAGNOSIS F	OR INTERMITTENT INCIDENT", EC-107.		
		OK or NG		
OK	<b>&gt;</b>	Replace electronic control fuel injection po	ump.	
NG	<b>&gt;</b>	Repair open circuit or short to ground or s	short to power in	h harness or connectors.

HA

EL

SE



#### **Description**

#### SYSTEM DESCRIPTION

The ECM and the electronic control fuel injection pump control unit (abbreviated as the injection pump control unit) perform the real time communication (signal exchange).

The ECM transmits the signals of the target fuel injection amount, target fuel injection timing, and engine speed, etc., and receives the signals of the pump speed and fuel temperature, etc. from the injection pump control unit.

By those signals, the injection pump controls the optimum fuel injection amount and injection timing of the spill valve and timing control valve.

Injection pump control unit has an on board diagnostic system, which detects malfunctions related to sensors or actuators built-into electronic control fuel injection pump. These malfunction information are transferred through the line (circuit) from injection pump control unit to ECM.

#### **FUEL INJECTION AMOUNT CONTROL**

In accordance with the target fuel injection amount signal from the ECM, the injection amount is controlled by controlling the spill valve in the injection pump and by changing the needle opening time.

#### FUEL INJECTION TIMING CONTROL

Based on the target fuel injection timing signal from the ECM, the injection timing is controlled in accordance with the timer spring by performing the duty control of the timing control valve in the injection pump and by adjusting the pressure of the timer piston high pressure chamber.

#### **FUEL TEMPERATURE SENSOR**

The sensor detects the fuel temperature in the injection pump and calibrates the injection amount change by the fuel temperature.

#### **CAM RING POSITION SENSOR**

The sensor detects the passing of the protrusion on the sensor wheel in the injection pump by the semiconductor magnetic resistance element sensor. The cam ring position sensor synchronizes with the cam ring, and detects the actual advance amount. The injection pump control unit measures the injection pump revolution by the signal of the cam ring position sensor.

#### **CONSULT-II Reference Value in Data Monitor** Mode

Remarks: Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
FUEL TEMP SEN	Engine: After warming up		More than 40°C (104°F)
SPILL/V	Engine: After warming up		Approx. 13°CA
INJ TIMG C/V	Engine: After warming up, idle the engine.		Approx. 50 - 70%
DECELER F/CUT	Engine: After warming up  Idle		OFF
BARO SEN	ing up		Altitude Approx. 0 m (0 ft): Approx. 100.62 kPa (1.0062 bar, 1.026 kg/cm², 14.59 psi) Approx. 1,000 m (3,281 ft): Approx. 88.95 kPa (0.8895 bar, 0.907 kg/cm², 12.90 psi) Approx. 1,500 m (4,992 ft): Approx. 83.16 kPa (0.8316 bar, 0.848 kg/cm², 12.06 psi) Approx. 2,000 m (6,562 ft): Approx. 78.36 kPa (0.7836 bar, 0.799 kg/cm², 11.36 psi)

#### **ECM Terminals and Reference Value**

Specification data are reference values and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

			,		
TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	
33	G/Y	Electronic control fuel injection pump	Engine is running.  Warm-up condition Idle speed	Approximately 2.5V	
40	R/B	Electronic control fuel injection pump	Engine is running.  Warm-up condition Idle speed	Approximately 2.5V	
52	L/B	Electronic control fuel injection pump	Engine is running.  Lidle speed	Approximately 0.1V	
53	L/R	Electronic control fuel injection pump	Engine is running.  Lidle speed	Approximately 0.35V	

### On Board Diagnosis Logic

Malfunction is detected when	Check Items (Possible cause)	
Injection pump control unit input signal [Crankshaft position sensor (TDC) signal] processing function is malfunctioning.	Harness or connectors     (Electronic control fuel injection pump circuit is open or shorted.)     Electronic control fuel injection pump	(

EM

LC

EC

FE

GL

MT

AT TF

PD

FA

RA

BR


ST

BT

HA

EL

SE




#### **DTC Confirmation Procedure**

### WITH CONSULT-II

- 1) Turn ignition switch "ON" and wait at least 2 seconds.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and run it for at least 2 seconds at idle speed. (If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
- 4) If DTC 0407 is detected, go to "Diagnostic procedure", EC-174. If DTC 0702 is detected, go to "Diagnostic Procedure", EC-194.

### WITHOUT CONSULT-II


- 1) Turn ignition switch "ON" and wait at least 2 seconds.
- 2) Start engine and run it for at least 2 seconds at idle speed. (If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
- 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 5) If DTC 0407 is detected, go to "Diagnostic Procedure", EC-174. If DTC 0702 is detected, go to "Diagnostic Procedure", EC-194.



### **Diagnostic Procedure**


#### 1 CHECK ELECTRONIC CONTROL FUEL INJECTION PUMP POWER SUPPLY CIRCUIT

- 1. Turn ignition switch "OFF".
- 2. Disconnect electronic control fuel injection pump harness connector.



SEF229Z

- 3. Turn ignition switch "ON".
- 4. Check voltage between electronic control fuel injection pump terminal 7 and ground.



SEF438Y

OK	<b>&gt;</b>	GO TO 3.
NG	<b>•</b>	GO TO 2.

#### 2 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M50, F5
- Harness connectors F4, EC4
- Harness for open or short between electronic control fuel injection pump and ECM
- Harness for open or short between electronic control fuel injection pump and ECM relay
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

#### 3 CHECK ELECTRONIC CONTROL FUEL INJECTION PUMP GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch "OFF".
- 2. Check harness continuity between electronic control fuel injection pump terminal 6 and ground. Refer to Wiring Diagram. **Continuity should exist.**
- 3. Also check harness for short to ground and short to power.

OK	or	NG

OK or NG


OK ▶	GO TO 5.
NG •	GO TO 4.

# DTC 0702 P2 TDC PULSE SIG

		Diagnostic Proc			
4	DETECT MALFUNCTIONI	NG PART			
Harr	the following. ness connectors F4, EC4 ness for open or short betwee	n electronic control fuel injection pump and	engine ground		
	<b>•</b>	Repair open circuit or short to ground or s		s or connectors.	
	T				
5 1 Cho		N LINE FOR OPEN AND SHORT owing terminals. Refer to Wiring Diagram.			
i. One	sek continuity between the foil	owing terminals. Itelef to willing Diagram.			
		Electronic control fuel injection pump	ECM		
		12	33 40		
		 5	52		
		8	53		
				MTDL 0444	
				MTBL0444	
	Continuity should exist.  o check harness for short to g	round and short to power.			
, 1100	ssak harrisso for short to g	OK or NG			
OK	<b>•</b>				
•					
NG	·	GO TO 7. GO TO 6.			
NG		GO TO 6.			
		GO TO 6.			
6	DETECT MALFUNCTIONI	GO TO 6.			
6 Check	DETECT MALFUNCTIONI the following. ness connectors F4, EC4	GO TO 6.  NG PART			
<b>6</b> Check • Harr	DETECT MALFUNCTIONI the following. ness connectors F4, EC4 ness for open or short between	GO TO 6.  NG PART  n electronic control fuel injection pump and			
<b>6</b> Check • Harr	DETECT MALFUNCTIONI the following. ness connectors F4, EC4	GO TO 6.  NG PART		s or connectors.	
6 Check • Harr	DETECT MALFUNCTIONI the following. ness connectors F4, EC4 ness for open or short betwee	GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or s		s or connectors.	
6 Check • Harr • Harr	DETECT MALFUNCTIONI the following. ness connectors F4, EC4 ness for open or short betwee	GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or sh		s or connectors.	
6 Check • Harr • Harr	DETECT MALFUNCTIONI the following. ness connectors F4, EC4 ness for open or short betwee	GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or some some some some some some some some		s or connectors.	
6 Check • Harr • Harr 7	DETECT MALFUNCTIONI the following. ness connectors F4, EC4 ness for open or short betwee  CHECK INTERMITTENT II to "TROUBLE DIAGNOSIS FO	GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or some some some short to ground or some short	short to power in harnes	s or connectors.	
6 Check • Harr • Harr 7 Refer	DETECT MALFUNCTIONI  the following. ness connectors F4, EC4 ness for open or short betwee  CHECK INTERMITTENT II  to "TROUBLE DIAGNOSIS FO	GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or some some services of the services o	short to power in harnes		
6 Check • Harr • Harr 7 Refer	DETECT MALFUNCTIONI the following. ness connectors F4, EC4 ness for open or short betwee  CHECK INTERMITTENT II to "TROUBLE DIAGNOSIS FO	GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or some some some short to ground or some short	short to power in harnes		
6 Check • Harr • Harr 7 Refer	DETECT MALFUNCTIONI  the following. ness connectors F4, EC4 ness for open or short betwee  CHECK INTERMITTENT II  to "TROUBLE DIAGNOSIS FO	GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or some some services of the services o	short to power in harnes		
6 Check • Harr • Harr 7 Refer	DETECT MALFUNCTIONI  the following. ness connectors F4, EC4 ness for open or short betwee  CHECK INTERMITTENT II  to "TROUBLE DIAGNOSIS FO	GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or some some services of the services o	short to power in harnes		
6 Check • Harr • Harr 7 Refer	DETECT MALFUNCTIONI  the following. ness connectors F4, EC4 ness for open or short betwee  CHECK INTERMITTENT II  to "TROUBLE DIAGNOSIS FO	GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or some some services of the services o	short to power in harnes		
<ul><li>Harr</li><li>Harr</li></ul>	DETECT MALFUNCTIONI  the following. ness connectors F4, EC4 ness for open or short betwee  CHECK INTERMITTENT II  to "TROUBLE DIAGNOSIS FO	GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or some some services of the services o	short to power in harnes		
6 Check • Harr • Harr 7 Refer	DETECT MALFUNCTIONI  the following. ness connectors F4, EC4 ness for open or short betwee  CHECK INTERMITTENT II  to "TROUBLE DIAGNOSIS FO	GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or some some services of the services o	short to power in harnes		
6 Check • Harr • Harr 7 Refer	DETECT MALFUNCTIONI  the following. ness connectors F4, EC4 ness for open or short betwee  CHECK INTERMITTENT II  to "TROUBLE DIAGNOSIS FO	GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or some some services of the services o	short to power in harnes		
6 Check • Harr • Harr 7 Refer	DETECT MALFUNCTIONI  the following. ness connectors F4, EC4 ness for open or short betwee  CHECK INTERMITTENT II  to "TROUBLE DIAGNOSIS FO	GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or some some services of the services o	short to power in harnes		

EL

SE



#### **Description**

#### SYSTEM DESCRIPTION

The ECM and the electronic control fuel injection pump control unit (abbreviated as the injection pump control unit) perform the real time communication (signal exchange).

The ECM transmits the signals of the target fuel injection amount, target fuel injection timing, and engine speed, etc., and receives the signals of the pump speed and fuel temperature, etc. from the injection pump control unit.

By those signals, the injection pump controls the optimum fuel injection amount and injection timing of the spill valve and timing control valve.

Injection pump control unit has an on board diagnostic system, which detects malfunctions related to sensors or actuators built-into electronic control fuel injection pump. These malfunction information are transferred through the line (circuit) from injection pump control unit to ECM.

#### **FUEL INJECTION AMOUNT CONTROL**

In accordance with the target fuel injection amount signal from the ECM, the injection amount is controlled by controlling the spill valve in the injection pump and by changing the needle opening time.

#### **FUEL INJECTION TIMING CONTROL**

Based on the target fuel injection timing signal from the ECM, the injection timing is controlled in accordance with the timer spring by performing the duty control of the timing control valve in the injection pump and by adjusting the pressure of the timer piston high pressure chamber.

#### **FUEL TEMPERATURE SENSOR**

The sensor detects the fuel temperature in the injection pump and calibrates the injection amount change by the fuel temperature.

#### **CAM RING POSITION SENSOR**

The sensor detects the passing of the protrusion on the sensor wheel in the injection pump by the semiconductor magnetic resistance element sensor. The cam ring position sensor synchronizes with the cam ring, and detects the actual advance amount. The injection pump control unit measures the injection pump revolution by the signal of the cam ring position sensor.

#### **CONSULT-II Reference Value in Data Monitor** Mode

GI

Remarks: Specification data are reference values.

D. /.	1 /\(\lambda\)
- INVA	I /Δ\
111/71	$I/ \cap I$

EM

LC

MONITOR ITEM	CONDITION		SPECIFICATION
FUEL TEMP SEN	Engine: After warming up		More than 40°C (104°F)
SPILL/V	Engine: After warming up		Approx. 13°CA
INJ TIMG C/V	Engine: After warming up, idle the engine.		Approx. 50 - 70%
DECELER F/CUT	Engine: After warming up  Idle		OFF
BARO SEN	I die		Altitude Approx. 0 m (0 ft): Approx. 100.62 kPa (1.0062 bar, 1.026 kg/cm², 14.59 psi) Approx. 1,000 m (3,281 ft): Approx. 88.95 kPa (0.8895 bar, 0.907 kg/cm², 12.90 psi) Approx. 1,500 m (4,992 ft): Approx. 83.16 kPa (0.8316 bar, 0.848 kg/cm², 12.06 psi) Approx. 2,000 m (6,562 ft): Approx. 78.36 kPa (0.7836 bar, 0.799 kg/cm², 11.36 psi)

EC

FE

GL

## **ECM Terminals and Reference Value**

AT

MT

Specification data are reference values and are measured between each terminal and ground.

TF

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

PD


TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	FA
33	G/Y	Electronic control fuel injection pump	Engine is running.  Warm-up condition Idle speed	Approximately 2.5V	RA
40	R/B	Electronic control fuel injection pump	Engine is running.  Warm-up condition Idle speed	Approximately 2.5V	BR ST
52	L/B	Electronic control fuel injection pump	Engine is running.  Idle speed	Approximately 0.1V	RS
53	L/R	Electronic control fuel injection pump	Engine is running.  Idle speed	Approximately 0.35V	BT

### On Board Diagnosis Logic

HA

EL

Malfunction is detected when	Check Items (Possible cause)
<ul> <li>Injection pump control unit receives incorrect voltage signal from ECM continuously.</li> </ul>	<ul> <li>Harness or connectors         (Electronic control fuel injection pump circuit is open or shorted.)</li> <li>Electronic control fuel injection pump</li> </ul>




#### **DTC Confirmation Procedure**



- 1) Turn ignition switch "ON" and wait at least 2 seconds.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and run it for at least 2 seconds at idle speed. (If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-200.

### WITHOUT CONSULT-II


- 1) Turn ignition switch "ON" and wait at least 2 seconds.
- 2) Start engine and run it for at least 2 seconds at idle speed. (If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
- 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with FCM
- 5) If DTC is detected, go to "Diagnostic Procedure", EC-200.



### **Diagnostic Procedure**


#### 1 CHECK ELECTRONIC CONTROL FUEL INJECTION PUMP POWER SUPPLY CIRCUIT

- 1. Turn ignition switch "OFF".
- 2. Disconnect electronic control fuel injection pump harness connector.



SEF229Z

- 3. Turn ignition switch "ON".
- 4. Check voltage between electronic control fuel injection pump terminal 7 and ground.



SEF438Y

OK	<b>&gt;</b>	GO TO 3.
NG	<b>•</b>	GO TO 2.

#### 2 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M50, F5
- Harness connectors F4, EC4
- Harness for open or short between electronic control fuel injection pump and ECM
- Harness for open or short between electronic control fuel injection pump and ECM relay
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

#### 3 CHECK ELECTRONIC CONTROL FUEL INJECTION PUMP GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch "OFF".
- 2. Check harness continuity between electronic control fuel injection pump terminal 6 and ground. Refer to Wiring Diagram. **Continuity should exist.**
- 3. Also check harness for short to ground and short to power.

OK	or	NG

OK or NG


OK ▶	GO TO 5.
NG •	GO TO 4.

EL

SE

# DTC 0703 P3 PUMP COMM LINE

_					
4	DETECT MALFUNCTION	NG PART			]
<ul><li>Harn</li></ul>	the following. ness connectors F4, EC4 ness for open or short betwee	n electronic control fuel injection pump and	engine ground		
	<b>&gt;</b>	Repair open circuit or short to ground or s	hort to power in	harness or connectors.	
5	CHECK COMMUNICATIO	N LINE FOR OPEN AND SHORT			7
1. Che	eck continuity between the foll	owing terminals. Refer to Wiring Diagram.			1
		Electronic control fuel injection pump	ECM 33		
		2	40		
		<u>5</u> 8	52 53		
				MTBL0444	
	Continuity should exist.  o check harness for short to g	round and short to power			
	DUIDUN HAITIESS IUI SHUIL (O Q	IOGINA AND SHOULID DOWEL			1
Z. AISO	, and the second				
		OK or NG			$\frac{1}{2}$
OK	<b>•</b>	OK or NG			-
		OK or NG			
OK NG	<b>&gt;</b>	OK or NG GO TO 7. GO TO 6.			]
OK NG 6	DETECT MALFUNCTION	OK or NG GO TO 7. GO TO 6.			
OK NG 6 Check Harn	DETECT MALFUNCTION  the following. ness connectors F4, EC4	OK or NG GO TO 7. GO TO 6.  NG PART			
OK NG 6 Check Harn	DETECT MALFUNCTIONI the following. ness connectors F4, EC4 ness for open or short between	OK or NG GO TO 7. GO TO 6.  NG PART  n electronic control fuel injection pump and			
OK NG 6 Check Harn	DETECT MALFUNCTION  the following. ness connectors F4, EC4	OK or NG GO TO 7. GO TO 6.  NG PART		harness or connectors.	
OK NG 6 Check • Harn • Harn	DETECT MALFUNCTIONI the following. ness connectors F4, EC4 ness for open or short betwee	OK or NG GO TO 7. GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or s		harness or connectors.	
OK NG 6 Check Harn Harn	DETECT MALFUNCTION  the following. ness connectors F4, EC4 ness for open or short betwee	OK or NG GO TO 7. GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or s		harness or connectors.	
OK NG 6 Check Harn Harn	DETECT MALFUNCTION  the following. ness connectors F4, EC4 ness for open or short betwee	OK or NG GO TO 7. GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or so NCIDENT  DR INTERMITTENT INCIDENT", EC-107.		harness or connectors.	
OK NG 6 Check Harn Harn 7	DETECT MALFUNCTIONI the following. ness connectors F4, EC4 ness for open or short betwee  CHECK INTERMITTENT I	OK or NG GO TO 7. GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or so NCIDENT  OR INTERMITTENT INCIDENT", EC-107.  OK or NG	hort to power in	harness or connectors.	
OK NG 6 Check Harn Harn	DETECT MALFUNCTION  the following. ness connectors F4, EC4 ness for open or short betwee	OK or NG GO TO 7. GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or so NCIDENT  DR INTERMITTENT INCIDENT", EC-107.	hort to power in		



#### **Description**

#### SYSTEM DESCRIPTION

The ECM and the electronic control fuel injection pump control unit (abbreviated as the injection pump control unit) perform the real time communication (signal exchange).

The ECM transmits the signals of the target fuel injection amount, target fuel injection timing, and engine speed, etc., and receives the signals of the pump speed and fuel temperature, etc. from the injection pump control unit.

By those signals, the injection pump controls the optimum fuel injection amount and injection timing of the spill valve and timing control valve.

Injection pump control unit has an on board diagnostic system, which detects malfunctions related to sensors or actuators built-into electronic control fuel injection pump. These malfunction information are transferred through the line (circuit) from injection pump control unit to ECM.

#### **FUEL INJECTION AMOUNT CONTROL**

In accordance with the target fuel injection amount signal from the ECM, the injection amount is controlled by controlling the spill valve in the injection pump and by changing the needle opening time.

#### **FUEL INJECTION TIMING CONTROL**

Based on the target fuel injection timing signal from the ECM, the injection timing is controlled in accordance with the timer spring by performing the duty control of the timing control valve in the injection pump and by adjusting the pressure of the timer piston high pressure chamber.

#### **FUEL TEMPERATURE SENSOR**

The sensor detects the fuel temperature in the injection pump and calibrates the injection amount change by the fuel temperature.

#### **CAM RING POSITION SENSOR**

The sensor detects the passing of the protrusion on the sensor wheel in the injection pump by the semiconductor magnetic resistance element sensor. The cam ring position sensor synchronizes with the cam ring, and detects the actual advance amount. The injection pump control unit measures the injection pump revolution by the signal of the cam ring position sensor.

GI

MA

EM

LC

EC

FE

GL

MT

AT

TF

#### **CONSULT-II Reference Value in Data Monitor** Mode

Remarks: Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
FUEL TEMP SEN	Engine: After warming	g up	More than 40°C (104°F)
SPILL/V	Engine: After warming up		Approx. 13°CA
INJ TIMG C/V	Engine: After warming up, idle the engine.		Approx. 50 - 70%
DECELER F/CUT	Engine: After warming up	Idle	OFF
BARO SEN	• Ignition switch: ON		Altitude Approx. 0 m (0 ft): Approx. 100.62 kPa (1.0062 bar, 1.026 kg/cm², 14.59 psi) Approx. 1,000 m (3,281 ft): Approx. 88.95 kPa (0.8895 bar, 0.907 kg/cm², 12.90 psi) Approx. 1,500 m (4,992 ft): Approx. 83.16 kPa (0.8316 bar, 0.848 kg/cm², 12.06 psi) Approx. 2,000 m (6,562 ft): Approx. 78.36 kPa (0.7836 bar, 0.799 kg/cm², 11.36 psi)

#### **ECM Terminals and Reference Value**

Specification data are reference values and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


ECM's transistor. Use a ground other than ECM terminals, such as the ground.					
TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	FA
33	G/Y	Electronic control fuel injection pump	Engine is running.  Warm-up condition Idle speed	Approximately 2.5V	RA
40	R/B	Electronic control fuel injection pump	Engine is running.  Warm-up condition Idle speed	Approximately 2.5V	BR ST
52	L/B	Electronic control fuel injection pump	Engine is running.  Idle speed	Approximately 0.1V	RS
53	L/R	Electronic control fuel injection pump	Engine is running.  Idle speed	Approximately 0.35V	BT

### On Board Diagnosis Logic

Malfunction is detected when	Check Items (Possible cause)
Spill valve (Built-into electronic control fuel injection pump) does not function properly.	<ul> <li>Harness or connectors (Electronic control fuel injection pump circuit is open or shorted.)</li> <li>Electronic control fuel injection pump</li> </ul>

HA

EL




#### **DTC Confirmation Procedure**

## WITH CONSULT-II

- 1) Turn ignition switch "ON" and wait at least 2 seconds.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and run it for at least 2 seconds at idle speed. (If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-206.

### WITHOUT CONSULT-II


- Turn ignition switch "ON" and wait at least 2 seconds.
- 2) Start engine and run it for at least 2 seconds at idle speed. (If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
- 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with
- 5) If DTC is detected, go to "Diagnostic Procedure", EC-206.



### **Diagnostic Procedure**


#### CHECK ELECTRONIC CONTROL FUEL INJECTION PUMP POWER SUPPLY CIRCUIT

- 1. Turn ignition switch "OFF".
- 2. Disconnect electronic control fuel injection pump harness connector.



SEF229Z

- 3. Turn ignition switch "ON".
- 4. Check voltage between electronic control fuel injection pump terminal 7 and ground.



SEF438Y

OK	<b>&gt;</b>	GO TO 3.
NG	<b>•</b>	GO TO 2.

#### **DETECT MALFUNCTIONING PART**

Check the following.

- Harness connectors M50, F5
- Harness connectors F4, EC4
- Harness for open or short between electronic control fuel injection pump and ECM
- Harness for open or short between electronic control fuel injection pump and ECM relay
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

#### CHECK ELECTRONIC CONTROL FUEL INJECTION PUMP GROUND CIRCUIT FOR OPEN AND SHORT 3

- 1. Turn ignition switch "OFF".
- 2. Check harness continuity between electronic control fuel injection pump terminal 6 and ground. Refer to Wiring Diagram. Continuity should exist.
- 3. Also check harness for short to ground and short to power.

OK or NG

OK or NG


OK ▶	GO TO 5.
NG •	GO TO 4.

## DTC 0704 P4-SPILL/V CIRC, DTC 0706 P6-SPILL VALVE ZD30DDTi

HA

### **Diagnostic Procedure (Cont'd)**

#### GI **DETECT MALFUNCTIONING PART** Check the following. • Harness connectors F4, EC4 MA • Harness for open or short between electronic control fuel injection pump and engine ground Repair open circuit or short to ground or short to power in harness or connectors. EM CHECK COMMUNICATION LINE FOR OPEN AND SHORT LC 1. Check continuity between the following terminals. Refer to Wiring Diagram. Electronic control fuel injection pump **ECM** 33 2 40 5 8 53 MTBL0444 Continuity should exist. 2. Also check harness for short to ground and short to power. MI OK or NG OK GO TO 7. AT NG GO TO 6. TF 6 **DETECT MALFUNCTIONING PART** Check the following. • Harness connectors F4, EC4 PD • Harness for open or short between electronic control fuel injection pump and ECM ▶ Repair open circuit or short to ground or short to power in harness or connectors. FA **CHECK INTERMITTENT INCIDENT** Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107. RA OK or NG OK Replace electronic control fuel injection pump. $\blacktriangleright$ BR NG Repair open circuit or short to ground or short to power in harness or connectors. ST BT



#### **Description**

#### SYSTEM DESCRIPTION

The ECM and the electronic control fuel injection pump control unit (abbreviated as the injection pump control unit) perform the real time communication (signal exchange).

The ECM transmits the signals of the target fuel injection amount, target fuel injection timing, and engine speed, etc., and receives the signals of the pump speed and fuel temperature, etc. from the injection pump control unit.

By those signals, the injection pump controls the optimum fuel injection amount and injection timing of the spill valve and timing control valve.

Injection pump control unit has an on board diagnostic system, which detects malfunctions related to sensors or actuators built-into electronic control fuel injection pump. These malfunction information are transferred through the line (circuit) from injection pump control unit to ECM.

#### **FUEL INJECTION AMOUNT CONTROL**

In accordance with the target fuel injection amount signal from the ECM, the injection amount is controlled by controlling the spill valve in the injection pump and by changing the needle opening time.

#### **FUEL INJECTION TIMING CONTROL**

Based on the target fuel injection timing signal from the ECM, the injection timing is controlled in accordance with the timer spring by performing the duty control of the timing control valve in the injection pump and by adjusting the pressure of the timer piston high pressure chamber.

#### **FUEL TEMPERATURE SENSOR**

The sensor detects the fuel temperature in the injection pump and calibrates the injection amount change by the fuel temperature.

#### **CAM RING POSITION SENSOR**

The sensor detects the passing of the protrusion on the sensor wheel in the injection pump by the semiconductor magnetic resistance element sensor. The cam ring position sensor synchronizes with the cam ring, and detects the actual advance amount. The injection pump control unit measures the injection pump revolution by the signal of the cam ring position sensor.

#### **CONSULT-II Reference Value in Data Monitor** Mode

GI

Remarks: Specification data are reference values.

$\Box \wedge \Box$	1 🗥
INVA	Ι/Δ\
111/7	//\n\

EM

LC

MONITOR ITEM	CONDITION		SPECIFICATION
FUEL TEMP SEN	Engine: After warming	g up	More than 40°C (104°F)
SPILL/V	Engine: After warming	g up	Approx. 13°CA
INJ TIMG C/V	Engine: After warming up, idle the engine.		Approx. 50 - 70%
DECELER F/CUT	Engine: After warming up	Idle	OFF
BARO SEN	• Ignition switch: ON		Altitude Approx. 0 m (0 ft): Approx. 100.62 kPa (1.0062 bar, 1.026 kg/cm², 14.59 psi) Approx. 1,000 m (3,281 ft): Approx. 88.95 kPa (0.8895 bar, 0.907 kg/cm², 12.90 psi) Approx. 1,500 m (4,992 ft): Approx. 83.16 kPa (0.8316 bar, 0.848 kg/cm², 12.06 psi) Approx. 2,000 m (6,562 ft): Approx. 78.36 kPa (0.7836 bar, 0.799 kg/cm², 11.36 psi)

EC

FE

GL

## **ECM Terminals and Reference Value**

AT

MT

Specification data are reference values and are measured between each terminal and ground.

TF

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

PD


TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	FA
33	G/Y	Electronic control fuel injection pump	Engine is running.  Warm-up condition Idle speed	Approximately 2.5V	RA
40	R/B	Electronic control fuel injection pump	Engine is running.  Warm-up condition Idle speed	Approximately 2.5V	BR ST
52	L/B	Electronic control fuel injection pump	Engine is running.  Idle speed	Approximately 0.1V	RS
53	L/R	Electronic control fuel injection pump	Engine is running.  Idle speed	Approximately 0.35V	BT

### On Board Diagnosis Logic

HA

EL

Malfunction is detected when	Check Items (Possible cause)		
• Injection pump control unit does not function properly.	Electronic control fuel injection pump		



#### **DTC Confirmation Procedure**

## WITH CONSULT-II


- 1) Turn ignition switch "ON" and wait at least 2 seconds.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and run it for at least 2 seconds at idle speed. (If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-210.



- 1) Turn ignition switch "ON" and wait at least 2 seconds.
- 2) Start engine and run it for at least 2 seconds at idle speed. (If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
- 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with FCM
- 5) If DTC is detected, go to "Diagnostic Procedure", EC-210.

### **Diagnostic Procedure**

1	INSPECTION START				
1	ignition switch "ON". :t "SELF DIAG RESULTS" m	node with CONSULT-II.			
	ı "ERASE".				
1	rm "DTC Confirmation Proce malfunction displayed again				
<u> </u>	. , ,	I:			
	Without CONSULT-II 1. Turn ignition switch "ON".				
2. Erase	the Diagnostic Test Mode I	I (Self-diagnostic results) memory.			
1	<ol> <li>Perform "DTC Confirmation Procedure", EC-210, again.</li> <li>Perform "Diagnostic Test Mode II (Self-diagnostic results)".</li> </ol>				
1	5. Is the DTC 0705 displayed again?				
Yes or No					
Yes	Yes ▶ Replace electronic control fuel injection pump.				
No	<b>&gt;</b>	INSPECTION END			



#### **Description**

#### SYSTEM DESCRIPTION

The ECM and the electronic control fuel injection pump control unit (abbreviated as the injection pump control unit) perform the real time communication (signal exchange).

The ECM transmits the signals of the target fuel injection amount, target fuel injection timing, and engine speed, etc., and receives the signals of the pump speed and fuel temperature, etc. from the injection pump control unit.

By those signals, the injection pump controls the optimum fuel injection amount and injection timing of the spill valve and timing control valve.

Injection pump control unit has an on board diagnostic system, which detects malfunctions related to sensors or actuators built-into electronic control fuel injection pump. These malfunction information are transferred through the line (circuit) from injection pump control unit to ECM.

#### **FUEL INJECTION AMOUNT CONTROL**

In accordance with the target fuel injection amount signal from the ECM, the injection amount is controlled by controlling the spill valve in the injection pump and by changing the needle opening time.

#### **FUEL INJECTION TIMING CONTROL**

Based on the target fuel injection timing signal from the ECM, the injection timing is controlled in accordance with the timer spring by performing the duty control of the timing control valve in the injection pump and by adjusting the pressure of the timer piston high pressure chamber.

#### **FUEL TEMPERATURE SENSOR**

The sensor detects the fuel temperature in the injection pump and calibrates the injection amount change by the fuel temperature.

#### **CAM RING POSITION SENSOR**

The sensor detects the passing of the protrusion on the sensor wheel in the injection pump by the semiconductor magnetic resistance element sensor. The cam ring position sensor synchronizes with the cam ring, and detects the actual advance amount. The injection pump control unit measures the injection pump revolution by the signal of the cam ring position sensor.



---

MA

EM

LG

EC

PP

GL

MT

AT

TF

שום

FA

RA

BR

ST

18

BT

HA

EL

SE

 $\mathbb{D}\mathbb{X}$ 

# **CONSULT-II Reference Value in Data Monitor Mode**

Remarks: Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION	
FUEL TEMP SEN	Engine: After warmin	g up	More than 40°C (104°F)	
SPILL/V	PILL/V • Engine: After warming up		Approx. 13°CA	
INJ TIMG C/V  • Engine: After warming up, idle the engine.		g up,	Approx. 50 - 70%	
DECELER F/CUT	• Engine: After warming up		OFF	
BARO SEN			Altitude Approx. 0 m (0 ft): Approx. 100.62 kPa (1.0062 bar, 1.026 kg/cm², 14.59 psi) Approx. 1,000 m (3,281 ft): Approx. 88.95 kPa (0.8895 bar, 0.907 kg/cm², 12.90 psi) Approx. 1,500 m (4,992 ft): Approx. 83.16 kPa (0.8316 bar, 0.848 kg/cm², 12.06 psi) Approx. 2,000 m (6,562 ft): Approx. 78.36 kPa (0.7836 bar, 0.799 kg/cm², 11.36 psi)	

#### **ECM Terminals and Reference Value**

Specification data are reference values and are measured between each terminal and ground.

#### **CAUTION:**


Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

			· 3	
TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
33	G/Y	Electronic control fuel injection pump	Engine is running.  Warm-up condition Idle speed	Approximately 2.5V
40	R/B	Electronic control fuel injection pump	Engine is running.  Warm-up condition Idle speed	Approximately 2.5V
52	L/B	Electronic control fuel injection pump	Engine is running.  Idle speed	Approximately 0.1V
53	L/R	Electronic control fuel injection pump	Engine is running.  Idle speed	Approximately 0.35V

### On Board Diagnosis Logic

Malfunction is detected when	Check Items (Possible cause)	
Fuel injection timing control system does not function properly.	Harness or connectors     (Electronic control fuel injection pump circuit is open or shorted.)     Electronic control fuel injection pump     Improper fuel quality     "INJ TIMING" in "ACTIVE TEST" mode with CONSULT-II.*	

<sup>\*:</sup> When using this item, DTC may be detected. If so, erase it because it is not a malfunction.



#### **DTC Confirmation Procedure**

WITH CONSULT-II

1) Turn ignition switch "ON" and wait at least 2 seconds.

2) Select "DATA MONITOR" mode with CONSULT-II.

3) Start engine and run it for at least 2 seconds at idle speed. (If engine does not run, turn ignition switch to "START" for at least 2 seconds.)

4) Keep engine speed at more than 2,000 rpm for at least 10 seconds.

If DTC is detected, go to "Diagnostic Procedure", EC-215.

### WITHOUT CONSULT-II

Turn ignition switch "ON" and wait at least 2 seconds. 1)

Start engine and run it for at least 2 seconds at idle speed. (If engine does not run, turn ignition switch to "START" for at least 2 seconds.)

3) Keep engine speed at more than 2,000 rpm for at least 10 seconds.

Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".

5) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with

6) If DTC is detected, go to "Diagnostic Procedure", EC-215.

GI

MA

EM

LC

EC

FE

MT

AT

TF

PD

FA

RA

BR

ST


BT

HA

EL

SE

### **Wiring Diagram**



GI


LC

FE

### **Diagnostic Procedure**

1 INSPECTI	ION START		MA	
Turn ignition switch "OFF".     Perform "Air Bleeding", EC-62, and "DRAINING WATER" in MA section.				
▶ GO TO 2.				

2	PERFORM DTC CONFIRM	MATION PROCEDURE AGAIN	
Perform "DTC Confirmation Procedure", EC-213 again.			
OK or NG			
OK • INSPECTION END			
NG	<b>•</b>	GO TO 3.	



36

SE

#### DTC 0707 P7-F/INJ TIMG FB

### **Diagnostic Procedure (Cont'd)**

#### 4 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M50, F5
- Harness connectors F4, EC4
- Harness for open or short between electronic control fuel injection pump and ECM
- Harness for open or short between electronic control fuel injection pump and ECM relay
  - Repair open circuit or short to ground or short to power in harness or connectors.

#### 5 CHECK ELECTRONIC CONTROL FUEL INJECTION PUMP GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch "OFF".
- 2. Check harness continuity between electronic control fuel injection pump terminal 6 and ground. Refer to Wiring Diagram. **Continuity should exist.**
- 3. Also check harness for short to ground and short to power.

#### OK or NG

ОК	•	GO TO 7.
NG	•	GO TO 6.

#### 6 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F4, EC4
- Harness for open or short between electronic control fuel injection pump and engine ground
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

#### 7 CHECK COMMUNICATION LINE FOR OPEN AND SHORT

1. Check continuity between the following terminals. Refer to Wiring Diagram.

Electronic control fuel injection pump	ECM
1	33
2	40
5	52
8	53

MTBL0444

#### Continuity should exist.

2. Also check harness for short to ground and short to power.

#### OK or NG

ОК	<b>&gt;</b>	GO TO 9.
NG	<b>&gt;</b>	GO TO 8.

#### 8 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F4, EC4
- Harness for open or short between electronic control fuel injection pump and ECM
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

# ZD30DDTi

# DTC 0707 P7 F/INJ TIMG FB

# Diagnostic Procedure (Cont'd)

9 CHECK INTERMITTENT INCIDENT			
Refer to	Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.		
OK or NG			
ОК	<b>&gt;</b>	Replace electronic control fuel injection pump.	
NG	<b>&gt;</b>	Repair open circuit or short to ground or short to power in harness or connectors.	

G[

MA

EM

LC

EC

FE

GL

MT

AT

TF

PD

FA

RA

BR

ST


RS

BT

HA

EL

SE




# **Description**

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The unit controls the engine.

# On Board Diagnosis Logic

Malfunction is detected when	Check Items (Possible Cause)
<ul> <li>An excessively high or low voltage from the absolute pressure sensor (built-into ECM) is sent to ECM.</li> </ul>	ECM     (ECCS-D control module)



### **DTC Confirmation Procedure**



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and wait at least 2 seconds.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-219.

# WITHOUT CONSULT-II

- 1) Turn ignition switch "ON" and wait at least 2 seconds.
- 2) Start engine and wait at least 2 seconds.
- 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON"
- 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with
- 5) If DTC is detected, go to "Diagnostic Procedure", EC-219.

G[

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA


EL

SE

# **Diagnostic Procedure**

1	INSPECTION START		] MA
	With CONSULT-II		
1. Turn ignition switch "ON". 2. Select "SELF DIAG RESULTS" mode with CONSULT-II. 3. Touch "ERASE".			EM
1	rm "DTC Confirmation Proce malfunction displayed again		LC
	Without CONSULT-II		
<ol> <li>Turn ignition switch "ON".</li> <li>Erase the Diagnostic Test Mode II (Self-diagnostic results) memory.</li> <li>Perform "DTC Confirmation Procedure", EC-218, again.</li> </ol>			EC
1	4. Perform "Diagnostic Test Mode II (Self-diagnostic results)".  5. Is the DTC 0802 displayed again?		
	Yes or No		
Yes	Yes		
No			
			MT

IDX




### **Description**

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The unit controls the engine.

# On Board Diagnosis Logic

Malfunction is detected when	Check Items (Possible Cause)
• ECM input signal processing function is malfunctioning.	ECM     (ECCS-D control module)



### **DTC Confirmation Procedure**



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 1 second.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-221.



- 1) Turn ignition switch "ON" and wait at least 1 second.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-221.

G[

# **Diagnostic Procedure**

1 INSP	ECTION START		Ma
(I) With COI	(F) With CONSULT-II		
1. Turn ignition		1 × 1 00 10 1 1 7 1	
2. Select "SEL 3. Touch "ERA	_F DIAG RESULTS" m \SE"	ode with CONSULI-II.	EN
	TC Confirmation Proce	dure", EC-220, again.	
	ınction displayed agai		
Without (	Without CONSULT-II		
	1. Turn ignition switch "ON".		
	2. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory.  3. Perform "DTC Confirmation Procedure", EC-220, again.		
		(Self-diagnostic results)".	
5. Is the DTC	5. Is the DTC 0802 displayed again?		
		Yes or No	
Yes	Yes ▶ Replace ECM.		
No			
			M

BR

AT

TF

PD

FA

RA

BT

RS


ST

. . . .

HA

EL

SE



# **Description**

The stop lamp switch is installed to brake pedal bracket. The switch senses brake pedal position and sends an ON-OFF signal to the ECM. The ECM uses the signal to control the fuel injection control system.

### **ECM Terminals and Reference Value**

Specification data are reference values and are measured between each terminal and ground.


#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
17	G/Y	Stop Jomp quitab	Ignition switch "ON"  Brake pedal fully released	Approximately 0V
17	G/1	Stop lamp switch	Ignition switch "ON"  Brake pedal depressed	BATTERY VOLTAGE (11 - 14V)

# On Board Diagnosis Logic

Malfunction is detected when	Check Items (Possible Cause)
• An irregular voltage signal from the switch is sent to ECM.	<ul> <li>Harness or connectors (The stop lamp switch circuit is open or shorted.)</li> <li>Stop lamp switch</li> </ul>



### **DTC Confirmation Procedure**




### WITH CONSULT-II

- 1) Turn ignition switch "ON".
- Select "DATA MONITOR" mode with CONSULT-II.
- Depress and release brake pedal more than 10 times.
- If DTC is detected, go to "Diagnostic Procedure", EC-224.

### WITHOUT CONSULT-II

- 1) Turn ignition switch "ON".
- Depress and release brake pedal more than 10 times.
- Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- Perform "Diagnostic Test Mode II (Self-diagnostic results)" with
- 5) If DTC is detected, go to "Diagnostic Procedure", EC-224.



# **Diagnostic Procedure**

### 1 CHECK STOP LAMP SWITCH CIRCUIT

- 1. Turn ignition switch "ON".
- 2. Check the stop lamp when depressing and releasing the stop lamp switch.

Stop lamp switch	Stop lamp
Fully released	Not illuminated
Depressed	Illuminated


MTBL0443

### OK or NG

OK ▶	GO TO 4.
NG •	GO TO 2.

### 2 CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT


- 1. Turn ignition switch "OFF".
- 2. Disconnect stop lamp switch harness connector.



SEF275Z

- 3. Turn ignition switch "ON".
- 4. Check voltage between stop lamp switch terminal 1 and ground with CONSULT-II or tester.





Voltage: Battery voltage

SEF435Y

OK or NG

OK ▶	GO TO 4.
NG ▶	GO TO 3.

### DETECT MALFUNCTIONING PART


Check the following.

- Fuse block (J/B) connector M3
- 10A fuse
- Harness for open and short between stop lamp switch and fuse

▶ Repair open circuit or short to ground or short to power in harness or connectors.

### CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch "OFF".
- 2. Disconnect ECM harness connector.
- 3. Disconnect stop lamp switch harness connector.



SEF275Z

- 4. Check harness continuity between ECM terminal 17 and stop lamp switch terminal 2. Refer to Wiring Diagram. Continuity should exist.
- 5. Also check harness for short to ground and short to power.

#### OK or NG

ОК	<b>&gt;</b>	GO TO 6.
NG	<b>•</b>	GO TO 5.

#### 5 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M52, F7
- Harness for open or short between ECM and stop lamp switch
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

الالاك

GI

MA

LC

FE

GL

MT

AT

TF

PD

FA

<u>ا</u> ۵

RA

BR

ST


29

BT

HA

EL

SE



7	CHECK INTERMITTENT INCIDENT		
Refer to	"TROUBLE DIAGNOSIS FO	TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.	
	► INSPECTION END		

GI

MA

### **ECM Terminals and Reference Value**

Specification data are reference values and are measured between each terminal and ground.


#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	LC LC
4	B/Y	ECM relay (Self-shutoff)	Ignition switch "ON"  Ignition switch "OFF"  For a few seconds after turning ignition switch "OFF"	Approximately 0.25V	EC
			Ignition switch "OFF"  A few seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)	CL
			Ignition switch "OFF"	0V	MT
38	B/Y	Ignition switch	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)	AT
56 61 116	W W W	Power supply for ECM	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)	TF

# On Board Diagnosis Logic

Malfunction is detected when	Check Items (Possible Cause)	FA
• An irregular voltage signal from the ECM relay is sent to ECM.	Harness or connectors     (ECM relay circuit is open or shorted.)     ECM relay	RA



### **DTC Confirmation Procedure**

( WITH CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- Turn ignition switch "OFF", wait at least 20 seconds and then turn "ON".
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-229.

# WITHOUT CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Turn ignition switch "OFF", wait at least 20 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with FCM
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-229.

SE

EL

PD


BR


ST

BT

HA


# **Wiring Diagram**





GI

# **Diagnostic Procedure**



### DTC 0902 ECM RLY

# **Diagnostic Procedure (Cont'd)**

### 4 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M50, F5
- Harness for open or short between ECM and ECM relay

▶ Repair open circuit or short to ground or short to power in harness or connectors.

### 5 CHECK ECM OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- Check harness continuity between ECM terminal 4 and ECM relay terminal 2. Refer to Wiring Diagram.
   Continuity should exist.
- 2. Also check harness for short to ground and short to power.

#### OK or NG

ОК	•	GO TO 7.
NG	•	GO TO 6.


### 6 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M52, F7
- Harness for open or short between ECM and ECM relay
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

### 7 CHECK ECM RELAY

- 1. Apply 12V direct current between ECM relay terminals 1 and 2.
- 2. Check continuity between ECM relay terminals 3 and 5, 6 and 7.



Condition	Continuity	
12V direct current supply between terminals 1 and 2	Yes	
OFF	No	

SEF296X


#### OK or NG

OK I	▶	GO TO 8.
NG	•	Replace ECM relay.

### 8 CHECK INTERMITTENT INCIDENT

Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.

**▶** INSPECTION END



# **Description**

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The unit controls the engine.

GI MA


EM

LC

EC

# On Board Diagnosis Logic

Malfunction is detected when	Check Items (Possible Cause)	FE
• ECM input signal processing function is malfunctioning.	ECM     (ECCS-D control module)	CL



### **DTC Confirmation Procedure**



TF

PD

FA

RA

BR

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Turn ignition switch "OFF", wait at least 20 seconds and then turn "ON".
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-232.
- WITHOUT CONSULT-II
- 1) Turn ignition switch "ON" and wait at least 2 seconds.
- Turn ignition switch "OFF", wait at least 20 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-232.

MT

AT

ST

1 110

BT


HA


EL

SE

# **Diagnostic Procedure**

1	INSPECTION START			
Witl	(F) With CONSULT-II			
1. Turn i	ignition switch "ON".			
2. Selec	t "SELF DIAG RESULTS" m	ode with CONSULT-II.		
3. Touch	ı "ERASE".			
4. Perfo	rm "DTC Confirmation Proce	edure", EC-231, again.		
5. Is the	5. Is the malfunction displayed again?			
Without CONSULT-II				
1. Turn ignition switch "ON".				
2. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory.				
3. Perfor	3. Perform "DTC Confirmation Procedure", EC-231, again.			
4. Perfor	4. Perform "Diagnostic Test Mode II (Self-diagnostic results)".			
5. Is the	5. Is the DTC 0903 displayed again?			
Yes or No				
Yes	Yes ▶ Replace ECM.			
No	No INSPECTION END			





# **Component Description**

The charge air pressure sensor detects pressure in the exit side of the charge air cooler. The sensor output voltage to the ECM increases as pressure increases. The charge air pressure sensor is not used to control the engine system under normal conditions.

GI

MA

EM

LG

EC

FE

GL

MT

TF

PD

FA

RA

AT

# **ECM Terminals and Reference Value**

Specification data are reference values, and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	
46	L	Charge air pressure sensor	

CONDITION DATA (DC Voltage)

Engine is running.

Warm-up condition Approximately 2.0V

BR

ST

# On Board Diagnosis Logic

Malfunction is detected when	Check Items (Possible Cause)
<ul> <li>An excessively high or low voltage from the sensor is sent to</li></ul>	<ul> <li>Harness or connectors</li></ul>
ECM.	(The sensor circuit is open or shorted.) <li>Charge air pressure sensor</li>


Idle speed

BT

HA

EL

SE




### **DTC Confirmation Procedure**



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 1 second.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-236.




- 1)
- Turn ignition switch "ON" and wait at least 1 second. Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-236.



# **Diagnostic Procedure**


### CHECK CHARGE AIR PRESSURE SENSOR POWER SUPPLY CIRCUIT

- 1. Stop engine.
- 2. Disconnect charge air pressure sensor harness connector.



SEF283Z

- 3. Turn ignition switch "ON".
- 4. Check voltage between charge air pressure sensor terminal 1 and ground with CONSULT-II or tester.



Voltage: Approximately 5V

SEF306Z

OK or NG

OK ►	GO TO 2.
NG ▶	Repair harness or connectors.

#### 2 CHECK CHARGE AIR PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch "OFF".
- 2. Check harness continuity between charge air pressure sensor terminal 3 and engine ground. Refer to Wiring Diagram.

#### Continuity should exist.

3. Also check harness for short to ground and short to power.

OK	or	NG
----	----	----

OK ▶	GO TO 4.
NG •	GO TO 3.

#### 3 DETECT MALFUNCTIONING PART

Check the following.


- Harness connectors F6, M51 (A/T models)
- Harness connectors M88, E106 (A/T models)
- Harness for open or short between ECM and charge air pressure sensor
- Harness for open or short between TCM (Transmission control module) and charge air pressure sensor
  - Repair open circuit or short to ground or short to power in harness or connectors.

# **DTC 0905 TURBO PRESSURE**

# Diagnostic Procedure (Cont'd)

		· , ,	1 Gl		
4	4 CHECK CHARGE AIR PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT				
2. Chec	Disconnect ECM harness connector.     Check harness continuity between ECM terminal 46 and charge air pressure sensor terminal 2. Refer to Wiring Diagram.     Continuity should exist.     Also check harness for short to ground and short to power.				
	OK or NG				
ОК	<b>•</b>	GO TO 5.	1		
NG	<b>•</b>	Repair open circuit or short to ground or short to power in harness or connectors.	LC		

5	CHECK CHARGE AIR PRESSURE SENSOR		
Remove charge air pressure sensor with its harness connector connected.			
2. Turn ignition switch "ON".			
3. Use p	3. Use pump to apply pressure to charge air pressure sensor as shown in the figure.		
CAUTIO	CAUTION:		
<ul><li>Alway</li></ul>	Always calibrate the pressure pump gauge when using it.		
• Inspec	<ul><li>Inspection should be done at room temperature [10 - 30°C (50 - 86°F)].</li></ul>		
4. Check	k the output voltage between charge air pressure sensor terminal 2 and engine ground.		



Pressure (Relative to atmospheric pressure)	Voltage V
0 kPa (0 mbar, 0 mmHg, 0 inHg)	1.9 - 3.0
+40 kPa (400 mbar, 300 mmHg, 11.81 inHg)	The voltage should be 0.6 to 1.0V higher than the value measured above.

SEF449Z

6.	
Replace charge air pressure sensor.	

6	CHECK INTERMITTENT INCIDENT	
Refer to	Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.	
	► INSPECTION END	
INSPECTION END		

EC

75

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

SE


# Description SYSTEM DESCRIPTION


Sensor	Input Signal to ECM	ECM Function	Actuator
Electronic controlled fuel injection pump	Fuel injection signal		
Crankshaft position sensor (TDC)	Engine speed		
Vehicle speed sensor	Vehicle speed		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position	EGR volume control	EGR volume control valve
Battery	Battery voltage		
Mass air flow sensor	Amount of intake air		
Air conditioner switch	Air conditioner operation		
Electrical load	Electrical load signal		
PNP switch	Park/Neutral position signal		

This system controls flow rate of EGR led from exhaust manifold to intake manifold. The opening of the EGR by-pass passage in the EGR volume control valve changes to control the flow rate. A built-in step motor moves the valve in steps corresponding to the ECM output pulses. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions.

The EGR volume control valve remains close under the following conditions.

- Engine stopped
- Engine starting
- Low engine coolant temperature
- Excessively high engine coolant temperature
- High engine speed
- Wide open throttle
- Low battery voltage





# **Description (Cont'd)** COMPONENT DESCRIPTION

#### EGR volume control valve

The EGR volume control valve uses a step motor to control the flow rate of EGR from exhaust manifold. This motor has four winding phases. It operates according to the output pulse signal of the ECM. Two windings are turned ON and OFF in sequence. Each time an ON pulse is issued, the valve opens or closes, changing the flow rate. When no change in the flow rate is needed, the ECM does not issue the pulse signal. A certain voltage signal is issued so that the valve remains at that particular opening.

# GI

MA

LC

# **CONSULT-II Reference Value in Data Monitor** Mode

Specification data are reference values.

MONITOR ITEM	COND	OITION	SPECIFICATION
	<ul><li>Engine: After warming up</li><li>Air conditioner switch: "OFF"</li></ul>	After 1 minute at idle	More than 10 steps
EGR VOL CON/V	Air conditioner switch: OFF     Shift lever: Neutral position     No-load	Revving engine up to 3,200 rpm quickly	0 step


### **ECM Terminals and Reference Value**

Specification data are reference values and are measured between each terminal and ground.

### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
103 105 109 115	L/Y L/W L R/L	EGR volume control valve	Engine is running.  Warm-up condition Idle speed	0.1 - 14V



### **DTC Confirmation Procedure**

WITH CONSULT-II

- Start engine and warm it up to normal operating temperature. 1)
- Select "DATA MONITOR" mode with CONSULT-II.
- Turn ignition switch "OFF", and immediately turn "ON" within 1 second.
- Start engine and let it idle.
- 5) If DTC is detected, go to "Diagnostic Procedure", EC-241.

# WITHOUT CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- Turn ignition switch "OFF", and immediately turn "ON" within 1 second.
- Start engine and let it idle.
- 4) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 5) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 6) If DTC is detected, go to "Diagnostic Procedure", EC-241.

EC

FE

GL

MT

AT

TF

PD

FA

RA


ST

BT

HA


EL

# **Wiring Diagram**



GI

# **Diagnostic Procedure**



ST

RS

BT


HA

EL

SE

### CHECK EGR VOLUME CONTROL VALVE POWER SUPPLY CIRCUIT-II

- 1. Turn ignition switch "OFF".
- 2. Disconnect ECM relay.



SEF225Z

3. Check harness continuity between ECM relay terminal 7 and EGR volume control valve terminals 2 and 5. Refer to Wiring Diagram.

Continuity should exist.

#### OK or NG

OK ▶	GO TO 4.
NG ▶	GO TO 3.


#### 3 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M50, F5
- Harness for open or short between EGR volume control valve and ECM relay
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

#### 4 CHECK EGR VOLUME CONTROL VALVE POWER SUPPLY CIRCUIT-III

Check voltage between ECM relay terminal 6 and ground with CONSULT-II or tester.



SEF297Z

OK or NG

OK ▶	GO TO 6.
NG ▶	GO TO 5.

#### 5 DETECT MALFUNCTIONING PART


Check the following.

- Harness connectors E127, M21
- 10A fuse
- Harness for open or short between ECM relay and battery
  - Repair open circuit or short to ground or short to power in harness or connectors.

### CHECK ECM RELAY

1. Apply 12V direct current between ECM relay terminals 1 and 2.

2. Check continuity between ECM relay terminals 3 and 5, 6 and 7.



Condition	Continuity	
12V direct current supply between terminals 1 and 2	Yes	
OFF	No	

SEF296X

OK or NG

OK ▶	GO TO 7.
NG ►	Replace ECM relay.

### 7 CHECK EGR VOLUME CONTROL VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch "OFF".
- 2. Disconnect ECM harness connector.
- Check harness continuity between ECM terminals and EGR volume control valve terminals as follows. Refer to Wiring Diagram.

ECM terminal	EGR volume control valve
103	1
105	3
109	6
115	4

MTBL0442

### Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK ▶	GO TO 8.
NG ►	Repair open circuit or short to ground or short to power in harness or connectors.

G[

MA

LC

EC

FE

GL

MT

AT

TF

PD

FA

RA

BR

51

RS

BT


HA


EL

SE

### CHECK EGR VOLUME CONTROL VALVE-I

Check resistance between EGR volume control valve terminal 2 and terminals 1, 3, terminal 5 and terminals 4, 6.





Resistance:

13 - 17 $\Omega$  [At 20°C (68°F)]

SEF414Y

OŁ	<b>(</b> o	r I	٧G
----	------------	-----	----


OK (With CONSULT-II)	<b>•</b>	GO TO 9.
OK (Without CONSULT-II)	<b>•</b>	GO TO 10.
NG	•	Replace EGR volume control valve.

#### CHECK EGR VOLUME CONTROL VALVE-II

#### (II) With CONSULT-II

- 1. Remove EGR volume control valve.
- 2. Reconnect ECM harness connector and EGR volume control valve harness connector.
- 3. Turn ignition switch "ON".
- 4. Perform "EGR VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II.
- 5. Check that EGR volume control valve shaft moves smoothly forward and backward according to the valve opening steps.

ACTIVE TEST			
EGR VOL CONT/V	20 step		
MONITOR	1		
CKPS-RPM (TDC)	XXX rpm		



SEF819Y

OK or NG

ОК	•	GO TO 11.
NG	•	Replace EGR volume control valve.

ST

BT


HA

EL

[DX

# DTC 1003 EGR VOLUME CONT/V

# Diagnostic Procedure (Cont'd) GI **CHECK EGR VOLUME CONTROL VALVE-II** Without CONSULT-II 1. Remove EGR volume control valve. MA 2. Reconnect ECM harness connector and EGR volume control valve harness connector. 3. Turn ignition switch "ON" and "OFF". 4. Check that EGR volume control valve shaft moves smoothly forward and backward according to the ignition switch position. LC EC FE GL SEF560W OK or NG MT OK GO TO 11. NG Replace EGR volume control valve. AT 11 **CHECK INTERMITTENT INCIDENT** TF Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107. **▶** INSPECTION END PD FA RA BR



# **Description**

#### SYSTEM DESCRIPTION

The ECM and the electronic control fuel injection pump control unit (abbreviated as the injection pump control unit) perform the real time communication (signal exchange).

The ECM transmits the signals of the target fuel injection amount, target fuel injection timing, and engine speed, etc., and receives the signals of the pump speed and fuel temperature, etc. from the injection pump control unit.

By those signals, the injection pump controls the optimum fuel injection amount and injection timing of the spill valve and timing control valve.

Injection pump control unit has an on board diagnostic system, which detects malfunctions related to sensors or actuators built-into electronic control fuel injection pump. These malfunction information are transferred through the line (circuit) from injection pump control unit to ECM.

#### **FUEL INJECTION AMOUNT CONTROL**

In accordance with the target fuel injection amount signal from the ECM, the injection amount is controlled by controlling the spill valve in the injection pump and by changing the needle opening time.

#### **FUEL INJECTION TIMING CONTROL**

Based on the target fuel injection timing signal from the ECM, the injection timing is controlled in accordance with the timer spring by performing the duty control of the timing control valve in the injection pump and by adjusting the pressure of the timer piston high pressure chamber.

### **FUEL TEMPERATURE SENSOR**

The sensor detects the fuel temperature in the injection pump and calibrates the injection amount change by the fuel temperature.

### **CAM RING POSITION SENSOR**

The sensor detects the passing of the protrusion on the sensor wheel in the injection pump by the semiconductor magnetic resistance element sensor. The cam ring position sensor synchronizes with the cam ring, and detects the actual advance amount. The injection pump control unit measures the injection pump revolution by the signal of the cam ring position sensor.

# **CONSULT-II Reference Value in Data Monitor** Mode

GI

Remarks: Specification data are reference values.

_	_	-
LA		/.\
IM	/A I	//\\

EM

LC

EC

MONITOR ITEM	CONDITION		SPECIFICATION
FUEL TEMP SEN	Engine: After warming up		More than 40°C (104°F)
SPILL/V	Engine: After warming	g up	Approx. 13°CA
INJ TIMG C/V	Engine: After warming up, idle the engine.		Approx. 50 - 70%
DECELER F/CUT	Engine: After warming up  Idle		OFF
BARO SEN	• Ignition switch: ON		Altitude Approx. 0 m (0 ft): Approx. 100.62 kPa (1.0062 bar, 1.026 kg/cm², 14.59 psi) Approx. 1,000 m (3,281 ft): Approx. 88.95 kPa (0.8895 bar, 0.907 kg/cm², 12.90 psi) Approx. 1,500 m (4,992 ft): Approx. 83.16 kPa (0.8316 bar, 0.848 kg/cm², 12.06 psi) Approx. 2,000 m (6,562 ft): Approx. 78.36 kPa (0.7836 bar, 0.799 kg/cm², 11.36 psi)

FE

GL

MT

**ECM Terminals and Reference Value** 

AT

Specification data are reference values and are measured between each terminal and ground.

TF

### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


PD

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	FA
33	G/Y	Electronic control fuel injection pump	Engine is running.  Warm-up condition Idle speed	Approximately 2.5V	RA
40	R/B	Electronic control fuel injection pump	Engine is running.  Warm-up condition Idle speed	Approximately 2.5V	BR ST
52	L/B	Electronic control fuel injection pump	Engine is running.  Idle speed	Approximately 0.1V	RS
53	L/R	Electronic control fuel injection pump	Engine is running.  Idle speed	Approximately 0.35V	BT

# On Board Diagnosis Logic

HA

Malfunction is detected when	Check Items (Possible cause)	EL
Fuel cut control system does not function properly.	<ul> <li>Harness or connectors (Electronic control fuel circuit is open or shorted.)</li> <li>Electronic control fuel</li> </ul>	SE




### **DTC Confirmation Procedure**



- 1) Turn ignition switch "ON" and wait at least 2 seconds.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and run it for at least 2 seconds at idle speed. (If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
- 4) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON"
- 5) If DTC is detected, go to "Diagnostic Procedure", EC-250.

# WITHOUT CONSULT-II


- 1) Turn ignition switch "ON" and wait at least 2 seconds.
- Start engine and run it for at least 2 seconds at idle speed. (If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
- 3) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON"
- Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 5) If DTC is detected, go to "Diagnostic Procedure", EC-250.



# **Diagnostic Procedure**


#### CHECK ELECTRONIC CONTROL FUEL INJECTION PUMP POWER SUPPLY CIRCUIT

- 1. Turn ignition switch "OFF".
- 2. Disconnect electronic control fuel injection pump harness connector.



SEF229Z

- 3. Turn ignition switch "ON".
- 4. Check voltage between electronic control fuel injection pump terminal 7 and ground.



SEF438Y

ОК	► GO TO 3.
NG	▶ GO TO 2.

### 2 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M50, F5
- Harness connectors F4, EC4
- Harness for open or short between electronic control fuel injection pump and ECM
- Harness for open or short between electronic control fuel injection pump and ECM relay
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

### 3 CHECK ELECTRONIC CONTROL FUEL INJECTION PUMP GROUND CIRCUIT FOR OPEN AND SHORT

- 1. Turn ignition switch "OFF".
- 2. Check harness continuity between electronic control fuel injection pump terminal 6 and ground. Refer to Wiring Diagram. **Continuity should exist.**
- 3. Also check harness for short to ground and short to power.

OK	or	NG

OK or NG

OK ▶	GO TO 5.
NG •	GO TO 4.

# DTC 1004 FUEL CUT SYSTEM1

4					
	DETECT MALFUNCTIONI	NG PART			7
Harne	the following. ness connectors F4, EC4 ness for open or short betwee	n electronic control fuel injection pump and	engine ground		
	•	Repair open circuit or short to ground or s	hort to power in	harness or connectors.	
5	CHECK COMMUNICATION	N LINE FOR OPEN AND SHORT			7
1. Ched	eck continuity between the foll	owing terminals. Refer to Wiring Diagram.			1
		Electronic control fuel injection pump	ECM 33		
		2	40		
		5	52		
		8	53		
				MTBL0444	
C	Continuity should exist.				
	check harness for short to g	round and short to power.			
	check harness for short to g	round and short to power.  OK or NG			
	o check harness for short to g	·			
2. Also		OK or NG			-
2. Also OK	<u> </u>	OK or NG			
2. Also OK	<u> </u>	OK or NG GO TO 7. GO TO 6.			] ] ]
2. Also OK NG	<b>&gt;</b>	OK or NG GO TO 7. GO TO 6.			
2. Also OK NG 6 Check	DETECT MALFUNCTIONI the following. ness connectors F4, EC4	OK or NG GO TO 7. GO TO 6.  NG PART	F0M		
2. Also OK NG 6 Check	DETECT MALFUNCTIONI the following. less connectors F4, EC4 less for open or short between	OK or NG GO TO 7. GO TO 6.  NG PART  n electronic control fuel injection pump and			
2. Also OK NG 6 Check	DETECT MALFUNCTIONI the following. ness connectors F4, EC4	OK or NG GO TO 7. GO TO 6.  NG PART		harness or connectors.	
2. Also OK NG 6 Check • Harne	DETECT MALFUNCTIONI the following. ness connectors F4, EC4 ness for open or short betwee	OK or NG GO TO 7. GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or s		harness or connectors.	
2. Also OK NG 6 Check Harne	DETECT MALFUNCTIONI the following. less connectors F4, EC4 less for open or short betwee	OK or NG GO TO 7. GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or s		harness or connectors.	
2. Also OK NG 6 Check Harne	DETECT MALFUNCTIONI the following. less connectors F4, EC4 less for open or short betwee	OK or NG GO TO 7. GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or so NCIDENT  OR INTERMITTENT INCIDENT", EC-107.		harness or connectors.	
2. Also OK NG 6 Check Harne Harne	DETECT MALFUNCTIONI the following. ness connectors F4, EC4 ness for open or short betwee  CHECK INTERMITTENT II to "TROUBLE DIAGNOSIS F6	OK or NG GO TO 7. GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or so NCIDENT OR INTERMITTENT INCIDENT", EC-107. OK or NG	hort to power in	harness or connectors.	
2. Also OK NG 6 Check Harne	DETECT MALFUNCTIONI the following. less connectors F4, EC4 less for open or short betwee	OK or NG GO TO 7. GO TO 6.  NG PART  n electronic control fuel injection pump and Repair open circuit or short to ground or so NCIDENT  OR INTERMITTENT INCIDENT", EC-107.	hort to power in		

EL

SE

# **Description**

#### SYSTEM DESCRIPTION

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor (TDC)	Engine speed	Glow	Glow lamp, Glow relay
Engine coolant tem- perature sensor	Engine coolant tem- perature	control	↓ Glow plugs

When engine coolant temperature is more than approximately 75°C (167°F), the glow relay turns off, inactivating the quick-glow control until coolant temperature drops below approximately 55°C (131°F). When coolant temperature is lower than approximately 75°C (167°F):

Ignition switch ON

After ignition switch has turned to ON, the glow relay turns ON for a certain period of time in relation to engine coolant temperature, allowing current to flow through glow plug.

Cranking


The glow relay turns ON, allowing current to flow through glow plug.


Starting

After engine has started, current continues to flow through glow plug (after-glow mode) for a certain period in relation to engine coolant temperature.

When engine speed exceeds approximately 4,800 rpm, current flow through glow plug is interrupted.

The glow indicator lamp turns ON for a certain period of time in relation to engine coolant temperature at the time glow relay is turned ON.





#### COMPONENT DESCRIPTION

#### Glow plug

The glow plug is provided with a ceramic heating element to obtain a high-temperature resistance. It glows in response to a signal sent from the ECM, allowing current to flow through the glow plug via the glow relay.

This engine uses two types of glow plugs.
 Type A has a blue or yellow paint mark.
 Type B has no paint mark.

The location of the paint mark is shown in the figure.

#### **WARNING:**

Do not use two types of glow plugs at the same time.

# **ECM Terminals and Reference Value**

Specification data are reference values and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16 L/W	Glow indicator lamp	Ignition switch "ON"  Glow indicator lamp is "ON"	Approximately 1V	
	L/VV	Glow indicator famp	Ignition switch "ON"  Glow indicator lamp is "OFF"	BATTERY VOLTAGE (11 - 14V)
111	LG/B	Glow relay	Refer to "SYSTEM DESCRIPTION", EC-252.	

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS


BT

HA

EL

SE

# **Wiring Diagram**



GI

MA

EM

FA

RA

BR

ST

BT


HA

EL

SE

# **Diagnostic Procedure**

1	INSPECTION START		
Check fuel level, fuel supplying system, starter motor, etc.			
OK or NG			
ОК	<b>&gt;</b>	GO TO 2.	
NG	<b>•</b>	Correct.	



#### 3 CHECK GLOW INDICATOR LAMP OPERATION

- (H) With CONSULT-II
- 1. Turn ignition switch "ON".
- 2. Select "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II.
- 3. Confirm that "COOLAN TEMP/S" indicates below 75°C (167°F). If it indicates above 75°C (167°F), cool down engine.

DATA MONITOR		
MONITOR NO DTC		
COOLAN TEMP/S	XXX °C	

SEF013Y

- 4. Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 5. Make sure that glow indicator lamp is turned "ON" for 1.5 seconds or more after turning ignition switch "ON", and then turned "OFF".


ok	or	NG
----	----	----

OK ▶	GO TO 5.
NG •	GO TO 6.

#### CHECK GLOW INDICATOR LAMP OPERATION

#### Without CONSULT-II

- 1. Turn ignition switch "ON".
- 2. Confirm that the voltage between ECM terminal 19 and ground is above 1.36V. If it is below 1.36V, cool down engine.



SEF430Y


- 3. Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 4. Make sure that glow indicator lamp is turned "ON" for 1.5 seconds or more after turning ignition switch "ON", and then turned "OFF".

	or	

OK ▶	GO TO 5.
NG •	GO TO 6.

## 5 CHECK GLOW CONTROL SYSTEM OVERALL FUNCTION


- 1. Turn ignition switch "OFF".
- 2. Set voltmeter probe between glow plug and engine body.
- 3. Turn ignition switch "ON".
- 4. Check the voltage between glow plug and engine body under the following conditions.



Conditions	Voltage
For 20 seconds after turning ignition switch ON	Battery voltage
More than 20 seconds after turning ignition switch ON	Approx. 0V


SEF234Z

OK ▶	INSPECTION END
NG ▶	GO TO 11.




#### CHECK GLOW RELAY POWER SUPPLY CIRCUIT

- 1. Turn ignition switch "OFF".
- 2. Disconnect glow relay.



SEF235Z

3. Check voltage between glow relay terminals 1, 3 and ground with CONSULT-II or tester.



SEF451Z

OK or NG

OK	<b>&gt;</b>	GO TO 13.
NG	<b>&gt;</b>	GO TO 12.

#### 12 DETECT MALFUNCTIONING PART

Check the following.

- 100A fusible link
- Harness for open or short between glow relay and battery
  - ► Repair harness or connectors.

## 13 CHECK GLOW RELAY OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- 1. Disconnect ECM harness connector.
- 2. Check harness continuity between ECM terminal 111 and glow relay terminal 2. Refer to Wiring Diagram.

#### Continuity should exist.

3. Also check harness for short to ground and short to power.

ОК	<b>&gt;</b>	GO TO 15.
NG	<b>•</b>	GO TO 14.

# **GLOW CONTROL SYSTEM**


# **Diagnostic Procedure (Cont'd)**

# 

2. Check harness of Continuity sh	Disconnect glow plug harness connector.  Check harness continuity between glow relay terminal 5 and glow plug harness connector. Refer to Wiring Diagram.  Continuity should exist.  Also check harness for short to ground and short to power.	
OK or NG		
OK ▶ GO TO 16.		
NG Repair open circuit or short to ground or short to power in harness or connectors.		

	Check the following.				
	Harness connectors E67, E223				
	Harness connectors E225, E241				
	◆ Harness for open or short between glow relay and glow plug      ▶ Repair open circuit or short to ground or short to power in harness or connectors.				

Repair open circuit or short to ground or short to power in harness or connectors.				
17 CHECK GLOW RELAY				
Check continuity between glow relay terminals 3 and 5 under the following conditions.				



**DETECT MALFUNCTIONING PART** 

16

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

Operation takes less than 1 second.

OK or NG		
OK ▶	GO TO 18.	
NG •	Replace glow relay.	

MA

EM

LC

EC

FE

GL

MT

AT

TF

PD

FA

RA

BR

ST

SEF433Y

RS


BT

HA


EL

SE

 $\mathbb{D}\mathbb{X}$ 



19	CHECK INTERMITTENT INCIDENT			
Refer to	er to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.			
	► INSPECTION END			



# **Diagnostic Procedure**

#### CHECK START SIGNAL OVERALL FUNCTION

#### (I) With CONSULT-II

- 1. Turn ignition switch "ON".
- 2. Check "START SIGNAL" in "DATA MONITOR" mode with CONSULT-II under the following conditions.


DATA MONITOR		
MONITORING	NO FAIL	
START SIGNAL	OFF	
CLSD TH/P SW	ON	
AIR COND SIG	OFF	
P/N POSI SW	ON	

Condition	"START SIGNAL"	
Ignition switch "ON"	OFF	
Ignition switch "START"	ON	

SEF604X

#### Without CONSULT-II

Check voltage between ECM terminal 20 and ground under the following conditions.



Condition	Voltage	
Ignition switch "START"	Battery voltage	
Other positions	Approximately 0V	

SEF415Y

#### OK or NG

OK ►	INSPECTION END
NG <b>•</b>	GO TO 2.

#### 2 CHECK START SIGNAL INPUT SIGNAL CIRCUIT

- 1. Turn ignition switch "OFF".
- 2. Disconnect ECM harness connector and ignition switch harness connector.
- 3. Check harness continuity between ECM terminal 20 and ignition switch terminal 6. Refer to Wiring Diagram.

#### Continuity should exist.

4. Also check harness for short to ground and short to power.

#### OK or NG

OK •	GO TO 4.
NG •	GO TO 3.

#### 3 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M52, F7
- 7.5A fuse
- Fuse block (J/B) connectors M3, E112
- Harness for open or short between ECM and ignition switch
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

ZD30DDTi

# START SIGNAL Diagnostic Procedure (Cont'd)

4	4 CHECK INTERMITTENT INCIDENT			
Refer to	Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.			
	► INSPECTION END			

G[

 $\mathbb{M}\mathbb{A}$ 

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

SE

# PARK/NEUTRAL POSITION (PNP) SWITCH

# **Description**

When the gear position is in "Neutral", neutral position is "ON". ECM detects the position because the continuity of the line (the "ON" signal) exists.

# **CONSULT-II** Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
D/N DOSLSW	Ignition switch: ON	Shift lever: Park/Neutral	ON
P/N POSI SW		Except above	OFF


## **ECM Terminals and Reference Value**

Specification data are reference values and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
22	P/B	Park/Neutral position switch	Ignition switch "ON"  Gear position is "Neutral" (M/T models)  Gear position is "P" or "N" (A/T models)	Approximately 0V
			Ignition switch "ON"  Except the above gear position	BATTERY VOLTAGE (11 - 14V)



# Diagnostic Procedure FOR M/T MODELS

#### CHECK OVERALL FUNCTION

## With CONSULT-II

- 1. Turn ignition switch "ON".
- 2. Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-II.
- 3. Check "P/N POSI SW" signal under the following conditions.


DATA MON	NITOR
MONITOR	NO DTC
P/N POSI SW	ON

Shift lever position	P/N POSI SW
Neutral position	ON
Except the above position	OFF

SEF049Y

# Without CONSULT-II

- 1. Turn ignition switch "ON".
- 2. Check voltage between ECM terminal 22 and ground under the following conditions.




Condition (Gear position)	Voltage V	
Neutral position	Approx. 0V	
Except the above position	Battery voltage	

SEF419Y

OK •	INSPECTION END
NG ►	GO TO 2.

# PARK/NEUTRAL POSITION (PNP) SWITCH

# **Diagnostic Procedure (Cont'd)**




# PARK/NEUTRAL POSITION (PNP) SWITCH

# Diagnostic Procedure (Cont'd)

7	CHECK INTERMITTENT IN	NCIDENT
Refer to	Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.	
	<b>•</b>	INSPECTION END

# FOR A/T MODELS **CHECK OVERALL FUNCTION** With CONSULT-II 1. Turn ignition switch "ON". 2. Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-II. 3. Check "P/N POSI SW" signal under the following conditions. DATA MONITOR MONITOR NO DTC P/N POSI SW P/N POSI SW Shift lever position Neutral position ON Except the above position OFF SEF049Y Without CONSULT-II 1. Turn ignition switch "ON".

2. Check voltage between ECM terminal 22 and ground under the following conditions.




Condition (Gear position)	Voltage V
Neutral position	Approx. 0V
Except the above position	Battery voltage

SEF419Y

OK ▶	INSPECTION END
NG ▶	GO TO 2.

# PARK/NEUTRAL POSITION (PNP) SWITCH

# **Diagnostic Procedure (Cont'd)**




# PARK/NEUTRAL POSITION (PNP) SWITCH

# **Diagnostic Procedure (Cont'd)**

#### CHECK PNP SWITCH POWER SUPPLY CIRCUIT

- 1. Turn ignition switch "OFF".
- 2. Disconnect PNP switch harness connector.
- 3. Turn ignition switch "ON".
- 4. Check voltage between PNP switch terminal 3 and ground with CONSULT-II or tester.



SEF299Z

#### OK or NG

OK	► GO TO 6.
NG	► GO TO 5.

#### 5 DETECT MALFUNCTIONING PART

Check the following.


- Fuse block (J/B) connector E112
- 7.5A fuse

6

- Harness for open or short between PNP switch and fuse
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

#### CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN OR SHORT-I

- 1. Turn ignition switch "OFF".
- 2. Disconnect TCM (Transmission control module) harness connector.
- 3. Check harness continuity between TCM terminal 36 and PNP switch terminals 7, 9 under the following conditions.



Conditions	Continuity
1	Should exist.
2	Should not exist.

SEF300Z

4. Also check harness for short to ground and short to power.

OK ▶	GO TO 8.
NG ▶	GO TO 7.


# ZD30DDTi

EL

SE

# PARK/NEUTRAL POSITION (PNP) SWITCH

		Diagnostic Procedure (Cont'd)	_
7	DETECT MALFUNCTIONING PART		
Check the following.  Diode E103  Harness for open or short between PNP switch and TCM (Transmission control module)			
• Hall	b	Repair open circuit or short to ground or short to power in harness or connectors.	
	<u> </u>	Tropan open anount of another ground of other to period in manifest of connectors.	
8	CHECK PARK/NEUTRAL	POSITION (PNP) SWITCH	
Refer	to "TROUBLE DIAGNOSIS F	OR NON-DETECTABLE ITEMS" in AT section.	
		OK or NG	
OK	<b>&gt;</b>	GO TO 9.	
NG	•	Replace park/neutral position (PNP) switch.	
9		PUT SIGNAL CIRCUIT FOR OPEN OR SHORT-II	
	n ignition switch "OFF". connect ECM harness connec	etor.	
3. Che	eck harness continuity betwee	n ECM terminal 22 and TCM terminal 14. Refer to Wiring Diagram.	
	Continuity should exist.  o check harness for short to g	round and short to power.	
	9	OK or NG	
OK	<b>•</b>	GO TO 11.	
NG	<b>•</b>	GO TO 10.	
10	DETECT MALFUNCTION	NG PART	
	the following.		
	ness connectors F7, M52 ness connectors M21, E127		
<ul><li>Harr</li></ul>	ness for open or short betwee	n ECM and TCM (Transmission control module)	
	<b>•</b>	Repair open circuit or short to ground or short to power in harness or connectors.	
11	CHECK INTERMITTENT I		
Perior	III TROUBLE DIAGNOSIS F	OR INTERMITTENT INCIDENT", EC-107.  INSPECTION END	
		INSPECTION END	



# **Component Description**

The heat up switch is located on the lower side of the instrument panel. This switch is used to speed up the heater's operation when the engine is cold.

When the ECM received the heat up switch "ON" signal, the ECM increases the engine idle speed to 1,100 to 1,200 rpm to warm up engine quickly.

This system works when all conditions listed below are met.

Heat up switch	ON
Engine coolant temperature	Below 105°C (221°F)
Shift lever	"P" or "N"
Accelerator pedal	Fully released

# **CONSULT-II** Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MADM LID CW		Heat up switch: ON	ON
WARM UP SW	Ignition switch: ON	Heat up switch: OFF	OFF


## **ECM Terminals and Reference Value**

Specification data are reference values and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
59	BR/W	Hoot up quitab	Ignition switch "ON"  Heat up switch is "OFF".	0V
59	DR/W	Heat up switch	Ignition switch "ON"  Heat up switch is "ON".	BATTERY VOLTAGE (11 - 14V)



# **Diagnostic Procedure**

1	INSPECTION START			
Do you	Do you have CONSULT-II?			
	Yes or No			
Yes	Yes ▶ GO TO 2.			
No	<b>•</b>	GO TO 3.		

#### 2 CHECK OVERALL FUNCTION

## With CONSULT-II

- 1. Turn ignition switch "ON".
- 2. Check "WARM UP SW" in "DATA MONITOR" mode with CONSULT-II under the following conditions.

DATA MONITOR		
MONITOR NO D		
WARM UP SW	OFF	

Conditions	WARM UP SW
Heat-up switch is "OFF".	OFF
Heat-up switch is "ON".	ON

SEF302Z


OK or NG

OK ▶	INSPECTION END
NG ►	GO TO 4.

## 3 CHECK OVERALL FUNCTION

## Without CONSULT-II

- 1. Turn ignition switch "ON".
- 2. Check voltage between ECM terminal 59 and ground under the following conditions.



Conditions	Voltage
Heat-up switch is "OFF".	Approximately 0V
Heat-up switch is "ON".	Battery voltage

SEF303Z

OK ▶	INSPECTION END
NG ▶	GO TO 4.



EL


SE

# **HEAT UP SWITCH**

# **Diagnostic Procedure (Cont'd)**

# 8 CHECK HEAT UP SWITCH

Check continuity between heat up switch terminals 5 and 6 under the following conditions.



Conditions	Continuity
Heat-up switch is "OFF".	Should not exist.
Heat-up switch is "ON".	Should exist.

SEF305Z

OK ▶	GO TO 9.
NG ►	Replace heat up switch.

9	CHECK INTERMITTENT INCIDENT	
Refer to	Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.	
	► INSPECTION END	

GI

MA

EM

LC

EC

MIT

AT

TF

PD

FA

RA

BR

# Description SYSTEM DESCRIPTION

Sensor	Input Signal to ECM	ECM Function	Actuator
Ignition switch	Start signal	Swirl	Swirl control valve control solenoid valve
Crankshaft position sensor (TDC)	Engine speed	ne speed control Vacuum signal  Neutral position signal valve control Swirl control valve	
PNP switch	Park/Neutral position signal		Swirl control valve actuator
ngine coolant temperature sensor	Engine coolant temperature		↓ Swiri control valve

This system has a swirl control valve in the throttle body.


While idling and during low engine speed operation, the swirl control valve closes. Thus the velocity of the air in the intake passage increases, promoting the vaporization of the fuel and producing a swirl in the combustion chamber.

Because of this operation, this system tends to increase the burning speed of the gas mixture, improve fuel consumption, and increase the stability in running conditions.


Also, except when idling and during low engine speed operation, this system opens the swirl control valve. In this condition, this system tends to increase power by improving intake efficiency via reduction of intake flow resistance, intake flow.

The solenoid valve controls swirl control valve's shut/open condition. This solenoid valve is operated by the ECM.

PNP switch	Engine speed	Engine cool- ant tempera- ture	Swirl control valve control solenoid valve	Swirl control valve
OFF	Less than 1,250 rpm	Less than 50°C (122°F)	OFF	Open
		More than 50°C (122°F)	ON	Closed
	More than 1,250 rpm	Less than 50°C (122°F)	OFF	Open
		More than 50°C (122°F)	OFF	Open
ON	_	_	OFF	Open



SE



# **Description (Cont'd)** COMPONENT DESCRIPTION

#### Swirl control valve control solenoid valve

The swirl control valve control solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the solenoid valve is bypassed to apply vacuum pump vacuum to the swirl control valve actuator. This operation closes the swirl control valve. When the ECM sends an OFF signal, the vacuum signal is cut and the swirl control valve opens.

# **CONSULT-II Reference Value in Data Monitor** Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
SWRL CONT S/V	<ul><li>Lift up the vehicle</li><li>Engine: After warming up, let it idle for more than 1 second.</li></ul>	Shift lever: Except "P" and "Neutral" position	ON
	Air conditioner switch: OFF     No-load	Shift lever: "Neutral" position	OFF


## **ECM Terminals and Reference Value**

Specification data are reference values and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
54 L/B	Swirl control valve control	Engine is running.  Warm-up condition At idle speed for more than 1 second. Lift up the vehicle Gear position is except "P" and "Neutral"	Approximately 0.1V	
		solenoid valve	Engine is running.  Idle speed Lift up the vehicle Gear position is "P" or "Neutral"	BATTERY VOLTAGE (11 - 14V)



# **Diagnostic Procedure**


1	INSPECTION START		
Do you l	Do you have CONSULT-II?		
	Yes or No		
Yes	<b>&gt;</b>	GO TO 2.	
No	<b>•</b>	GO TO 3.	

#### 2 **CHECK OVERALL FUNCTION**

#### (P) With CONSULT-II

- 1. Start engine and let it idle.
- 2. Select "SWIRL CONT S/V 1" in "ACTIVE TEST" mode with CONSULT-II.
- 3. Touch "ON" and "OFF" alternately on CONSULT-II screen.
- 4. Make sure that swirl control valve actuator rod moves according to "SWIRL CONT S/V 1" indication.

ACTIVE TEST	
SWIRL CONT S/V 1	ON
MONITOR	
CKPS-RPM (TDC)	750 rpm
SWRL CON S/V 1	ON



SEF307Z


OK or NG

OK ▶	INSPECTION END
NG •	GO TO 4.

#### **CHECK OVERALL FUNCTION**

#### Without CONSULT-II

- 1. Lift up the vehicle.
- 2. Start engine and warm it up to normal operating temperature.
- 3. Run engine at idle speed.
- 4. Make sure that swirl control valve actuator rod moves when shifting the shift lever to "P" or "Neutral" position and then to positions other than "P" and "Neutral".



SEF308Z

OK ▶	INSPECTION END
NG ▶	GO TO 5.

#### **Diagnostic Procedure (Cont'd) CHECK VACUUM SOURCE** (II) With CONSULT-II 1. Turn ignition switch "OFF". 2. Disconnect vacuum hose connected to swirl control valve actuator. 3. Start engine and let it idle. 4. Select "SWIRL CONT S/V 1" in "ACTIVE TEST" mode with CONSULT-II. 5. Touch "ON" and "OFF" alternately on CONSULT-II screen. 6. Check vacuum hose for vacuum existence under the following conditions. ACTIVE TEST SWIRL CONT S/V 1 ON Swirl control valve actuator MONITOR CKPS-RPM (TDC) 750 rpm SWIRL CONT S/V 1 Vacuum SWRL CON S/V 1 ON Should exist. OFF Should not exist.


OK or NG

OK GO TO 7.  $\blacktriangleright$ NG GO TO 6.

#### 5 **CHECK VACUUM SOURCE**

#### Without CONSULT-II

- 1. Turn ignition switch "OFF".
- 2. Disconnect vacuum hose connected to swirl control valve actuator.
- 3. Lift up the vehicle.
- 4. Start engine and warm it up to normal operating temperature.
- 5. Run engine at idle speed
- 6. Check vacuum hose for vacuum existence under the following conditions.



Condition	Vacuum
Shift lever is in positions other than "P" and "Neutral".	Should exist.
Shift lever is in "P" or "Neutral" position.	Should not exist.

SEF310Z

OK or NG	
OK ▶	GO TO 7.
NG •	GO TO 6.

GI

MA

EM

LC

EC

FE

GL

MT

AT

SEF309Z

TF

PD

FA

RA

BR

BT

HA

EL

SE


# Diagnostic Procedure (Cont'd)

#### **CHECK SWIRL CONTROL VALVE ACTUATOR**

1. Turn ignition switch "OFF".

6

- 2. Install a vacuum pump to swirl control valve actuator.
- 3. Make sure that the swirl control valve actuator rod moves smoothly when applying vacuum of -93.3 kPa (-933 mbar, -700 mmHg, -27.6 inHg) and releasing it.




SEF311Z

#### OK or NG

OK ►	Repair or replace vacuum hoses and vacuum gallery.
NG ▶	Replace swirl control valve actuator.

#### **CHECK VACUUM HOSE**

- 1. Turn ignition switch "OFF".
- 2. Check vacuum hoses and vacuum gallery for clogging, cracks or improper connection.






SEF109L

OK ►	GO TO 8.
NG •	Repair or replace vacuum hoses and vacuum gallery.

# **Diagnostic Procedure (Cont'd)**




# Diagnostic Procedure (Cont'd)

#### CHECK SWIRL CONTROL VALVE CONTROL SOLENOID VALVE

#### With CONSULT-II

- 1. Reconnect all disconnected harness connectors.
- 2. Turn ignition switch "ON".
- 3. Select "SWIRL CONT S/V 1" in "ACTIVE TEST" mode with CONSULT-II.
- 4. Check air passage continuity of swirl control valve control solenoid valve under the following conditions.

ACTIVE TEST			
SWIRL CONT S/V 1 ON			
MONITOR			
CKPS-RPM (TDC)	750 rpm		
SWRL CON S/V 1	ON		




SWIRL CONT S/V 1	Air passage continuity between A and B
ON	Yes
OFF	No

SEF313Z

#### Without CONSULT-II

- 1. Apply 12V direct current between swirl control valve control solenoid valve terminals.
- 2. Check air passage continuity of swirl control valve control solenoid valve under the following conditions.



Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No


SEF335X

OK ▶	GO TO 12.
NG •	Replace swirl control valve control solenoid valve.

12	CHECK INTERMITTENT INCIDENT		
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.			
	► INSPECTION END		

# INTAKE AIR CONTROL VALVE CONTROL SOLENOID VALVE

ZD30DDTi



# **Description**

Vibration when stopping the engine can be controlled by cutting intake air right before the fuel is cut. The intake air control valve control solenoid valve controls the ON-OFF load of the intake air control valve actuator. As a result, the intake air control valve control solenoid valve will be turned ON when the ignition switch is turned OFF with the engine running and when the engine stalls. After the engine has stopped, the intake air control valve control solenoid valve will return to fully open.

# GI

MA

LC

# **ECM Terminals and Reference Value**

Specification data are reference values, and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	R/W Intake air control valve control solenoid valve	Intake air control valve	Engine is running.	BATTERY VOLTAGE (11 - 14V)
			Ignition switch "OFF"  For a few seconds after engine stops	Approximately 0.1V

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

38


BT


HA

EL

SE

# **Wiring Diagram**







# INTAKE AIR CONTROL VALVE CONTROL SOLENOID VALVE

ZD30DDTi

# **Diagnostic Procedure**



- 1. Turn ignition switch "OFF".
- 2. Disconnect vacuum hose connected to intake air control valve actuator.
- 3. Start engine and let it idle.
- 4. Check vacuum hose for vacuum existence under the following conditions.



Condition	Vacuum
For a few seconds after turning ignition switch OFF	Should exist.
Except above.	Should not exist.
	<u> </u>

SEF316Z

OK or NG	
OK ▶	GO TO 3.
NG •	GO TO 4.

GI

MA

LC

EC

FE

GL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

SE

# INTAKE AIR CONTROL VALVE CONTROL SOLENOID VALVE

ZD30DDTi

# Diagnostic Procedure (Cont'd)

# 3 CHECK INTAKE AIR CONTROL VALVE ACTUATOR 4. Turn ignition switch "OFF". 5. Install a vacuum pump to intake air control valve actuator. 6. Make sure that the intake air control valve actuator rod moves smoothly when applying vacuum of –93.3 kPa (–933 mbar, –700 mmHg, –27.56 psi) and releasing it. View with vacuum tank removed Vacuum pump Vacuum pump SEF317Z OK or NG

Repair or replace vacuum hoses and vacuum gallery.

Replace intake air control valve actuator.

OK

NG

4	CHECK VACUUM HOSE		
	3. Turn ignition switch "OFF". 4. Check vacuum hoses and vacuum gallery for clogging, cracks or improper connection.		
		© Zsplit	
	Clogging		
		Improper connection	
	SEF109L		
	OK or NG		
ОК	<b>•</b>	GO TO 5.	
NG	<b>•</b>	Repair or replace vacuum hoses and vacuum gallery.	

## INTAKE AIR CONTROL VALVE CONTROL SOLENOID VALVE

ZD30DDTi

ST


BT

HA

EL

SE

## **Diagnostic Procedure (Cont'd)**




## INTAKE AIR CONTROL VALVE CONTROL SOLENOID VALVE

CHECK INTAKE AIR CONTROL VALVE CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT-II

ZD30DDTi

## **Diagnostic Procedure (Cont'd)**

- 1. Turn ignition switch "OFF".
- 2. Disconnect ECM relay.



SEF225Z

3. Check harness continuity between intake air control valve control solenoid valve terminal 2 and ECM relay terminal 7. Refer to Wiring Diagram.

#### Continuity should exist.

4. Also check harness for short to ground and short to power.

#### OK or NG

OK ▶	GO TO 8.
NG ►	GO TO 7.


#### 7 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M50, F5
- Harness for open or short between intake air control valve control solenoid valve and ECM relay
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

#### 8 CHECK INTAKE AIR CONTROL VALVE CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT-III

Check voltage between ECM relay terminal 6 and ground with CONSULT-II or tester.



SEF297Z

OK or NG

OK •	GO TO 10.
NG <b>&gt;</b>	GO TO 9.

#### 9 DETECT MALFUNCTIONING PART


Check the following.

- Harness connectors M21, E127
- 10A fuse
- Harness for open or short between ECM relay and battery
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.


## INTAKE AIR CONTROL VALVE CONTROL SOLENOID VALVE

ZD30DDTi

## **Diagnostic Procedure (Cont'd)**




13	CHECK INTERMITTENT INCIDENT		
Perform	Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.		
	► INSPECTION END		



### **Description**

The load from the variable nozzle turbocharger control solenoid valve controls the actuator. By changing the variable nozzle vane opening through the rods, the intake air volume is adjusted.



The variable nozzle turbocharger control solenoid valve is moved by ON/OFF pulse from the ECM. The longer the ON pulse, the charge air pressure rises.

# **CONSULT-II** Reference Value in Data Monitor Mode

#### Specification data are reference values.

MONITOR ITEM	CONE	DITION	SPECIFICATION
VNT S// 1	Engine: After warming up     Air conditioner switch: "OFF"     Shift lever: Neutral position     No-load	Idle	Approx. 56%
VINT 3/V T		2,000 rpm	Approx. 20%

ZD30DDTi

### **ECM Terminals and Reference Value**

Specification data are reference values, and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

			, ,		l⊆l/Ω
TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	EM LC
				Approximately 6.8V	
			Engine is running.	(V) 20	EC
			Warm-up condition Idle speed	10 0	FE
					GL
404	D (D	Variable nozzle turbo-		SEF253Z	VL
101	R/B	charger control solenoid valve		Approximately 11V	0.052
				(V) (V)	MT
		Engine is running.  Warm-up condition Engine speed is 2,000 rpm	Warm-up condition	20 10 0	AT
			Engine speed is 2,000 ipin	1ms	TF
				SEF254Z	

GI

MA

EM

MT

PD

FA

RA

BR

ST

RS

BT


HA

EL

SE

ZD30DDTi

## **Wiring Diagram**



E202 , F12 B

110 111 112


107 108 109

1 2 3 5 6 7 8 9

ZD30DDTi

GI

## **Diagnostic Procedure**



SEF321Z

OK or NG		
OK ▶	GO TO 3.	
NG ▶	GO TO 5.	

SE

BT

HA


EL

ZD30DDTi

## **Diagnostic Procedure (Cont'd)**

#### CHECK VARIABLE NOZZLE TURBOCHARGER CONTROL ACTUATOR

- 1. Turn ignition switch "OFF".
- 2. Install a vacuum pump to variable nozzle turbocharger control actuator.
- 3. Make sure that the variable nozzle turbocharger control actuator rod moves smoothly when applying vacuum of -53.3 kPa (-533 mbar, -400 mmHg, -15.75 inHg) and releasing it.




SEF322Z

#### OK or NG

OK ▶	GO TO 4.
NG ►	Replace turbocharger assembly.

#### 4 CHECK VACUUM HOSE

- 1. Turn ignition switch "OFF".
- 2. Check vacuum hoses and vacuum gallery for clogging, cracks or improper connection.






SEF109L

#### OK or NG

OK ►	GO TO 9.
NG •	Repair or replace vacuum hoses and vacuum gallery.

ZD30DDTi

## **Diagnostic Procedure (Cont'd)**



ZD30DDTi

## **Diagnostic Procedure (Cont'd)**

#### 7 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M21, E127
- Harness connectors E69, E202
- Fuse block (J/B) connector M2
- 10A fuse
- Harness for open or short between variable nozzle turbocharger control solenoid valve and fuse
  - ▶ Repair open circuit or short to ground or short to power in harness or connectors.

## 8 CHECK VARIABLE NOZZLE TURBOCHARGER CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

- 1. Turn ignition switch "OFF".
- 2. Disconnect ECM harness connector.
- 3. Check harness continuity between ECM terminal 101 and variable nozzle turbocharger control solenoid valve terminal 1. Refer to Wiring Diagram.

#### Continuity should exist.

4. Also check harness for short to ground and short to power.

_	1/	or	N.I	^
()	ĸ	Or	N	(i

OK •	GO TO 10.
NG •	GO TO 9.

#### 9 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E230, F12
- Harness for open or short between variable nozzle turbocharger control solenoid valve and ECM
  - Repair open circuit or short to ground or short to power in harness or connectors.

**ZD30DDTi** 

ST


BT

HA


EL

SE

## **Diagnostic Procedure (Cont'd)**



11	CHECK INTERMITTENT I	NCIDENT	
Perform	Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107.		
	► INSPECTION END		



### **Description**

With the heat up switch ON, engine speed is increased and the exhaust gas control valve is closed, which helps to promote heating and improve heating performance.

The exhaust gas control valve control solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the solenoid valve is bypassed to apply vacuum pump vacuum to the exhaust gas control valve actuator. This operation closes the exhaust gas control valve. When the ECM sends an OFF signal, the vacuum signal is cut and the exhaust gas control valve opens.

## **CONSULT-II Reference Value in Data Monitor Mode**

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
EXH/GAS REG V	<ul> <li>Vehicle: Stopped</li> <li>Engine speed: Below 1,200 rpm</li> <li>Engine coolant temperature: Below 87°C (189°F)</li> <li>Heat up switch: ON</li> </ul>	ON
	Except above	OFF

#### **ECM Terminals and Reference Value**


Specification data are reference values, and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
11	BR/Y	Exhaust gas control valve control solenoid valve	Engine is running.  Engine speed is below 1,200 rpm Engine coolant temperature is below 87°C (189°F) Stop the vehicle Heat up switch is "ON"	Approximately 0.1V
			Engine is running.  Except the above condition	BATTERY VOLTAGE (11 - 14V)

ZD30DDTi



ZD30DDTi

## **Diagnostic Procedure**

1	INSPECTION START		
Do you l	Do you have CONSULT-II?		
Yes or No			
Yes	<b>•</b>	GO TO 2.	
No	<b>&gt;</b>	GO TO 3.	

#### 2 CHECK OVERALL FUNCTION-I


#### With CONSULT-II

- 1. Turn ignition switch "ON".
- 2. Select "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II.
- 3. Make sure that "COOLAN TEMP/S" indication is below 60°C (140°F). If out of range, cool down the engine.

#### NOTE

The following procedure should be performed before the engine coolant temperature reaches 87°C (189°F).

- 4. Disconnect vacuum hose connected to exhaust gas control valve actuator.
- 5. Start engine and let it idle.
- 6. Check vacuum hose for vacuum existence under the following conditions.







Heat up switch	Vacuum
ON	Should exist.
OFF	Should not exist.

Operation takes less than 1 second.

SEF318Z

ОК	<b>•</b>	GO TO 4.
NG	<b>•</b>	GO TO 5.

## EXHAUST GAS CONTROL VALVE CONTROL SOLENOID VALVE

ZD30DDTi

## Diagnostic Procedure (Cont'd)

#### CHECK OVERALL FUNCTION-I

#### Without CONSULT-II


3

7. Turn ignition switch "ON".


8. Make sure that voltage between ECM terminal 19 and ground is more than 1.88V. If out of range, cool down the engine.

The following procedure should be performed before the voltage becomes less than 1.06V.

- 9. Disconnect vacuum hose connected to exhaust gas control valve actuator.
- 10. Start engine and let it idle.
- 11. Check vacuum hose for vacuum existence under the following conditions.







Operation takes less than 1 second.


SEF318Z

#### OK or NG

OK ▶	GO TO 4.
NG ►	GO TO 5.

#### 4 CHECK OVERALL FUNCTION-II

- 1. Turn ignition switch "OFF".
- 2. Remove exhaust gas control valve actuator from exhaust tube.
- 3. Install a vacuum pump to exhaust gas control valve actuator.
- 4. Make sure that the exhaust gas control valve moves smoothly when applying vacuum of -86.6 to -93.3 kPa (-866 to -93.3 kPa (-



SEF319Z

ok	or	NG
----	----	----

OK •	INSPECTION END
NG ►	Replace exhaust gas control valve assembly.

GI

MA

EM

LC

EC

FE

GL

MT

AT

97

TF

PD

FA

RA

BR

ST

RS

RT

HA


EL

SE

# EXHAUST GAS CONTROL VALVE CONTROL SOLENOID VALVE


ZD30DDTi

## Diagnostic Procedure (Cont'd)




#### 6 CHECK EXHAUST GAS CONTROL VALVE CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

- 1. Turn ignition switch "OFF".
- 2. Disconnect exhaust gas control valve control solenoid valve harness connector.



SEF285Z

- 3. Turn ignition switch "ON".
- 4. Check voltage between exhaust gas control valve control solenoid valve terminal 2 and ground with CONSULT-II or tester.



SEF312Z

OK	or	NG
----	----	----

OK ▶	GO TO 8.
NG ▶	GO TO 7.


## EXHAUST GAS CONTROL VALVE CONTROL SOLENOID VALVE


ZD30DDTi

## **Diagnostic Procedure (Cont'd)**

#### GI **DETECT MALFUNCTIONING PART** Check the following. Harness connectors M21, E127 MA • Fuse block (J/B) connector M2 • 10A fuse • Harness for open or short between exhaust gas control valve control solenoid valve and fuse EM Repair open circuit or short to ground or short to power in harness or connectors. 8 CHECK EXHAUST GAS CONTROL VALVE CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT EC 1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 11 and exhaust gas control valve control solenoid valve terminal 1. Refer to Wiring Diagram. FE Continuity should exist. 4. Also check harness for short to ground and short to power. OK or NG OK GO TO 10. NG GO TO 9. MI 9 **DETECT MALFUNCTIONING PART** Check the following. Harness connectors M21, E127 Harness connectors M50, F5 TF Harness for open or short between exhaust gas control valve control solenoid valve and ECM Repair open circuit or short to ground or short to power in harness or connectors. PD 10 CHECK EXHAUST GAS CONTROL VALVE CONTROL SOLENOID VALVE FA 1. Apply 12V direct current between exhaust gas control valve control solenoid valve terminals. 2. Check air passage continuity of exhaust gas control valve control solenoid valve under the following conditions. RA Air passage continuity Condition between A and B FUSE) 12V direct current supply between Yes terminals 1 and 2 No supply No SEF335X OK or NG OK GO TO 11. HA NG Replace exhaust gas control valve control solenoid valve. **CHECK INTERMITTENT INCIDENT** 11 Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-107. INSPECTION END

## **Wiring Diagram**





## **General Specifications**

## **CARBURETOR**

Carburetor model			21J360-56
		Р	36 (1.42)
Throttle body bore	mm (in)	S	40 (1.57)
Venturi diameter mm (in) –		Р	32 (1.26)
		S	36 (1.42)
		Р	#140
Main jet		S	#210
		Р	#60
Main air bleed		S	#80
01			#50
Slow jet		S	#130
01		Р	#170
Slow air bleed		S	#60
Power jet			#120
Choke type			Automatic choke
Fast idle adjustment			
Fast idle speed (A/T model in "N" position)		rpm	1,600±200
Clearance "A" (at 2nd cam step) mm (in)		1.37±0.14 (0.0539±0.0055)	
Vacuum break adjustment		mm (in)	
Clearance "R <sub>1</sub> "			3.25±0.25 (0.1280±0.0098)
Clearance "R <sub>2</sub> "			5.0±0.5 (0.197±0.020)
Idle appead	rpm Normal Air conditioner: ON		650±50
Idle speed rpm			1,100±50
Ignition timing (BTDC)			10°±1°
Idle CO%			1.5

P: Primary S: Secondary #: 1/100 mm

Vacuum motor

kPa (mbar, mmHg, inHg)

	, , ,
Opening starts	-9.6 (-96, -72, -2.83)
Fully open	Over -19.5 (-195, -146, -5.75)

## **Inspection and Adjustment**

### ATC AIR CLEANER

Intake manifold vacuum kPa (mbar, mmHg, inHg)		temperature (°F)
	Below 38 (100)	Above 48 (118)
Below 10.7 (107, 80, 3.15)	Cool air	Cool air
Above 22.7 (227, 170, 6.69)	Hot air	Cool air

#### **IDLE COMPENSATOR**

	Unit: °C (°F)
Idle compensator partially opens	65 - 74 (149 - 165)
Idle compensator fully opens	Above 74 (165)

#### **FUEL PUMP**

Fuel pump capacity mℓ (Imp fl oz)/minute	1,250 (44.0)
Fuel pressure kPa (bar, kg/cm², psi)	14.7 (0.147, 0.15, 2.1)


#### **BCDD**


BCDD set pressure (at sea level)	-76.0±0.7 (-760±7,
kPa (mbar, mmHg, inHg)	-570±5, -22.44±0.20)

### **DISTRIBUTOR**

Firing order	1-5-3-6-2-4
Rotating direction	Counterclockwise
Air gap mm (i	n) 0.25 - 0.5 (0.0098 - 0.0197)
Cap insulation resistance M	Ω More than 50
Rotor head insulation resistance	More than 50

### Distributor spark advance curve





#### **IGNITION COIL**

Primary resistance [at 20°C (68°F)]	Ω	Approximately 1
Secondary resistance [at 20°C (68°F)]	kΩ	Approximately 10

MA

EM

LC

EC

FE

GL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

SE

## **General Specifications**

	Unit: rpm
Engine	ZD30DDTi
Idle speed	750±25
Maximum engine speed	4,300

## **Injection Pump Numbers**

Engine	Part number	Pump assembly number
ZD30DDTi	16700 VG100	109342-4023

## **Injection Nozzle**

Unit: kPa (bar, kg/cm², psi)

	Used	19,026 (190.3, 194, 2,759)
Initial injection pressure	New	19,516 - 20,497 (195.2 - 205.0, 199 - 209, 2,830 - 2,972)
	Limit	16,182 (161.8, 165, 2,346)

## **Engine Coolant Temperature Sensor**

Temperature °C (°F)	Resistance k $\Omega$
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

## **Crankshaft Position Sensor (TDC)**

Resistance [at 20°C (68°F)] Ω	1,287 - 1,573
-------------------------------	---------------

## **Glow Plug**

Resistance [at 20°C (68°F)] $\Omega$	Approximately 0.5
--------------------------------------	-------------------

### **Accelerator Position Sensor**

Throttle valve conditions	Resistance between terminals 2 and 3 kΩ [at 25°C (77°F)]
Completely closed	Approximately 0.5
Partially open	0.5 - 4
Completely open	Approximately 4

## **EGR Volume Control Valve**