

E INDEX

INDEX----- E - 1
RHD VEHICLE----- E - 1
LHD VEHICLE ----- E - 4

1 INDEX

1-1 RHD VEHICLE

| | ITEM | PAGE | ITEM | PAGE | |
|---|---|-----------------|--|-------|---|
| A | A/C evap. sensor | D-266 | Data link connector (A/T CONTROL) | D-81 | |
| | A/C switch | D-265 | Data link connector (SRS AIRBAG SYSTEM) | D-93 | |
| | A/T ECU (ENGINE CONTROL SYSTEM) | D-36 | Data link connector (IMMOBILIZER SYSTEM) | D-121 | |
| | A/T ECU (VSC) | D-70 | Data link connector (METER) | D-162 | |
| | A/T ECU (A/T CONTROL) | D-81 | Data link connector | D-273 | |
| | ABS G sensor | D-61 | Defogger | D-137 | |
| | Airbag cut off switch | D-95 | Defogger relay | D-137 | |
| | Airbag squib | D-93 | Defogger switch | D-137 | |
| | Alternator | D-25 | Deicer | D-145 | |
| | Ambient sensor | D-266 | Deicer relay | D-145 | |
| | Antenna coil | D-121 | Deicer switch | D-145 | |
| B | Back-up lamp | D-217 | Diode (Courtesy) | D-114 | |
| | Back-up lamp switch | D-217 | Diode | D-53 | |
| | Brake actuator(ABS) | D-61 | Dome lamp | D-105 | |
| | Brake actuator(VSC) (ENGINE CONTROL SYSTEM) | D-36 | Door control receiver | D-113 | |
| | Brake actuator(VSC) (VSC) | D-69 | Door lock motor | D-113 | |
| | Brake actuator(VSC) (A/T CONTROL) | D-82 | Door lock position switch | D-114 | |
| | Brake vacuum pressure switch | D-34 | Dual pressure switch | D-265 | |
| C | Cam position sensor | D-34 | Duty solenoid | D-81 | |
| | Center airbag sensor(Computer) | D-93 | EFI ECU (ENGINE CONTROL SYSTEM) | D-33 | E |
| | Center diff. lock switch | D-53 | EFI ECU (VSC) | D-70 | |
| | Center indicator | Airbag cutt off | EFI ECU (A/T CONTROL) | D-82 | |
| | | | EFI ECU (METER) | D-163 | |
| | | Security | EFI main relay | D-34 | |
| | | | Flasher relay | D-193 | F |
| | | Seat belt | Floor shift illumination | D-209 | |
| | | | Fog lamp relay | D-186 | |
| | | Tail | Fog lamp switch | D-185 | |
| | | | Front fog lamp | D-186 | |
| | Clearance lamp | D-209 | Front oxygen sensor | D-34 | |
| | Courtesy switch | D-114 | Front satellite sensor | D-93 | |
| | Crank position sensor | D-34 | Front turn lamp | D-193 | |
| | Curtain shield airbag | D-94 | Front washer motor | D-225 | |
| D | Data link connector | D-35 | Front wiper motor | D-225 | |
| | (ENGINE CONTROL SYSTEM) | | Front wiper switch | D-225 | |
| | Data link connector (ABS) | D-61 | Fuel pump motor | D-34 | |
| | Data link connector (VSC) | D-69 | Fuel pump relay | D-34 | |

| ITEM | | PAGE | ITEM | | PAGE |
|------|--------------------------|-------------------------|---------------------------------------|------------------------|-------|
| G | Fuel sender gauge | D-162 | Meter | Center diff. | D-53 |
| | Glove box illumination | D-209 | | Charging | D-25 |
| H | Hazard switch | D-193 | | DAC | D-72 |
| I | Headlamp | D-173 | | Front fog | D-185 |
| | Headlamp leveling switch | D-175 | | FUEL | D-161 |
| | Headlamp leveling unit | D-175 | | High beam | D-173 |
| | Headlamp relay | D-173 | | High-water temperature | D-162 |
| | Headlamp switch | D-173 | | LCD | D-161 |
| | Heated mirror | D-137 | | Low Fuel | D-163 |
| | Heater blower motor | D-266 | | Low-water temperature | D-162 |
| | Heater blower switch | D-266 | | Meter illumination | D-210 |
| | Heater relay | D-265 | | MIL | D-36 |
| | Heater resistor | D-266 | | O/D OFF | D-83 |
| | High mounted stop lamp | D-201 | | Oil | D-163 |
| | Horn | D-249 | | Rear fog | D-185 |
| | Horn relay | D-249 | | Slip | D-72 |
| | Horn switch | D-249 | | SPEED | D-161 |
| | Ignition coil | D-33 | | TACHO | D-161 |
| | Immobilizer ECU | D-121 | | Tail | D-210 |
| | Injector | D-35 | | TRC OFF | D-72 |
| | Intake air temp. sensor | D-35 | | Turn | D-193 |
| | ITC ECU | D-113 | | VSC | D-72 |
| K | Key switch | D-161 | | VSC OFF | D-72 |
| L | Knock sensor | D-34 | Meter | | D-114 |
| | License plate lamp | D-209 | MGC relay | | D-265 |
| | Linear throttle sensor | D-34 | Mirror adjust | | D-129 |
| | LUC solenoid | D-81 | Multi information display mode switch | | D-161 |
| M | Luggage room lamp | D-105 | Neutral start switch (Except R range) | | D-81 |
| | Magnet clutch | D-265 | Neutral start switch (R range) | | D-217 |
| | Master switch | D-153 | O/D OFF switch | | D-81 |
| | Meter | A/T indicator | Oil control valve | | D-35 |
| | | ABS (ABS) | Oil fluid level switch | | D-163 |
| | | ABS (VSC) | Oil pressure switch | | D-163 |
| | | Airbag | Oil temperature sensor | | D-81 |
| | | Brake | Outer mirror switch | | D-129 |
| | | Buzzer (METER) | Output revolution sensor | | D-82 |
| | | Buzzer (Light reminder) | Parking brake switch | | D-163 |

| | ITEM | PAGE | ITEM | PAGE | |
|---|----------------------|-------|----------------------------|-------|---|
| | Power outlet | D-257 | Tail lamp switch | D-209 | |
| | Power window motor | D-153 | TRC OFF switch | D-72 | |
| | Power window switch | D-153 | Turbine revolution sensor | D-82 | |
| | Pressure sensor | D-35 | Turn signal switch | D-193 | |
| | Pretensioner | D-93 | VSC main relay | D-69 | V |
| | Purge VSV | D-35 | VSC motor relay | D-69 | |
| R | R/S ISC | D-35 | VSV1 | D-53 | |
| | RAD FAN relay | D-45 | VSV2 | D-53 | |
| | Radiator fan motor | D-45 | Water temp. sensor | D-35 | W |
| | Radio | D-241 | Yaw rate sensor & G sensor | D-71 | Y |
| | Rear fog lamp | D-185 | | | |
| | Rear oxygen sensor | D-34 | | | |
| | Rear turn lamp | D-193 | | | |
| | Rear washer motor | D-233 | | | |
| | Rear wiper motor | D-233 | | | |
| | Rear wiper switch | D-233 | | | |
| | Room & Map lamp | D-105 | | | |
| | Room lamp | D-105 | | | |
| S | Seatbelt switch | D-161 | | | |
| | Side airbag | D-94 | | | |
| | Side airbag sensor | D-93 | | | |
| | Side turn lamp | D-193 | | | |
| | Solenoid No.1 | D-81 | | | |
| | Solenoid No.2 | D-81 | | | |
| | Solenoid No.3 | D-81 | | | |
| | Speaker | D-241 | | | |
| | Speed sensor (ABS) | D-61 | | | |
| | Speed sensor (VSC) | D-69 | | | |
| | Speed sensor (METER) | D-163 | | | |
| | Starter | D-17 | | | |
| | Starter relay | D-17 | | | |
| | Steering sensor | D-71 | | | |
| | Stop lamp | D-201 | | | |
| | Stop lamp relay | D-70 | | | |
| | Stop lamp switch | D-201 | | | |
| | Switch solenoid | D-81 | | | |
| T | Tail lamp | D-209 | | | |

1-2 LHD VEHICLE

| | ITEM | PAGE | ITEM | PAGE | |
|---|---|----------------|--|-------|---|
| A | A/C evap. sensor | D-270 | Data link connector (A/T CONTROL) | D-87 | |
| | A/C switch | D-269 | Data link connector | D-99 | |
| | A/T ECU (ENGINE CONTROL SYSTEM) | D-42 | (SRS AIRBAG SYSTEM) | | |
| | A/T ECU (VSC) | D-76 | Data link connector (IMMOBILIZER SYSTEM) | D-125 | |
| | A/T ECU (A/T CONTROL) | D-87 | Data link connector (METER) | D-168 | |
| | ABS G sensor | D-65 | Data link connector | D-277 | |
| | Airbag cut off switch | D-101 | Defogger | D-141 | |
| | airbag squib | D-99 | Defogger relay | D-141 | |
| | Alternator | D-29 | Defogger switch | D-141 | |
| | Ambient sensor | D-270 | Deicer | D-149 | |
| | Antenna coil | D-125 | Deicer relay | D-149 | |
| B | Back-up lamp | D-221 | Deicer switch | D-149 | |
| | Back-up lamp switch | D-221 | Diode | D-57 | |
| | Brake actuator(ABS) | D-65 | Diode(Courtesy) | D-118 | |
| | Brake actuator(VSC) (ENGINE CONTROL SYSTEM) | D-42 | Dome lamp | D-109 | |
| | Brake actuator(VSC) (VSC) | D-75 | Door control receiver | D-117 | |
| | Brake actuator(VSC) (A/T CONTROL) | D-88 | Door lock motor | D-117 | |
| | Brake vacuum pressure switch | D-39 | Door lock position switch | D-118 | |
| C | Cam position sensor | D-40 | Dual pressure switch | D-269 | |
| | Center airbag sensor(Computer) | D-99 | Duty solenoid | D-87 | |
| | Center diff. lock switch | D-57 | EFI ECU (ENGINE CONTROL SYSTEM) | D-39 | E |
| | Center indicator | Airbag cut off | EFI ECU (VSC) | D-76 | |
| | | Security | EFI ECU (A/T CONTROL) | D-88 | |
| | | Seatbelt | EFI ECU (METER) | D-169 | |
| | | Tail | EFI main relay | D-40 | |
| | Clearance lamp | D-213 | Flasher relay | D-197 | F |
| | Courtesy switch | D-118 | Floor shift illumination | D-213 | |
| | Crank position sensor | D-40 | Fog lamp relay | D-190 | |
| | Curtain shield airbag | D-100 | Fog lamp switch | D-189 | |
| D | Data link connector | D-41 | Front fog lamp | D-190 | |
| | (ENGINE CONTROL SYSTEM) | | Front oxygen sensor | D-40 | |
| | Data link connector (ABS) | D-65 | Front satellite sensor | D-99 | |
| | Data link connector (VSC) | D-75 | Front turn lamp | D-197 | |
| | | | Front washer motor | D-229 | |
| | | | Front wiper motor | D-229 | |
| | | | Front wiper switch | D-229 | |
| | | | Fuel pump motor | D-40 | |

| ITEM | | PAGE | ITEM | | PAGE |
|------|--------------------------|-------|------|---------------------------------------|-------|
| | Fuel pump relay | D-40 | | Buzzer (Light reminder) | D-214 |
| | Fuel sender gauge | D-168 | | Center diff. | D-57 |
| G | Glove box illumination | D-213 | | Charge | D-29 |
| H | Hazard switch | D-197 | | DAC | D-78 |
| | Headlamp | D-179 | | Front fog | D-189 |
| | Headlamp leveling switch | D-181 | | FUEL | D-167 |
| | Headlamp leveling unit | D-181 | | High beam | D-179 |
| | Headlamp relay | D-179 | | High-water temperature | D-168 |
| | Headlamp switch | D-179 | | LCD | D-167 |
| | Heated mirror | D-141 | | Low fuel | D-169 |
| | Heater blower motor | D-270 | | Low-water temperature | D-168 |
| | Heater blower switch | D-270 | | Meter illumination | D-214 |
| | Heater relay | D-269 | | MIL | D-42 |
| | Heater resistor | D-270 | | O/D OFF | D-89 |
| | High mounted stop lamp | D-205 | | Oil | D-169 |
| | Horn | D-253 | | Rear fog | D-189 |
| | Horn relay | D-253 | | Slip | D-78 |
| | Horn switch | D-253 | | SPEED | D-167 |
| I | Ignition coil | D-39 | | TACHO | D-167 |
| | Immobilizer ECU | D-125 | | Tail | D-214 |
| | Injector | D-40 | | TRC OFF | D-78 |
| | Intake air temp. sensor | D-41 | | Turn | D-197 |
| | ITC ECU | D-117 | | VSC | D-78 |
| K | Key switch | D-167 | | VSC OFF | D-78 |
| | Knock sensor | D-40 | | Meter | D-118 |
| L | License plate lamp | D-213 | | MGC relay | D-269 |
| | Linear throttle sensor | D-40 | | Mirror adjust | D-133 |
| | LUC solenoid | D-87 | | Multi information display mode switch | D-167 |
| | Luggage room lamp | D-109 | | Neutral start switch (Except R range) | D-87 |
| M | Magnet clutch | D-269 | | Neutral start switch (R range) | D-221 |
| | Master switch | D-157 | | O/D OFF switch | D-87 |
| | | | | Oil control valve | D-41 |
| | A/T indicator | D-89 | | Oil fluid level switch | D-169 |
| | ABS (ABS) | D-66 | | Oil pressure switch | D-169 |
| | ABS (VSC) | D-78 | | Oil temperature sensor | D-87 |
| | Airbag | D-102 | | Outer mirror switch | D-133 |
| | Brake | D-168 | | Output revolution sensor | D-88 |
| | Buzzer (METER) | D-167 | | | |

| | ITEM | PAGE | ITEM | PAGE | |
|---|----------------------|-------|----------------------------|-------|---|
| P | Parking brake switch | D-169 | Tail lamp | D-213 | T |
| | Power outlet | D-261 | Tail lamp switch | D-213 | |
| | Power window motor | D-157 | TRC OFF switch | D-78 | |
| | Power window switch | D-157 | Turbine revolution sensor | D-88 | |
| | Pressure sensor | D-41 | Turn signal switch | D-197 | |
| | Pretensioner | D-99 | VSC main relay | D-75 | V |
| | Purge VSV | D-41 | VSC motor relay | D-75 | |
| R | R/S ISC | D-41 | VSV1 | D-57 | |
| | RAD FAN relay | D-49 | VSV2 | D-57 | |
| | Radiator fan motor | D-49 | Water temp. sensor | D-41 | W |
| | Radio | D-245 | Yaw rate sensor & G sensor | D-77 | Y |
| | Rear fog lamp | D-189 | | | |
| | Rear oxygen sensor | D-40 | | | |
| | Rear turn lamp | D-197 | | | |
| | Rear washer motor | D-237 | | | |
| | Rear wiper motor | D-237 | | | |
| | Rear wiper switch | D-237 | | | |
| | Room & Map lamp | D-109 | | | |
| | Room lamp | D-109 | | | |
| S | Seatbelt switch | D-167 | | | |
| | Side airbag | D-100 | | | |
| | Side airbag sensor | D-99 | | | |
| | Side turn lamp | D-197 | | | |
| | Solenoid No.1 | D-87 | | | |
| | Solenoid No.2 | D-87 | | | |
| | Solenoid No.3 | D-87 | | | |
| | Speaker | D-245 | | | |
| | Speed sensor (ABS) | D-65 | | | |
| | Speed sensor (VSC) | D-75 | | | |
| | Speed sensor (METER) | D-169 | | | |
| | Starter | D-21 | | | |
| | Starter relay | D-21 | | | |
| | Steering sensor | D-77 | | | |
| | Stop lamp | D-205 | | | |
| | Stop lamp relay | D-76 | | | |
| | Stop lamp switch | D-205 | | | |
| | Switch solenoid | D-87 | | | |

TO INDEX

TO NEXT SECTION