

Special Tool Glossary

Service Tools

Special service tools have been developed to facilitate removal, dismantling and assembly of mechanical components in a cost effective and time efficient manner. The use of such special tools also helps prevent the potential for damage to components.

Some operations described in this manual cannot be carried out properly without the aid of the relevant service tools.

All orders and enquiries from the United Kingdom and European countries except Germany, Austria, Switzerland and Spain and countries not in the following list should be sent direct to:

SPX UK Ltd.,

Genoa House,

Everdon Park,

Daventry,

Northants,

NN11 5YJ

England

Tel: 0044 (0) 1327 303467/303455

Fax: 0044 (0) 1327 706632

e-mail: spxsalesuk@servicesolutions.spx.com

Overseas orders for the following countries should be placed with the local distributor.

Germany, Austria and Switzerland

SPX Europe GMBH,

Porschestraße 4,

63512 Hainburg,

Germany

Tel: 0049 61829590

Fax: 0049 6182959299

Spain

SPX Iberica SA,

C/Francisco Aritio,
158 nave 72 (Nudo Oeste),
19004 Guadalajara,
Spain
Tel: 0034 949208381
Fax: 0034 949208327

North America

SPX Corporation
665, Eisenhower Drive,
Owatonna,
MN 55060,
USA
Tel: 0018 772979110
Fax: 0018 005787375

Australia

SPX Australia,
28, Clayton Road,
Notting Hill,
Victoria 3168,
Australia
Tel: 0061 00395446222
Fax: 0061 00395445222
e-mail: sales@spx.com.au

Japan and East Asia

Jatek Ltd.,
5 - 53, Minawacho 2-chome,

Kohoku-ku,
Yokohama,
Kanagawa 223-0051,
Japan
Tel: 0081 455627700
Fax: 0081 455627800