


Published: Jun 29, 2004

Parking Brake Switch (70.35.46)

Removal

1. Remove the parking brake switch.
 - ▶ Remove the cover.
 - ▶ Remove the retaining screw.
 - ▶ Disconnect the electrical connector.



Installation

1. To install, reverse the removal procedure.