

Published: Jun 30, 2004

Brake Pedal and Bracket - Vehicles With: Manual Transmission (70.35.03)

Removal

NOTE:

The brake pedal, clutch pedal and bracket is serviced as a complete assembly. The procedure to remove and install the assembly is shown in the clutch pedal procedure.

1. Remove the clutch and brake pedal assembly. For additional information, refer to [Clutch Pedal \(33.30.02\)](#) (Section 308-02)

Installation

1. Install the clutch and brake pedal assembly. For additional information, refer to [Clutch Pedal \(33.30.02\)](#) (Section 308-02)