


Published : Mar 2, 2001


## Connecting Rod Large End Bore

1 . Measure the bearing bore in two directions. The difference is the connecting rod bore out-of-round. Verify the out-of-round is within specification.



VUJ0002223

2 . Measure the bearing bore diameter in two directions. Verify the bearing bore is within specification.



VUJ0002222