

Published : Mar 2, 2001

Crankshaft End Play

- 1 . Using the Dial Indicator Gauge with Brackets, measure the end play.
 - Measure the end play by lifting the crankshaft using a lever.
 - If the value is out of the specification, install new thrust half rings to take up the end float and repeat the measurement.

