


Published : Apr 28, 2004



Accessory Drive



E50592

Item	Part Number	Description
1	-	Generator
2	-	Deflection pulley
3	-	Power steering pump
4	-	A/C compressor
5	-	Coolant pump
6	-	Crankshaft pulley
7	-	Accessory drive belt
8	-	Tensioner assembly

The engine crankshaft pulley drives the accessory components, which comprise the torsional vibration damper, generator, power steering pump, A/C compressor and coolant pump, via the accessory drive belt.

The belt, which is maintenance free poly-V type belts, are automatically pre-loaded by the tensioning rollers and are routed over deflection pulleys in order to maintain sufficient adhesion about the drive wheels. This ensures slip-free drive of the accessory components.