

Published : Jun 14, 2005

A-Pillar Moulding LH

Removal

NOTE :

This procedure is also applicable for the RH moulding.

- 1 . Open the bonnet. Remove the A-pillar moulding.
▶ Release and discard the 5 clips.



Installation

- 1 . **NOTE :**
The lower clip is unique to the others and must only be installed to the lowest position on the moulding.
To install, reverse the removal procedure.
▶ New clips must be used.