


Published : Feb 24, 2004

Interior Mirror (76.10.51)

Removal

1. If installed, remove the interior mirror upper and lower covers.


▶ Release the 2 clips.



2. Vehicles with an auto-dimming interior mirror, remove the interior mirror.

▶ Disconnect the electrical connector.

▶ Rotate the mirror stem at its base to release from the windshield.



3. Vehicles without an auto-dimming interior mirror, remove the interior mirror.

▶ Pull the mirror away from the windshield to release the clip.




Installation

1. Vehicles without an auto-dimming interior mirror, install the interior mirror.
 - ▶ Slide the mirror onto the boss from above to engage the clip.



E49730

2. Vehicles with an auto-dimming interior mirror, install the interior mirror.
 - ▶ Rotate the mirror stem at its base to secure to the windshield.
 - ▶ Connect the electrical connector.



E49731

3. Install the interior mirror covers.
 - ▶ Secure with the clips.