


Published : Mar 25, 2004

Rear Door Window Control Switch

Removal

1. Remove the window control switch.
 - ▶ Carefully release the front of the switch.
 - ▶ Disconnect the electrical connector.



Installation

1. To install, reverse the removal procedure.