



## Fender Apron Panel Closing Panel

### Removal


#### NOTE :

In this procedure the fender apron closing panel is replaced in conjunction with the fender apron panel or the fender apron panel reinforcement.

- 1 . Disconnect both battery cables. For additional information, refer to [Specifications](#) (Section 414-00 Charging System - General Information)
- 2 . Remove the fender apron panel. For additional information, refer to [Fender Apron Panel](#) (Section 501-27 )
- 3 . Remove the fender apron panel reinforcement. For additional information, refer to [Fender Apron Panel Reinforcement](#) (Section 501-27 )

4 .

Item	Description
1	7 plug welds.
2	2 spot welds.
3	2 spot welds.
4	5 plug welds.



E56612

- 5 . For additional information:
  - Welding. For additional information, refer to [Body Repairs](#) (Section 501-25A Body Repairs - General Information)
  - Corrosion protection. For additional information, refer to [Corrosion Protection](#) (Section 501-25B Body Repairs - Corrosion Protection)
  - Tolerance checks. For additional information, refer to [Body and Frame](#) (Section 501-26 Body Repairs - Vehicle Specific Information and Tolerance Checks)

### Installation

- 1 . Install is the reversal of removal.