


AUTOMATIC TRANSAXLE CROSS-SECTIONAL VIEW

B3E051701030A03



B3E0517T002

1	Torque converter
2	Oil pump
3	Forward clutch

4	Front planetary gear
5	Rear planetary gear
6	3-4 clutch
7	Reverse clutch
8	2-4 brake band
9	Low and reverse brake
10	One-way clutch
11	Primary gear
12	Secondary gear
13	Output gear
14	Differential