


# TORQUE CONVERTER OUTLINE

---

B3E051719100A01

- The torque converter clutch mechanism mechanically engages the pump impeller and the turbine runner under a certain condition, and transmits the power, not through the fluid, but directly, preventing the slip loss of the torque converter.
- The torque converter has obtained sufficient transaxle efficiency and torque converting ratio that matches the output characteristic of each engine.



B3E0517A014