


## ONE-WAY CLUTCH OPERATION

B3E051701030A19

- The one-way clutch outer race (front internal gear) rotates clockwise (seen from the torque converter side) freely, but the sprags rise to lock the rotation when the outer race tries to rotate counterclockwise.
- The one-way clutch locks the counterclockwise rotation of the front internal gear, and also locks the counterclockwise revolution of the rear planetary gear via the rear planetary carrier.

### Note

- All direction of rotation are viewed from the torque converter.



B3E0517A004

1	One-way clutch outer race (front internal gear) cannot rotate
2	One-way clutch outer race (front internal gear) can rotate
3	One-way clutch inner race (fixed to transaxle case)
4	One-way clutch outer race (front internal gear)
5	One-way clutch
6	One-way clutch inner race
7	Transaxle case