

# PLANETARY GEAR OUTLINE

---

B3E051701030A20

- The planetary gear is a transaxle which converts the driving force of the turbine shaft to the optimal driving force and transmits it to the output gear through the operation of each clutch and brake.
- A double arranged gear with a single planetary gear unit is adopted for the planetary gear; they are the front planetary gear and the rear planetary gear (from converter side).
- The planetary gear consists of the internal gear, planetary carrier (pinion gears), and the sun gear.