

# PARKING MECHANISM OUTLINE

---

B3E051701030A23

- When the selector lever is shifted to P position, the parking pawl engages the parking gear and locks the output gear (i.e., rotation of the driving wheels).