

INSPECTION DURING REMOVAL, DISASSEMBLY

A6E201400004M04

- When removed, each part should be carefully inspected for malfunction, deformation, damage, and other problems.

