

# ENGINE ABBREVIATIONS

---

B3E010002000T01

AAS	Air Adjusting Screw
ABDC	After Bottom Dead Center
ABS	Antilock Brake System
ACC	Accessories
ATDC	After Top Dead Center
ATX	Automatic Transaxle
BBDC	Before Bottom Dead Center
BDC	Bottom Dead Center
BTDC	Before Top Dead Center
CAN	Controller Area Network
CCM	Comprehensive Component Monitor
CM	Control Module
DC	Drive Cycle
DLC-2	Data Link Connector-2
DOHC	Double Overhead Camshaft
DSC	Dynamic Stability Control
DTC	Diagnostic Trouble Code
EX	Exhaust
FFD	Freeze Frame Data
HU	Hydraulic Unit
IN	Intake
KOEO	Key On Engine Off
KOER	Key On Engine Running
M	Motor
MTX	Manual Transaxle
OCV	Oil Control Valve
PATS	Passive Anti-theft System
PC	Pending Code
PID	Parameter Identification
P/S	Power Steering
SEI	Single Electric Ignition
SST	Special Service Tool
TAS	Throttle Adjust Screw
TDC	Top Dead Center
WDS	Worldwide Diagnostic System