

## OBD FREEZE FRAME DATA [LF]

---

B3E010200102W04

- This is the technical data which indicates the engine condition at the time of the first malfunction. This data will remain in the memory even if another emission-related DTC is stored, with the exception of Fuel system or Misfire DTCs. Once freeze frame data for Fuel system or Misfire DTC is stored, it will overwrite any previous data and the freeze frame will not be overwritten again.