


ENGINE LOCATION INDEX [LF]

B3E011001002W01



B3E0110W098

1	Drive belt (See DRIVE BELT INSPECTION [LF] .) (See DRIVE BELT REPLACEMENT [LF] .) (See DRIVE BELT AUTO TENSIONER INSPECTION [LF] .)
2	Tappet (See VALVE CLEARANCE INSPECTION [LF] .) (See VALVE CLEARANCE ADJUSTMENT [LF] .)
3	Engine (See COMPRESSION INSPECTION [LF] .) (See ENGINE REMOVAL/INSTALLATION [LF] .) (See ENGINE DISASSEMBLY/ASSEMBLY [LF] .)
4	Timing chain

	(See TIMING CHAIN REMOVAL/INSTALLATION [LF].)
5	Cylinder head gasket (See CYLINDER HEAD GASKET REPLACEMENT [LF].)
6	Front oil seal (See FRONT OIL SEAL REPLACEMENT [LF].)
7	Rear oil seal (See REAR OIL SEAL REPLACEMENT [LF].)
8	Plug hole plate (See PLUG HOLE PLATE REMOVAL/INSTALLATION [LF].)