

## ENGINE OIL LEVEL INSPECTION [ZJ, Z6]

---

B3E011114001W01

1. Position the vehicle on level ground.
2. Warm up the engine.
3. Stop the engine and allow **approx. 5 min** before continuing.
4. Remove the dipstick and verify that the oil level is between the F and L marks on the dipstick.
  - If the oil level is below the L mark, add engine oil.

