


ENGINE OIL LEVEL INSPECTION [LF]

B3E011114001W02

1. Position the vehicle on level ground.
2. Warm up the engine.
3. Stop the engine and allow **approx. 5 min** before continuing.
4. Remove the dipstick and verify that the oil level is between the MAX and MIN marks on the dipstick.
 - If the oil level is below the MIN mark, add engine oil.



B3E01111W005