

# THERMOSTAT INSPECTION [LF]

---

B3E011215171W04

1. Inspect the thermostat for the following.

## Warning

- During inspection, the thermostat and water are extremely hot and they can cause burns. Do not touch the thermostat and water.
- The valve should not open under normal temperature.
- Opening temperature and valve lift
  - If there is malfunction, replace the thermostat.

Item		Specification
Initial-opening temperature	(°C {°F})	80-84 {176-183}
Full-open temperature	(°C {°F})	97 {207}
Full-open lift	(mm {in})	8.0 {0.31} or more