


INTAKE-AIR SYSTEM DIAGRAM [ZJ, Z6]

B3E011300113T03



B3E0113T002

1	Resonance chamber
2	Air cleaner
3	PCM
4	IAC valve
5	Throttle body
6	Variable intake-air shutter valve actuator (Z6)
7	Variable intake-air shutter valve (Z6)
8	Variable tumble shutter valve actuator
9	Variable tumble shutter valve
10	Intake manifold
11	To PCM