


## RESONANCE CHAMBER FUNCTION [ZJ, Z6]

---

B3E011313191T01

- Installed on the fresh air duct to reduce intake air noise.



1	Resonance chamber
2	Fresh-air duct