


FUEL SYSTEM FLOW DIAGRAM [ZJ, Z6, LF]

B3E011401006W02



B3E01 14T004

1	Fuel-filler cap
2	Fuel filter (high-pressure)
3	Pressure regulator
4	Fuel pump unit
5	Fuel pump
6	Fuel filter (low-pressure)
7	Fuel tank
8	Fuel injector
9	Fuel flow