

EXHAUST SYSTEM INSPECTION [LF]

B3E011500115W03

1. Start the engine and inspect each exhaust system component for exhaust gas leakage.
 - If there is leakage, repair or replace the appropriate component.