


## EGR SYSTEM STRUCTURE [ZJ, Z6, LF]

B3E011601007T03


- Consists of an EGR valve and EGR pipe to conduct exhaust gas to the intake air system.

### System diagram [ZJ, Z6]



B3E01 16T005

### System diagram [LF]



B3E01 16T004

1	EGR valve
---	-----------