


## POSITIVE CRANKCASE VENTILATION (PCV) VALVE INSPECTION [ZJ, Z6, LF]

---

B3E011613890W01

1. Remove the intake manifold.
2. Remove the PCV valve.
3. Verify that there is no airflow when pressure is applied to port A.



- If there is airflow, replace the PCV valve.
4. Verify that there is airflow when vacuum is applied to port A.
- If there is no airflow, replace the PCV valve.