

ROLLOVER VALVE FUNCTION [ZJ, Z6, LF]

B3E011642720T01

- The rollover valve prevents fuel flow into the evaporative gas passage during sudden cornering or vehicle rollover.
- The built-in check valve (two-way) maintains a constant pressure in the fuel tank.