


IGNITION SYSTEM LOCATION INDEX [ZJ, Z6]

B3E011801009W01



B3E01 18T002

1	Ignition coil (See IGNITION COIL REMOVAL/INSTALLATION [ZJ, Z6].) (See IGNITION COIL INSPECTION [ZJ, Z6].)
2	Spark plug (See SPARK PLUG REMOVAL/INSTALLATION [ZJ, Z6].) (See SPARK PLUG INSPECTION.)