


B3E014000140T04

B3E0140T504



file:///R:/My%20Websites/Files/001%20NEW/Mazda%203%20BK/srvc/html/B3E01... 15/02/2019

2	Refrigerant pressure switch (low pressure, high pressure)
3	Refrigerant pressure switch (medium pressure)
4	VSS
5	Input/turbine speed sensor
6	TFT sensor
7	TR switch
8	Clutch switch
9	Neutral switch
10	Down switch
11	Up switch
12	M range switch
13	Pressure control solenoid
14	Shift solenoid
15	A/C relay
16	Main relay
17	Fuel pump relay
18	Instrument cluster
19	ABS HU/CM
20	DSC HU/CM
21	DLC-2
22	Fan control module
23	Starter relay
24	Ignition switch
25	Battery
26	EGR valve
27	IAT sensor
28	MAF sensor
29	TP sensor
30	BARO sensor
31	ECT sensor
32	Front HO2S
33	Rear HO2S
34	Generator (terminal P: stator coil)
35	CMP sensor
36	CKP sensor
37	KS
38	PSP switch
39	Fuel injector
40	OCV
41	IAC valve
42	Purge solenoid valve
43	Variable tumble shutter valve actuator
44	Variable intake-air shutter valve actuator (Z6)
45	Ignition coil No.1
46	Ignition coil No.2
47	Ignition coil No.3
...	

	Ignition coil No.4
49	To generator (terminal D: field coil)