

## VARIABLE TUMBLE CONTROL OUTLINE [ZJ, Z6]

---

B3E014000140T16

- At cold-engine start, the following occurs due to the closing of the variable tumble shutter valve for improved cold engine exhaust emission performance.

- Improved intake airflow speed near injectors
- Strong air tumble occurs in the combustion chamber, promoting vaporization mixture of intake air and fuel