


VARIABLE TUMBLE CONTROL BLOCK DIAGRAM [ZJ, Z6]

B3E014000140T17

- The PCM determines the engine operation conditions based on input signals and sends an operation signal to the variable tumble shutter valve actuator.



1	ECT sensor
2	CKP sensor
3	TP sensor
4	Variable tumble shutter valve actuator