


FUEL PUMP CONTROL BLOCK DIAGRAM [ZJ, Z6]

B3E014000140T26

- The PCM determines the engine starting condition based on each input signal and controls the fuel pump relay on/off.



1	CKP sensor
2	Instrument cluster (engine stop request signal)
3	Fuel pump relay