

## EVAPORATIVE PURGE CONTROL OUTLINE [ZJ, Z6]

---

B3E014000140T31

- An appropriate amount of evaporative gas is fed into the dynamic chamber by the driving of the purge solenoid valve according to the engine operation conditions to ensure driveability and prevent release of evaporative gas into the atmosphere.