


# HEATED OXYGEN SENSOR (HO2S) HEATER CONTROL BLOCK DIAGRAM [ZJ, Z6]

B3E014000140T38

- The PCM determines the engine operation conditions based on input signals and sends an operation signal to the front or rear HO2S.



B3E0140T533

1	ECT sensor
2	IAT sensor
3	CKP sensor
4	TP sensor
5	MAF sensor
6	BARO sensor
7	Battery
8	Front HO2S heater
9	Rear HO2S heater