

## MASS AIR FLOW (MAF) SENSOR FUNCTION [LF]

---

B3E014013211T01

- Detects the air amount (mass airflow amount) inducted into the engine.