


ENGINE COOLANT TEMPERATURE (ECT) SENSOR CONSTRUCTION/OPERATION [ZJ, Z6]

B3E014018840T02


- Installed on the cylinder head.



B3E0140T511

1 ECT sensor

- A thermistor type is used and the resistance changes according to the ECT.
- As shown in the characteristics graph, when the ECT is high, the resistance is small, and when the ECT is low, the resistance is large.



B3E0140T556

1	ECT sensor
2	PCM
3	CPU
4	ECT sensor characteristic
5	Resistance (kilohm)
6	ECT