

INTAKE AIR TEMPERATURE (IAT) SENSOR FUNCTION [ZJ, Z6]

B3E014018840T03

- Detects the IAT.