


CONTROL SYSTEM DIAGRAM [LF]

B3E014018880W11



B3E0140T002

1	Air cleaner
2	MAF/IAT sensor
3	TP sensor
4	MAP sensor
5	CMP sensor
6	KS
7	ECT sensor
8	CKP sensor
9	Front HO2S

10	Rear HO2S
11	Purge solenoid valve
12	EGR valve
13	Variable intake-air solenoid valve
14	Variable tumble solenoid valve
15	IAC valve
16	BARO sensor
17	PCM
18	To PCM