

EGR CONTROL OUTLINE [LF]

B3E014018881T28

- Adjusts the EGR valve to the optimum opening angle according to engine operation conditions.
- The valve in the EGR valve allows for more precise control by being driven by the stepping motor.