


EGR CONTROL BLOCK DIAGRAM [LF]

B3E014018881T29



B3E0140T017

1	MAF sensor
2	IAT sensor
3	TP sensor
4	ECT sensor
5	CKP sensor
6	Neutral switch
7	CPP switch
8	Battery voltage
9	Vehicle speed signal (CAN)
10	EGR valve operation step number
11	Target EGR valve position
12	Current EGR valve position
13	Basic EGR valve position
14	Corrections
15	EGR valve